

User Manual

150S



© Excell Precision Limited 2021. All rights reserved worldwide.

The information contained herein is the property of Excell Precision Limited and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorised by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.



6F, No. 127, Lane 235, Baoqiao Rd., Xindian District,
New Taipei City 23145, Taiwan



pm-all@excell.com.tw



+886-2-8919-1000



<https://www.excell-scale.com>



+886-2-8919-2209



TABLE OF CONTENTS

Safety.....	3
Features.....	3
Chapter 1 Front and Rear Panel Specifications.....	4
1-1 Front panel.....	4
1-2 Rear panel	4
1-3 Keypad Description.....	5
1-4 Specification	5
1-5 Display Firmware Version	6
Chapter 2 General Function Guide	7
2-1 Function Setup and Operation Procedures.....	7
2-2 Error Messages (Display in General Function setting).....	8
2-3 Function Setting 08888.....	10
2-4 Set internal calibration password (FNC-16)	13
Chapter 3 Calibration	14
3-1 Load Cell Connection	14
3-2 Parameter Setting and Calibration Flow Chart.....	15
3-3 MODBUS Calibration.....	17
3-4 Specification calibration 08898.....	18
3-5 General Calibration 08888.....	20
3-6 Linearity calibration 08888.....	21
3-7 Digital calibration 08 888.....	23
Chapter 4 Weight Comparison Procedures.....	24
4-1 Function Configuration Menu.....	24
4-2 Check Weighing Configuration	27
4-3 Batching Signal Outputs	30
4-4 Normal batching flow chart (SQ-01=1).....	31
4-5 Loss-in Weight flow chart (SQ1=2)	32
4-6 Hi, OK, Lo output flowchart.....	33
4-7 Normal batching (built-in program) flowchart (SQ-01=4)	34
4-8 Loss-in Weight (built in program) (SQ-01=5)	35
4-9 Hold mode (SQ-01 = 6).....	36
4-9-1 Hold mode flow chart.....	37
4-9-2 Hi, OK, Lo comparison	38
4-10 Totalizing (ACCU.) Auto / Transmit	38
Chapter 5 Interface	39



5-1 Serial Input / Output Interface (default OP-01)	39
5-2 BCD parallel output interface (OP-02) 	48
5-3 Analogue Current / Voltage Output Interface (OP-03).....	50
5-4 External Parallel Input / Output Interface	52
Chapter 6 Maintenance	57
6-1 Restore All Parameters to Their Default Factory Values.....	57
6-2 Maintenance Function Parameters	57
6-2-1 Restore the function parameter back to its default value.....	58
6-2-2 Clear zero compensation and TARE values	58
6-2-3 Clear batch setting	58
6-2-4 Display zero voltage (mV/V)	58
6-2-5 Clear batch setting	58
6-3 Test mode	59
6-3-1 7-Segment display testing	60
6-3-2 Keypad and calibration SW testing.....	60
6-3-3 Display A/D internal value display	60
6-3-4 RS-232 serial loop back testing.....	60
6-3-5 EEPROM memory testing	60
6-3-6 Option interface card testing.....	60
Appendix 1 Description of 7-Segment Characters	62
Appendix 2 Function Table.....	63
Appendix 3 MODBUS Data Address Table I	72
Appendix 4 MODBUS Data Address Table II	73
Appendix 5 Examples for Input and Output of Modbus	74


Check Firmware Version

During power-on countdown, press key to display firmware version 040112XX, where XX is maintenance number.



Safety

- When the instrument is installed, connect an earth bonding conductor from FG to the earth connection marked “ ”. 
- Disconnect the mains power supply before opening the instrument housing.
- To install the optional interface cards, it is necessary to disconnect the mains power supply and fit a yellow/green earth bonding cable to the rear panel.
- Before turning the power on ensure the supply voltage is within the acceptable range, DC 12V ~ 24V.
- The operating ambient temperature range is 0 °C ~ 40 °C (32 °F ~ 104 °F).



Features

150S has a wide range of applications from batching to simple weighing.

Features:

- ◆ Stand alone batching mode or connect to PLC for external system control
- ◆ Built in batching / dosing functions
- ◆ Manual / automatic discharge operation
- ◆ Set cycle times in a batch
- ◆ Totalise weight and number of cycles
- ◆ Key in the signal voltage value (mV / V) directly via the keypad, no need to apply any weight to the bottom work to calibrate the weigher
- ◆ Display load cell output voltage (mV / V) for future maintenance
- ◆ Adjustable filter
- ◆ RS232C bi-directional and RS485 communication
- ◆ Built in MODBUS


Interface options:

- ◆ OP-01 RS-422 / RS-485 / RS-232 serial interface
- ◆ OP-02-1 BCD parallel output interface (Open collector output)
- ◆ OP-02-2 BCD parallel output interface (TTL output)
- ◆ OP-03 16 Bit Analogue current/voltage output interface
(4 ~ 20 mA / 0 ~ 10 V)
- ◆ OP-04 Control I/O (4 In / 4 Out) + Setpoint In (BCD code)
- ◆ OP-05 Control I/O (8 In / 8 Out)



Chapter 1 Front and Rear Panel Specifications

1-1 Front panel



Display

- 6 digits, bright red, 7 segment LED display, character height 16mm (0.63").
- Display can be switched between Gross Weight / Net Weight / Totalised Weight / Number of transactions in the total.

Indication icons “◀”


ZERO	◀ : Zero Indication
MD	◀ : Unstable weight Indication
GROSS	◀ : Gross weight Indication
NET	◀ : Net weight Indication

- ◆ The indicator is supplied with suitable labels to customise the icon displays.
- ◆ Refer to FNC-06 ~ FNC-09 for the various options available.

Weighing Units

- Weighing Units kg / g / t / lb.

1-2 Rear panel



• 13 Way Terminal Block

1 st	FG
2 nd	DC+
3 rd	DC-
4 th	NC
5 th	TX
6 th	RX
7 th	SG
8 th	EXC+
9 th	SEN+
10 th	SEN-
11 th	EXC-
12 th	SIG +
13 th	SIG -

- Calibration Switch set to the left is “OFF” and to the right is “ON”



1-3 Keypad Description



- When entering data or reference setting, it means "ESC".
In the normal operation, it puts the indicator in standby mode or escape.
- **Entering standby mode:** All of the display (except ZERO "◀" symbol) and serial data output are disabled.
 - **Escape from standby mode:** Re-power on mains for normal operation.



- When parameter setting, it moves the flashing digit left.
- In the normal mode, it performs a Zero operation.



- When parameter setting, it moves the flashing digit right.
- In the normal mode, it performs a semi-auto Tare operation.



- When parameter setting, it increments the flashing digit or steps up the select item.
- In the normal mode, it accesses the FNC-05 setting.
During power-on countdown, press this key to display firmware version.



- When parameter setting, it decrements the flashing digit or steps down the select item.
- In the normal mode, it accesses the FNC-04 setting.



- Confirm / enter key.

- Function FNC-03 can be used to selectively disable individual keys.
- Zero operation, will be limited by functions CSP-05 and CSP-10.
- Zero operation, will be limited by functions CSP-10 and CSP-11.

1-4 Specification

A/D Conversion

* Input Sensitivity	: Over 0.12µV/d
* Internal Resolution	: 1 / 1 000 000
* Max. Sampling Speed	: 120 times/s.
* Application Range	: - 0.1 ~ 4.0 mV / V
* Load Cell Excitation Voltage	: 5 V DC ±5%, 120 mA (Up to eight (8) 350 Ω load cells can be connected)





Power supply

- ◆ DC 12V ~ 24V
- ◆ Power consumption is about 10 VA



Dimensions

Panel cutout



1-5 Display Firmware Version

During power-on countdown, press

F1
^

to display firmware version.



Chapter 2 General Function Guide

2-1 Function Setup and Operation Procedures

Function	Operation	Display	Description
Enter calibration mode	Turn the calibration switch to "ON"	88 888	See 3-2 for details
Enter function setting	Press and not release, then press key after the power is turned on	88 888	See 2-2 for details
Reset all parameters back to default	Turn the power on then turn the calibration switch to "ON" then press and hold the and keys during the self-testing sequence	8.888	See 6-1 for details
Reset general function parameters back to default	Turn the power on and press and keys during self-testing sequence	8 888	See 6-2-1 for details
Clear zero point compensation and tare value	Turn the power on and press and keys during self-testing sequence, and then press	2 8888	See 6-2-2 for details
Clear setpoint parameter setting	Turn the power on and press and keys during self-testing sequence, and then press two times	3 888	See 6-2-3 for details
Value of zero point voltage(mV / V)	Turn the power on and Press and , then press key three times	8 8888	See 6-2-4 for details
Value of Span voltage (mV / V)	Turn the power on and Press and , then Press	9 8888	See 6-2-5 for details
Entering to test mode	Turn the power on and press and keys during self-testing sequence	8. 888	See 6-3 for details



Function	Operation	Display	Description
Check weighing setpoint parameter setting	Press the key to set the parameter of FUNC.4 to 1 in the normal mode	 or 	See 4-2 for details

Key actions in function set up mode

- ⇒ Increases the number of the flashing digit
- ⇒ Decreases the number of the flashing digit
- ⇒ Moves the flashing digit one space to the left
- ⇒ Moves the flashing digit one space to the right
- ⇒ Saves the configuration
- ⇒ Quits set up mode / Escape


2-2 Error Messages (Display in General Function setting)

- ⇒ Load Cell output voltage < - 0.1mV / V or > 4mV / V
- ⇒ Weight value ≤ previous weight value
- ⇒ Actual measured weight value ≤ previous weight value
- ⇒ Setting value 0
- ⇒ mV / V value entered > measuring range
- ⇒ mV / V value entered is too small (SPAN – Zero < 0 mV / V)
- ⇒ Displayed resolution is less than 0.12 µV / division




Function Setting Procedures

With weight displayed press and hold the key. Then, press key





2-3 Function Setting 88888



*Function Parameter code

8888800	⇒ Digital Filter I
8888801	⇒ Digital Filter II
8888802	⇒ Lock keypad function
8888803	⇒ "F" function setting
8888804	⇒ "F1" function setting
8888805	⇒ Front panel indication "◀" setting (first)
8888806	⇒ Front panel indication "◀" setting (second)
8888807	⇒ Front panel indication "◀" setting (third)
8888808	⇒ Front panel indication "◀" setting (fourth)
8888809	⇒ Terms of back to zero
8888810	⇒ Hold
8888811	⇒ Rate for display rewrite
8888812	⇒ Turn-on zero setting
8888813	⇒ Stand-by mode setting
8888814	⇒ Zero function record setting
8888815	⇒ Internal calibration password setting
8888816	⇒ Turn on/off watchdog

To continue the next function setting

or press key to escape

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



▣ FNC Group function setting

Item	Function	Setting value			Default	
		Parameter	Description			
FNC-01	Digital Filter I	0	5 Hz		4	
		1	4.17 Hz			
		2	2.5 Hz			
		3	2.08 Hz			
		4	1.25 Hz			
		5	1.04 Hz			
		6	0.63 Hz			
		7	0.52 Hz			
		8	0.31 Hz			
		9	0.26 Hz			
FNC-02	Digital Filter II	0	Disabled		2	
		1	Less filter	Greater		
		2				
		3				
		4				
		5				
FNC-03	Key – Locked	000000 ↓ 111111	0 1	Normal (lock disable) Close (lock enable)	The bits and front panel key positions are related to each other	
FNC-04	“F” function setting	Parameter ⇒ Description 0 ⇒ Display Net / Gross weight 1 ⇒ Setpoint parameter setting 2 ⇒ Tare reset 3 ⇒ Manual serial, parallel print output 4 ⇒ Start load 5 ⇒ Stop load 6 ⇒ Start comparison 7 ⇒ Unload command 8 ⇒ Totalise weight and counts command 9 ⇒ Clear totalised weight and counts 10 ⇒ Hold mode 11 ⇒ Escape Hold mode(I / O DSP) 12 ⇒ Convert to Gross / Net / totalised weight / totalised Count				
FNC-05	“F1” function setting					



EXCELL®

EXCELL PRECISION CO., LTD

Item	Function	Setting value		Default
		Parameter	Description	
FNC-06	Front panel indication “◀” setting (top)	Parameter ⇒ Description 0 ⇒ Zero 1 ⇒ MD 2 ⇒ Gross 3 ⇒ Net 4 ⇒ Totalised weight (Accu. V) 5 ⇒ Totalised transactions (Accu. C) 6 ⇒ SP1 7 ⇒ SP2 8 ⇒ SP3 9 ⇒ Hi 10 ⇒ OK 11 ⇒ Lo 12 ⇒ Under 13 ⇒ Over 14 ⇒ Discharge 15 ⇒ Running 16 ⇒ Hold		0
FNC-07	Front panel indication “◀” setting (next to top)			1
FNC-08	Front panel indication “◀” setting (next to bottom)			2
FNC-09	Front panel indication “◀” setting (bottom)			3
FNC-10	Return to zero band (d: refer to CSP-03)	0	5 d	0
		1	10 d	
		2	20 d	
		3	40 d	
		4	60 d	
		5	80 d	
		6	100 d	
		7	150 d	
		8	200 d	
		9	250 d	
FNC-11	Hold	0	Hold	0
		1	Peak hold (positive 1)	
		2	Peak hold (negative)	
		3	Peak hold (absolute value)	
		4	Peak hold (positive 2)	
FNC-12	Rate for display rewrite	0	No limitation	0
		1	20 times/s	
		2	10 times/s	
		3	5 times/s	
		4	1 time/s	



Item	Function	Setting value		Default
		Parameter	Description	
FNC-13	Turn-on zero setting	0	Disable	0
		1	Enable	
FNC-14	Stand-by mode setting	0	Disable all the functions under stand-by mode	0
		1	Only turn off display but not disable other functions under stand-by mode	
FNC-15	Zero function record setting	0	Zero point record not saved into EEPROM	0
		1	Zero point record saved into EEPROM	
FNC-16	Internal calibration password setting	0000	No password	0000
		0001	Password is set	
FNC-17	Turn on/off watchdog	1	Turn on watchdog	1
		0	Turn off watchdog	


2-4 Set internal calibration password (FNC-16)

The default value of FNC-16 is 0000, which means internal calibration without password. To set a password, enter 4-digit numbers (other than 0001, 0000) and press confirm key to complete. If password is set to 0001, error message “UN.VALI” will appear.


If password has been set, FNC-16 will display 0001. To change password, it must enter the previously set password first. If entered password is wrong, it displays “PW ERR”. If entered password is correct, it displays “NEW PW” and then enters 4-digit numbers (other than 0001) for new password or enters 0000 to remove password. If password is forgotten, it must reset to factory setting.

Chapter 3 Calibration


3-1 Load Cell Connection



3-2 Parameter Setting and Calibration Flow Chart



Calibration process




- Before the Linearity Calibration, the General Calibration should be completed.



3-3 MODBUS Calibration

- ☒ RS1-02 set as “4” (MODBUS RTU mode)
- RS1-07 set as “01” (scale’s address)
- a. CAL Switch set to ON and set 00 CCP = CCP, or



- b. CAL Switch set to OFF

Eg:

Zero calibration

Input 01050423FF007CC0 ← zero calibration

Reading calibration status

1. Command: Input 010100410005AC1D

First 01 is scale’s address. Second 01 is command. 00 41 (decimal number 65) is MODBUS address. 00 05 means continuously inquire 5 addresses, i.e. 65, 66, 67, 68, 69.

2. Scale’s reply: 01010105919B

First 01 is scale’s address. Second 01 is command. Third 01 means reply with 1 byte, i.e. the subsequent 05 is binary 0000 0101 – if first bit is 1, that means Address 65 (decimal) is set to 1 → performing zero calibration, and so on. If second bit is zero, then span calibration has no action. Please refer to “Appendix 3: MODBUS Data Address Table”. After zero calibration has finished without Err message, zero calibration is completed.

Span calibration

Input weight calibration value 3000

Input 0110044C0001020BB8EADE ← Input weight calibration value 3000

Put 3kg on the platter

Span calibration

Input 01050424FF00CD01 ← Span calibration

Reading calibration status

1. Command: Input 0101004200015DDE


2. Scale’s reply: 010101019048

First 01 is scale’s address. Second 01 is command. Third 01 is scale’s reply byte count. Fourth 01 is binary 0000 0001, which means address – if first bit



is 1, that means Address 66 (decimal) is set to 1, i.e performing span calibration. Please refer to “Appendix 3: MODBUS Data Address Table”. After zero calibration has finished without Err message, zero calibration is completed. 9048 is CRC error detecting code.

3-4 Specification calibration 0 8 8 8 8



*Calibration parameter code

888888 ⇒Unit

888888 ⇒Decimal Point

888888 ⇒Min. Division

888888 ⇒Max. Capacity

888888 ⇒Zero Range

888888 ⇒Time of Zero tracking

888888 ⇒Range of Zero tracking

888888 ⇒Investigate period of unstable

888888 ⇒Investigate range of unstable

888888 ⇒Function Zero and Tare when the weight is unstable

888888 ⇒Tare function availability when gross weight is negative

To continue the next function setting

or press **I/O ESC** key to escape

F1	⇒ Increment flashing digit
F	⇒ Decrement flashing digit
ZERO	⇒ Move flashing point left
TARE	⇒ Move flashing point right
ENTER	⇒ Store data in memory
I/O ESC	⇒ Exit / Escape



Item	Function	Setting value		Default
		Parameter	Description	
CSP-01	Unit	0	None	2
		1	g	
		2	Kg	
		3	t	
		4	lb	
CSP-02	Decimal Point	0	None	0
		1	1 Decimal Point	
		2	2 Decimal Point	
		3	3 Decimal Point	
CSP-03	Division	1	Division size	1
		2		
		5		
		10		
		20		
		50		
CSP-04	Max. Capacity	999999 ↓ 000000	Max. capacity	999999
CSP-05	Zero range	0 =full range (±1%~30%)	Zero range = calibration zero point ± (Max. capacity×setting value %)	0
CSP-06	Time of zero tracking	0.0 ~ 5.0 (sec)	Time and range of zero tracking should be use at the same time. If the time is set to 0.0, the zero tracking function is disabled	1.0
CSP-07	Range of zero tracking	0 ~ 9	Range of zero tracking = (setting value×½)D , D=min. division Range and time of zero tracking should be use at the same time. If the range is set to 0, the zero tracking function is disabled	2
CSP-08	Investigate time in stable	0.0 ~ 5.0 (sec)	Investigate time and range should be use at the same time. If the time is set to 0.0, the investigate time is disabled	1.0
CSP-09	Investigate range in stable	0 ~ 9	Investigate time and range should be use at the same time. If the range is set to 0, the investigate range is disabled	2
CSP-10	Weight unstable, function ZERO and TARE	0	Action	0
		1	None	
CSP-11	Gross Weight is negative, function TARE	0	Action	0
		1	None	



3-5 General Calibration

Set CAL switch to ON

88 888

Select General Calibration

88 888

Press Key

8888 kg

Zero Calibration
No weight on the platform
or in the hopper

Press the key

... kg

Five sec. later

8888

Two sec. later

30000 kg

Weight Calibration

Use the front panel to key in the weight value

Place the weight on the platform or inside the hopper

After the weight is stable

... kg

Press the key

... kg

Calibration complete set calibration switch to the OFF position

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Zero calibration only, press key to escape after the display shows 8888.

Span calibration only, press key entering directly to span calibration after the display shows 8888.

Please refer to error message during calibration of the display show 888.X.



3-6 Linearity calibration 88888

Before the Linearity calibration, the General calibration should be completed.

Set CAL switch to ON

88 888

Select linearity calibration

88 888

Press the key

88 88

Use to select one of calibration points (1P~5P)

88 : no setting value
888 : with setting value

Select one of five calibration, and
Press the key

888888

Press the key

Press the key

888889

Press the key

Key in the correct weight value

888888

Press the key

.....

When stable, the display area shows
the modified weight value

888888

Press the key

88 888

Finish the 1st calibration point
setting. Either continues the
second point calibration or
press key to exit the
linearity calibration process

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left.
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Please refer to the error message list if the display

shows 888.X .



Display the setting value of linearity calibration

Set CAL switch to ON

88 888

Select linearity calibration

88 888

Press the key

88 888

Press the key

888888

Press the key

88 989

Use to select one of calibration points (1P~5P)

88 : no setting value
888 : with setting value

Display the setting value of this calibration point

Either continue to display the second point value or press key to exit the linearity calibration mode

Clear the setting value of linearity calibration

Set CAL switch to ON

88 888

Select linearity calibration

88 888

Press the key

88 888

Press the key

888888

Press the key

88 88

Use keys to select one of calibration. (1P~5P)

88 → No setting value
888 → With setting value

The screen shows the setting

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Either continue to clear the second point value or press key to exit the linearity calibration mode



Please refer to the error message list if the display shows 888.X.



3-7 Digital calibration 88 888

Set CAL switch to ON

88 888

Select Digital calibration

88 888

Press the Key

88888

Two sec. later

8.88888

Method 1
Input zero voltage

Method 2
With no weight on the platform or in the hopper
press the key to set zero.

8.88888

Press the key

888

Two sec. later

8.88888

Input the span voltage

8.88888

Press the key

888.

Two sec. later

8.88888

Enter the weighing capacity

8.88888

Press the key


88 888

Display shows nothing
after calibration

Calibration completed set calibration switch to the OFF position

Please refer to the error message list if the display shows 888.X.

Example:



Zero Voltage $\Rightarrow 0.00036 \text{ mV/V}$ (incl. dead load)

Span Voltage $\Rightarrow 2.90000 \text{ mV/V}$

Capacity $\Rightarrow 30\,000 \text{ divisions}$

Zero voltage calibration.
Two sec. later

Method 1
Input zero voltage

Method 2
With no weight on the platform or in the hopper
press the key to set zero.

Press the key

Span voltage calibration.
Two sec. later

Input the span voltage

Press the key

Enter the weighing capacity

Press the key


Display shows nothing
after calibration

	\Rightarrow Increment flashing digit
	\Rightarrow Decrement flashing digit
	\Rightarrow Move flashing point left
	\Rightarrow Move flashing point right
	\Rightarrow Store data in memory
	\Rightarrow Exit / Escape



Chapter 4 Weight Comparison Procedures



4-1 Function Configuration Menu



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



Functional Parameter Instruction

Item	Function	Setting value		Default
		Parameter	Description	
SQ- 01	Batching mode	1	Normal batch	9
		2	Loss-in weight	
		3	Comparison mode	
		4	Normal batch (Built-in program)	
		5	Loss-in weight (Built-in program)	
		6	Hold mode (Built-in program)	
		9	Close flow control	
SQ- 02	Batching start delay time	0.0 ~ 25.5 (sec)	The built-in auto-program starts the batch comparison procedure after the input of the batch start signal	0.0
SQ- 03	SP1,SP2 Waiting time comparison	0.0 ~ 25.5 (sec)	No full flow comparison during this function's set time period. If the set value is 0, indicates this function is not in use	0.0
SQ- 04	Batch finish output signal delay time	0.0 ~ 25.5 (sec)	Output the batch finished signal after this delay time	0.5
SQ- 05	Batch finish Condition	0	Wait until the weight is stabilized	0
		1	No need to wait until the weight has stabilized	
SQ- 06	Batch finish Output signal time	0.0 ~ 25.5 (sec)	Batch finished output signal time. If set to 0, the output signal will be off until the next batch start	1.0
Batch finish signal		ON		
		OFF		
Batch finish				
SQ- 07	Number of Times the supplementary loading function operates	0 ~ 255	If the set value is 0, this function is not in use	0
SQ- 08	Supplementary loading gate open time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	0.1
SQ- 09	Supplementary loading gate close time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	1.0
Supplementary loading signal				
				
SQ- 07 Times of "ON" of the supplementary loading				



Item	Function	Setting value		Default
		Parameter	Description	
SQ- 10	Discharge start delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is ON	0.0
SQ- 11	Discharge stop delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is OFF	0.0
SQ- 12	Discharge time	0.0 ~ 25.5 (sec)	Won't activate internal discharge control function, if set to 0	0
<p>The diagram illustrates the logic for the Discharge output signal. It starts with a 'Discharge input signal' (a pulse that triggers SQ-10). SQ-10 generates a pulse that activates the 'Weight reach zero band'. This band is defined by two points: 'SQ- 10' (start) and 'SQ- 11' (end). The 'Discharge output signal' is active during the time interval between SQ-10 and SQ-11, provided the weight reaches the zero band.</p>				
SQ- 13	Restart delay time	0.0 ~ 25.5 (sec)	Delay time before Restart signal is ON	1.0
SQ- 14	Batching counts	0 ~ 255 (times)	Number of batch runs 0 ⇒ one batch only	0
SQ- 15	Set the zero band in to final weighing value	0	No setting	0
		1	Setting	
SQ- 16	Hi, OK, Lo	0	Comparison anytime	0
		1	To compare at batch finish	
		2	To compare at external input signal	
		3	To compare at batching finish and external input signal	
		4	Comparison auto	
SQ- 17	Auto totalise weight / counts	0	Disabled	0
		1	Enabled	
SQ- 18	The parameter source in weight comparison	0	Key in directly from front keypad	0
		1	Input directly from rear interface	
SQ- 19	Weight comparison delay time	0.0 ~ 25.5 (sec)	Comparison delay time for Hi, OK, Lo	0.5
SQ- 20	TARE auto.	0	Press keypad TARE to TARE	0
		1	TARE auto	
SQ- 21	Discharge auto	0	Input from external input or keypad	0
		1	Discharge auto + manual	

4-2 Check Weighing Configuration

1. FNC-04 = 1, SQ-01 = 1, 2, 4 or 5

Press the key



Display shows the existing

Final value setting, Input new

value as required.

Press the key



Display shows the existing

SP1 value setting, Input new

value as required.

Press the key



Display shows the existing

SP2 value setting, Input new

value as required.

Press the key



Display shows the existing

Free Fall value setting, Input new

value as required.

Press the key



Display shows the existing

Over value setting, Input new

value as required.

Press the key



Display shows the existing Under

value setting. Input new value as required.

Press the key



Display shows the existing Zero Band


setting. Input new value as required.

Press the key

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



2. FNC-04 = 1, SQ-01 = 3



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



3. FNC-04 = 1, SQ-01 = 6

Press the key

→

Display shows the existing Hi value setting,
Input new value as required.

Press the key

Display shows the existing Lo value setting,
Input new value as required.

Press the key

Display shows the existing Zero Band
setting, Input new value as required.

Press the key

Display show the existing Peak Ready
value setting. Input new value as required.

Press the key

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape



4-3 Batching Signal Outputs

▫ Normal batching signal outputs

Signal	Output condition
SP1	Net \geq Final(value) - SP1(value)
SP2	Net \geq Final(value) - SP2(value)
SP3	Net \geq Final(value) – Free Fall (in-flight) (value)
Under	Net $<$ Final(value) – Under(value)
Over	Net \geq Final(value) + Over(value)
Zero Band	Gross \leq Zero Band(value)

▫ Loss-in-weight signal outputs


Signal	Output condition
SP1	Gross \geq SP1(value)
SP2	- Net \geq Final(value) – SP2(value)
SP3	- Net \geq Final(value) – Free Fall (in-flight) (value)
Under	- Net $<$ Final(value) – Under(value)
Over	- Net \geq Final(value) + Over(value)
Zero Band	Gross \leq Zero Band(value)

▫ Hi, OK, Lo signal outputs


Setting		Signal	Output condition
SQ01	SQ16		
1,2,4,5	1,3	Under	Net $<$ Final(value) – Under(value)
3	0,2,4		Net $<$ Lo(value)
1,2,4,5	1,3	Over	Net \geq Final(value) + Over(value)
3	0,2,4		Net \geq HI(value)
1,2,4,5	1,3	OK	Final(value) – Under(value) \leq Net $<$ Final(value) + Over(value)
3	0,2,4		Lo(value) \leq Net $<$ Hi(value)
1,2,4,5	1,3	LO	Net $<$ Final(value) – Under(value)
3	0,2,4		Net $<$ Lo(value)
1,2,4,5	1,3	HI	Net \geq Final(value) + Over(value)
3	0,2,4		Net \geq HI(value)



4-4 Normal batching flow chart (SQ-01=1)




4-5 Loss-in Weight flow chart (SQ1=2)






4-6 Hi, OK, Lo output flowchart



4-7 Normal batching (built-in program) flowchart (SQ-01=4)




- If to activate circulatory function, please wait till zero signal output.

Batch signal setting

- FNC04~05=4、5
- IN01~08=4、5
- If use "unloading continuously control" (SQ14), please keep batch start signal ON

4-8 Loss-in Weight (built in program) (SQ-01=5)




Batch signal setting

- FNC04~05=4、5
- IN01~08=4、5




4-9 Hold mode (SQ-01 = 6)


1. General hold mode (FNC-11 = 0)



2. Peak hold mode (FNC-11 = 1、2)



3. Peak hold mode (FNC-11 = 3、4)




Peak hold mode with four different states (FNC-11 = 1,2,3,4), positive peak weight(1), negative peak weight, absolute value of peak weight and positive peak weight(2) . The peak holds of absolute value and positive peak weight (2) both have no peak ready signal output.



4-9-1 Hold mode flow chart

(SQ-01=6,SQ-16=0 or 2 or 4)





4-9-2 Hi, OK, Lo comparison

1. Normal HOLD (FNC-11 = 0)

Entering the Hold mode, Hi, OK, Lo comparison output. Escape Hold mode will switch off the outputs.

2. Peak HOLD (FNC-11 = 1, 2)

If Peak Ready is ON, Hi, OK, Lo comparison output. Escape Hold mode will switch off the outputs.

3. The absolute value of peak HOLD (FNC-11 = 3)

Entering the Hold mode, Hi, OK, Lo comparison output.

4. FNC-11 = 4

When the external input single Judgement is ON, Hi, OK, Lo comparison output.

5. If to release HOLD (display value and Hi, OK, Lo signal), please make HOLD release signal on.

4-10 Totalizing (ACCU.) Auto / Transmit

With automatic totalising active (SQ-17) or RS232 / RS485 or BCD output set to auto transmit.

1. SQ-01 = 1, 2, 4 or 5 batch / loss-in weight

- a) When the weight reaches the Final weight and the batch finish signal is ON the net weight will be added to the totaliser and number of additions is incremented. The RS-232 / RS-485 and BCD outputs transmit data. (RS-01/ RS-02=10 accumulated weight and counts)
- b) When the net weight returns to the zero range (FNC-10), then the sequence in a) above can be repeated.
- c) When SQ-01=1 or 4, Net >Final and Batch finish=1, it accumulate once.
- d) When SQ-01=2 or 5, -Net >Final and Batch finish=1, it accumulate once.

2. SQ-01 = 3 Comparison mode

- a) When the net weight exceeds the zero range and the weight has stabilized it will be added to the totaliser and number of additions is incremented. The RS-232 – RS-485 and BCD outputs transmit data.

3. SQ-01=6 HOLD mode

- a).Lo. Wt. <weight<Hi. Wt. weight will be added to the totaliser and number of additions is incremented.RS-232 / RS-485 and BCD outputs transmit data. (RS-01/ RS-02=10 accumulated weight and counts)
- b). Until the net weight returns to the zero range (FNC-10), then the sequence in a) above can be repeated.




Chapter 5 Interface


5-1 Serial Input / Output Interface (default OP-01)

Pin location and setting

1. Built-in RS-232 or RS-485



PIN	Function
5	TXD / DA-
6	RXD / DA+
7	SG



Jumper configuration

When the distance is long, add terminal resistance at the end of the transmission line (first unit and last unit) to reduce signal distortion

First serial port interface 88 898 setting procedure

88 898

Press key

888888

Input desired parameter code

888888

Press key

888888

Display show the existing parameter code. Input a new code as required

888888

Press key

Continue to the next function setting or

press key to escape

	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape




Item	Function	Setting value		Default
		Parameter	Description	
RS1- 01	Transmit format	0	As display	0
		1	Gross only	
		2	Net only	
		3	As display (simple)	
		4	Gross (simple)	
		5	Net (simple)	
		6	Comparison + As display (simple)	
		7	Comparison +Gross (simple)	
		8	Comparison +Net (simple)	
		9	Tare	
RS1- 02	Transmit mode	10	Totalised (Accu.) Weight and number of transactions	
		0	Transmit continuous + command mode	4
		1	Auto transmit + command mode	
		2	Manual transmit + command mode	
RS1- 03	Transmit speed	3	Command mode	
		0	600	4
		1	1200	
		2	2400	
		3	4800	
		4	9600	
		5	19200	
		6	38400	
		7	57600	
RS1- 04	Parity Bit length Stop Bit	8	115200	2
	0	N, 8, 1		
	1	O, 7, 1		
	2	E, 7, 1		
	MODBUS Mode: Parity Bit length Stop Bit	0	N, 8, 2	2
		1	O, 7, 1	
		2	E, 7, 1	
RS1- 05	Transmit times	0	Open	0
		1	1 time/sec.	
		2	2 time/sec.	
		3	5 time/sec.	
		4	10 time/sec.	
RS1- 06	Transmission conditions	0 0 0 0 0 0	0 ⇒ transmit cont. 1 ⇒ Stop transmit Negative (Net Wt.) Weight unstable Overload (OL)	000000



RS1- 07	Indicator poling address	00 ↓ 99	When set to 0, Indicator addressing is not used	1
---------	--------------------------	---------------	---	---


2. OP-01 RS-422 / RS-485 / RS-232



PIN	Function	
	RS422/RS485	RS232
1	SDA	TXD
2	SDB	
3	RDA	RXD
4	RDB	
5	TRM	
6	SG	SG

☒ Jumper configuration

Second serial port interface 88888 setting procedure







	Function	Setting value		Default
		Parameter	Description	
RS2- 01	Transmit format	0	As display	0
		1	Gross only	
		2	Net only	
		3	As display (simple)	
		4	Gross (simple)	
		5	Net (simple)	
		6	Comparison + As display (simple)	
		7	Comparison +Gross (simple)	
		8	Comparison +Net (simple)	
		9	Tare	
RS2- 02	Transmit mode	10	Totalised (Accu.) Weight and number of transactions	
		0	Transmit continuous + command mode	3
		1	Auto transmit + command mode	
		2	Manual transmit + command mode	
RS2- 03	Transmit speed	3	Command mode	
		0	600	2
		1	1200	
		2	2400	
		3	4800	
		4	9600	
RS2- 04	MODBUS Mode: Parity Bit length Stop Bit	5	19200	2
		0	N, 8, 1	
		1	O, 7, 1	
		2	E, 7, 1	
		0	No parity, 8 data bits, 1 Stop bit	
		1	Odd parity, 7 data bits, 1 Stop bit	
RS2- 05	Transmit times	2	Even parity, 7 data bits, 1 Stop bit	2
		0	N, 8, 2	
		1	Odd parity, 7 data bits, 1 Stop bit	
		2	Even parity, 7 data bits, 1 Stop bit	
		0	No parity, 8 data bits, 1 Stop bit	
RS2- 06	Transmission conditions	1	1 time/sec.	0
		2	2 time/sec.	
		3	5 time/sec.	
		4	10 time/sec.	
		0 0 0 0 0 0	0 ⇒ transmit cont.	
			Negative (Net Wt.) Weight unstable Overload (OL)	
RS2- 07	Indicator poling address	00 ↓ 99	When set to 0, Indicator addressing is not used	0



RS-422



RS-485



Notice:

- The maximum connection is 10 sets of indicator.
- When the Host computer has the built-in terminal resist, it is not necessary to have the external one.
- On the last set of indicator, the TRM & RDB can be connected depends on the situation.
- When the host computer has no single (SG), it is acceptable to disconnect that part.



☒ Data format

1. General Format

NET	S	T	,	G	S	,	+	0	1	2	3	4	5	6	k	g	CR LF
GROSS	S	T	,	N	T	,	+	1	2	3	4	.	5	6		g	
TARE	S	T	,	T	R	,	+	0	1	2	3	4	5	6		t	
+ OL	O	L	,	G	S	,	+	SP									
- OL	O	L	,	G	S	,	-	SP									
UNSTABLE	U	S	,	G	S	,	+	1	2	3	4	.	5	6	k	g	


2. Totalised (Accu.) Format (RS1-01 / RS2-01=10)

Accu. Weight	T	W	,	+	1	2	3	4	5	6	.	7	8	9	k	g	CR LF
Accu. Wt. Over+	T	W	,	+	SP												
Accu. Wt. Over -	T	W	,	-	SP												
Accu. Count	T	N	,	+	0	1	2	3	4	5	6	7	8	9			
Accu. Count over	T	N	,	+	SP												

3. Sample Format

Gross/Net or as display	+	1	2	3	4	5	6			CR LF
Over load positive	+	SP	SP	SP	SP	SP	SP			
Over load negative	-	SP	SP	SP	SP	SP	SP			

4. Setpoint (1) + Simple Format (Gross/Net or as display)



- bit 0 : Zero Band
- bit 1 : Over
- bit 2 : Under / Hi
- bit 3 : SP1 / OK
- bit 4 : SP2 / Lo
- bit 5 : SP3
- bit 6 : Discharge
- bit 7 : Batch finished



5. Comparison condition (2)

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
--------	--------	--------	--------	--------	--------	--------	--------

Byte 0 : Zero Band

Byte 1 : Over

ON : 0 (ASC II Code 30 H)

Byte 2 : Under / Hi

OFF : 1 (ASC II Code 31 H)

Byte 3 : SP1 / OK

Byte 4 : SP2 / Lo

Byte 5 : SP3

Byte 6 : Discharge

Byte 7 : Batch finished

Description

	Output	ASCII	Description
Status 1	OL	4FH, 4CH	Over load
	ST	53H, 54H	Weight stable
	US	55H, 53H	Weight unstable
Status 2	GS	47H, 53H	Gross Weight
	NT	45H, 54H	Net Weight
	TR	54H, 52H	TARE
	TW	54H, 57H	Totalised Weight
	TN	54H, 4EH	Number of transactions in total
Data of Weight	0 ~ 9	30H ~ 39H	Figure of weight
	+, -	2BH, 2DH	Symbol (+ or -) of weight
	Space	20H	Over load
	.	2EH	Decimal
Units	Space, Space	20H, 20H	None
	kg	6BH, 67H	kg
	Space t	20H, 74H	tonne
	lb	6CH, 62H	lb
Ending code	CR, LF	0DH, 0AH	Ending code
Separating code	,	2CH	Comma



☒ Command mode

1. Command Format A

Host	Command	<CR><LF>		
Slave			Command	<CR><LF>

MZ	Zero	CZ	Zero compensation On/OFF
MT	Tare	CT	Clear TARE value
MG	Gross Weight	MN	Net weight
AT	Accu. Current net weight and times plus 1		
ST	Deduct times of last accu. Value minus 1		
DT	Clear accu. Value and times		
BB	Start batching (one time)	HB	Load stop
BC	Start batching (continuous)		
BD	Start unload		
SC	Transmit continuous	SA	Auto transmit
SM	Manual transmit	SO	Command mode
%	Stop continuous transmission and enter the command mode		

Note : Since BC continuous weighing is completed, it must zero re-set the continuous weighing frequency by BB command.

2. Command Format B

Host	Command	<CR><LF>		
Slave			Data	<CR><LF>

RW	Read current weight	RT	Read TARE
RG	Read Gross Weight	RN	Read Net weight
RB	Read current display of wt (simple)	RH	Read Gross (simple)
RI	Read Net (simple)		
RJ	Read comparison situation + current display of weight (simple)		
RK	Read comparison situation + Gross (simple)		
RL	Read comparison situation + Net (simple)		
RO	Read comparison situation (2)		
RF	Read prior completed weight	RA	Read accu. Value (incl. times)

Note : Prior command plus %

Read Weight Compared value: RS□□

FW	Read target item of unload value	S1	Read SP1
S2	Read SP2	S3	Read SP3
UD	Read Under	LO	Read LO
ZB	Read Zero Band	HI	Read HI
PR	Reading Peak value	OV	Read Over

Ex:

Command : RSFW <CR> <LF>

Indicator reply : RSFW□□□□□□

Finish 6 bytes



3. COMMAND FORMAT C

Host	Command + Data	<CR><LF>		
Slave			Command + Data	<CR><LF>

Write weight compared value WS□□XXXXXX
XXXXXX : value (6 bytes) □□ : setting items

FW	Write target item of unload value	S1	Write SP1
S2	Write SP2	S3	Write SP3
UD	Write Under	LO	Write LO
ZB	Write Zero Band	HI	Write HI
PR	Write Peak value	OV	Write Over
BC	Write SQ14	PT	Set OUT

Note : WSPTxxxxx (input 0~255 decimal system) converts to BIT value which indicates OUT (1-8) is ON, and the rest of numbers are OFF.

Ex:

Inputting WSPT000010 means the BIT value is 00001010 (OUT 2, 4 = ON) (OUT 1, 3, 5, 6, 7, 8 are OFF).

☒ Error messages

- E1: Format command fault
- E2: Setting parameters over range
- E3: Command not recognised

☒ Indicator poling address

If address of RS1(2) – 07 is set to 0, after receiving the command, it executes the command directly.

If address of RS1(2) – 07 is set to 1 ~ 99, after receiving the command, it compares the address before the command. If it is correct, it then executes the command.

For example: The indicator poling address is set to 02; it would send the weight value only if it received the command:


@02RW <CR> <LF>



5-2 BCD parallel output interface (OP-02) 0 5 8 8 8


PIN Location

D-Sub 37PIN




PIN	Function	PIN	Function
1	SG	20	SG
2	1×10^0	21	2×10^0
3	4×10^0	22	8×10^0
4	1×10^1	23	2×10^1
5	4×10^1	24	8×10^1
6	1×10^2	25	2×10^2
7	4×10^2	26	8×10^2
8	1×10^3	27	2×10^3
9	4×10^3	28	8×10^3
10	1×10^4	29	2×10^4
11	4×10^4	30	8×10^4
12	1×10^5	31	2×10^5
13	4×10^5	32	8×10^5
14	Gross / - Net	33	Stable / - MD
15	Plus / - Minus	34	DP1
16	DP2	35	DP3
17	DP4	36	Over / - Normal
18	Data ready	37	Hold input
19			


Equivalent Circuit



Open Collector Output (OP-02-1)




TTL Output (OP-02-2)



Hold Input



Function setting




F1 ^	⇒ Increment flashing digit
F v	⇒ Decrement flashing digit
<	⇒ Move flashing point left
>	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value		Default
		Parameter	Description	
bCd- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
bCd- 02	Transmit mode	0	Transmit continuous	0
		1	Auto transmit	
		2	Manual transmit	
bCd- 03	Output Logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 04	Data ready Signal logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 05	OL output code	0	FFFFFF	0
		1	999999	
bCd- 06	Data code	0	BCD Code	0
		1	Hex. Code	



5-3 Analogue Current / Voltage Output Interface (OP-03)

☒ Location



A. Terminal (4 way)

- 1 : 4 ~ 20mA current output, A(+)
- 2 : 0 ~ 10V voltage output, V(+)
- 3 : Current / voltage signal, Com. (-)
- 4 : Ground / 0V, FG

B. SPAN adjustment

Current / voltage Span adjustment to increase value turn clockwise, decrease value turn anticlockwise.

C. ZERO adjustment

Current / voltage Zero adjustment to increase value turn clockwise, decrease value turn anticlockwise.

☒ Analogue output interface specification


Resolution : 16 bits

Current output : 4 ~ 20mA (0 ~ 550 Ω load)

Voltage output : 0 ~ 10V



Function setting



	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value		Default
		Parameter	Description	
AnL- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
AnL- 02	Signal output	0	Current output	0
		1	Voltage output	
AnL- 03	Weight in Lo	000000 ~ 999999	When the weight reaches the value of that in AnL-03(the Max. weight is the max setting value (refer to CSP-04), the current / voltage(refer to AnL-02) output is changed to that configured in AnL-04	0
AnL- 04	Current / Voltage in Lo	4.0 mA ~ 20.0 mA or 0.0 V ~ 10.0 V		
AnL- 05	Weight in Hi	000000 ~ 999999	When the weight reaches the value of that in AnL-05(the Max. weight is the max setting value (refer to CSP-04), the current / voltage(refer to AnL-02) output is changed to that configured in AnL-06	30000
AnL- 06	Current / Voltage in Hi	4.0 mA ~ 20.0 mA or 0.0 V ~ 10.0 V		




☒ Analogue output notes

1. The current output, load resistor should not exceed 550 Ω. It is recommended that a resistor with a low temperature coefficient and a power rating above 0.2 W be used.
2. Avoid short circuits between the positive and negative analogue output terminals as the interface this may cause damage.
3. It is recommended that a screened cable is used to connect the analogue output to its load and that the screen is earthed to avoid noise interference.

5-4 External Parallel Input / Output Interface

☒ PIN location

D-Sub 37PIN



☒ OP-04 Control I/O (4 in / 4 out) + Setpoint Input (BCD code)


PIN	I/O	Signal	PIN	I/O	Signal
1	IN	Code 100	20	IN	Code 101
2	IN	Code 102	21	IN	Code 103
3	IN	Code 104	22	IN	Code 105
4	IN	Code 106	23	IN	Code 107
5	IN	Code 108	24	IN	Code 109
6	IN	Code 1010	25	IN	Code 1011
7			26		
8			27	OUT	OUT 1
9	OUT	OUT 2	28	OUT	OUT 3
10	OUT	OUT 4	29	IN	Vex
11		COM 2	30		COM 2
12			31		
13		COM 1	32		COM1
14	IN	IN 1	33	IN	IN 2
15	IN	IN 3	34	IN	IN 4
16			35		
17			36	IN	Code 1
18	IN	Code 2	37	IN	Code 4
19	IN	Code 8			

☒ OP-05 Control I/O (8 in / 8 out)

PIN	I/O	Signal	PIN	I/O	Signal
1	IN	IN 1	20		COM 1
2	IN	IN 2	21		COM 1
3	IN	IN 3	22		COM 1
4	IN	IN 4	23		COM 1
5	IN	IN 5	24		COM 1
6	IN	IN 6	25		COM 1
7	IN	IN 7	26		COM 1
8	IN	IN 8	27		COM 1
9		COM 1	28		COM 1
10		COM 2	29		COM 2
11	OUT	OUT 1	30		COM 2
12	OUT	OUT 2	31		COM 2
13	OUT	OUT 3	32		COM 2
14	OUT	OUT 4	33		COM 2
15	OUT	OUT 5	34		COM 2
16	OUT	OUT 6	35		COM 2
17	OUT	OUT 7	36		COM 2
18	OUT	OUT 8	37		COM 2
19	IN	Vex			



Input signal configuration




	⇒ Increment flashing digit
	⇒ Decrement flashing digit
	⇒ Move flashing point left
	⇒ Move flashing point right
	⇒ Store data in memory
	⇒ Exit / Escape

Item	Function	Setting value		Default
		Parameter	⇒ Description	
IN - 01	Input 1	0	⇒ None	1
		1	⇒ Zero	
IN - 02	Input 2	2	⇒ Tare	2
		3	⇒ Tare reset	
IN - 03	Input 3	4	⇒ Start batching	3
		5	⇒ Stop batching	
IN - 04	Input 4	6	⇒ Discharge Command	4
		7	⇒ Hold	
IN - 05	Input 5	8	⇒ Hold display & I/O reset	5
		9	⇒ Totalise (Accu) Command	
IN - 06	Input 6	10	⇒ Clear totaliser (Accu)	6
		11	⇒ Clear previous total (Accu) Value	
IN - 07	Input 7	12	⇒ Start to compare	7
		13	⇒ Serial and parallel printer manual output	
IN - 08	Input 8	14	⇒ Net / Gross	8



Output signal setting




Item	Function	Setting value		Default
		Parameter	Description	
OUT- 01	Output 1	0 1 2 3 4 5 6 7 8 9 10 11 12 13 14	⇒ None ⇒ Zero band ⇒ SP1 ⇒ SP2 ⇒ SP3 ⇒ Batching completed ⇒ Discharge ⇒ Peak ready ⇒ Stable ⇒ Internal batching process running ⇒ Under ⇒ Over ⇒ Hi ⇒ OK ⇒ Lo	1 2 3 4 5 6 7 8
OUT- 02	Output 2			
OUT- 03	Output 3			
OUT- 04	Output 4			
OUT- 05	Output 5			
OUT- 06	Output 6			
OUT- 07	Output 7			
OUT- 08	Output 8			
OUT-09	The output logic of OUT-04~OUT-01		0000 → positive logic 1111 → negative logic	0000
OUT-10	The output logic of OUT-08~OUT-05		0000 → positive logic 1111 → negative logic	0000



■ Equivalent Circuits


Input



■ IN 1 ~ IN 8 and COM 1. Input signal - Open \leftrightarrow OFF, Short \leftrightarrow ON.

■ Warning: Don't use external power (AC or DC) to connect to the input terminals.

Output





☒ Thumbwheel Switches (for OP-04)

The interface can connect to external thumbwheel switches or a PLC to input various parameters depending on the configuration of SQ-01.

The input variables are:


① Final (5 digits), SP2 (4 digits) & Free Fall (3 digits).

or ② Hi (6 digits), Lo (6 digits).


When using external thumbwheel Switches, SQ-18 should be set to 1.

Connection data

SQ-01 = 1, 2, 4 or 5



SQ-01 = 3 or 6





Chapter 6 Maintenance

6-1 Restore All Parameters to Their Default Factory Values.

(1) While the indicator is counting back to zero, adjust SW to ON and press **F** **ENTER** keys.

(2) Display shows the flashing digits **8.888**.


(3) Confirm / abort.

(3-1) To confirm press the **ENTER** key & don't release it until the display shows **888**, then release the key and return the calibration SW to OFF.

(3-2) To abort, set the calibration SW to OFF directly.

6-2 Maintenance Function Parameters

Power on the machine. Press **F** **ENTER** keys while the display counts back to zero.





6-2-1 Restore the function parameter back to its default value

- (1) During the indicator count back to zero, press keys.
- (2) The display shows
- (3) Press the key and the display shows flashing.
- (4) Confirm / abort.
 - (4-1) To confirm, press the key & don't release it. The display will then show
 - (4-2) To abort press the key or switch the power off.

6-2-2 Clear zero compensation and TARE values

- (1) During the indicator count back to zero, press keys.
- (2) The display shows press the F1 key to display
- (3) Press the key, the display shows flashing.
- (4) Confirm / abort.
 - (4-1) To confirm press the key & don't release it. The display will then show
 - (4-2) To abort press the key or switch the power off.

6-2-3 Clear batch setting

- (1) During the indicator count back to zero, press keys.
- (2) The display shows press the F1 key to display
- (3) Press the key, the display shows flashing.
- (4) Confirm / abort.
 - (4-1) To confirm press the key & don't release it. The display will then show
 - (4-2) To abort press the key or switch the power off.

6-2-4 Display zero voltage (mV/V)

- (1) During the indicator count back to zero, press keys.
- (2) The display shows press the F1 key to display
- (3) Press the key the display shows the zero voltage (mV/V). e.g.
- (4) Press the key or switch the power off.


6-2-5 Clear batch setting

- (1) During the indicator count back to zero, press keys.
- (2) The display shows press the F1 key to display
- (3) Press the key, the display shows the span voltage (mV/V). e.g.
- (4) Press the key or switch the power off.



6-3 Test mode

During the indicator count back to zero





6-3-1 7-Segment display testing

The display will show 0 ~ 9, then display “.” and all of the icons.

To exit press the key

6-3-2 Keypad and calibration SW testing

Setting the calibration SW to “ON”, or pressing any key will cause the related display segment to change from 1 → 1. To exit press the key

6-3-3 Display A/D internal value display

Display range is 0 ~ 520,000d (-0.1mV/V ~ 4.0mV/V). To exit press the key

6-3-4 RS-232 serial loop back testing

Terminal pin 5 and pin 6 must be connected together at the rear of the indicator.

If display shows 8855, the interface is working normally. If display shows 8888, the interface is not working correctly.

6-3-5 EEPROM memory testing

If the display shows 8855, it means normal. If the display shows 8888, the memory is not working correctly.

6-3-6 Option interface card testing

OP-01 RS232/RS422/RS485 testing

1) RS232 testing

J1~J4 ⇒ 1, 2 short (Adjust J1~J4 mini jumper to 2, 3)

Terminal pin 1 and pin 3 must be connected together at the rear of the indicator.

If display shows 8855, the interface is working normally. If display shows 8888, the interface is not working correctly.

2) RS422 testing

J1~J4 ⇒ 1, 2 short (Adjust J1~J4 mini jumper to 1, 2)

J5~J6 ⇒ 1, 2 short (Adjust J5~J6 mini jumper to 1, 2)

Terminal pin1 and pin 3, pin 2 and pin 4 must be separately connected together at the rear of the indicator.

If display shows 8855, the interface is working normally. If display shows 8888, the interface is not working correctly.

OP-02 BCD parallel output interface testing

1) A flashing decimal point indicates the test procedure is active.

2) Program will transmit OFF → ON → OFF signal for each output bit of the BCD interface in sequence.



■ OP-03 Analogue current output interface testing

1) 0 ~ 20 mA current output testing

Use an ammeter to measure the output current between pin1 & pin 3 of the interface.

Use the keys to select the output current level desired.

⇒ 4mA

⇒ 12mA

⇒ 20mA

2) 0 ~ 10V voltage output testing

Use a voltmeter to measure the voltage between pin 2 & pin 3 of the interface.

Use the keys to select the output voltage level desired.


⇒ 1V

⇒ 5V

⇒ 10V


■ **Warning: To avoid damage to components use only a voltmeter.**

■ OP-04 Control I/O (4I/4O) testing



2) Press the key to switch to the control input value.

■ OP-05 Control I/O (8I/8O) testing





Appendix 1 Description of 7-Segment Characters

Digit	7 segments letter	Alphabet	7 segments letter	Alphabet	7 segments letter
0		A		N	
1		B		O	
2		C		P	
3		D		Q	
4		E		R	
5		F		S	
6		G		T	
7		H		U	
8		I		V	
9		J		W	
		K		X	
		L		Y	
°C		M		Z	



Appendix 2 Function Table

Specification Calibration

Item	Function	Setting value		Default
		Parameter	Description	
CSP-01	Unit	0	None	2
		1	g	
		2	Kg	
		3	t	
		4	lb	
CSP-02	Decimal Point	0	None	0
		1	1 Decimal Point	
		2	2 Decimal Point	
		3	3 Decimal Point	
CSP-03	Division	1	Division size	1
		2		
		5		
		10		
		20		
		50		
CSP-04	Max. Capacity	999999 ↓ 000000	Max. capacity	999999
CSP-05	Zero range	0 =full range (±1%~30%)	Zero range = calibration zero point ± (Max. capacity×setting value %)	0
CSP-06	Time of zero tracking	0.0 ~ 5.0 (sec)	Time and range of zero tracking should be use at the same time. If the time is set to 0.0, the zero tracking function is disabled	1.0
CSP-07	Range of zero tracking	0 ~ 9	Range of zero tracking = (setting value×½)D , D=min. division Range and time of zero tracking should be use at the same time. If the range is set to 0, the zero tracking function is disabled	2
CSP-08	Investigate time in stable	0.0 ~ 5.0 (sec)	Investigate time and range should be use at the same time. If the time is set to 0.0, the investigate time is disabled	1.0
CSP-09	Investigate range in stable	0 ~ 9	Investigate time and range should be use at the same time. If the range is set to 0, the investigate range is disabled	2
CSP-10	Weight unstable, function ZERO and TARE	0	Action	0
		1	None	
CSP-11	Gross Weight is negative, function TARE	0	Action	0
		1	None	



FNC Group Function Setting

Item	Function	Setting value			Default	
		Parameter	Description			
FNC-01	Digital Filter I	0	5 Hz		4	
		1	4.17 Hz			
		2	2.5 Hz			
		3	2.08 Hz			
		4	1.25 Hz			
		5	1.04 Hz			
		6	0.63 Hz			
		7	0.52 Hz			
		8	0.31 Hz			
		9	0.26 Hz			
FNC-02	Digital Filter II	0	Disabled		2	
		1	Less filter ↔ Greater			
		2				
		3				
		4				
		5				
FNC-03	Key – Locked	000000 ↓ 111111	0 1	Normal (lock disable) Close (lock enable)	The bits and front panel key positions are related to each other 000000	
FNC-04	“F” function setting	Parameter ⇒ Description 0 ⇒ Display Net / Gross weight 1 ⇒ Setpoint parameter setting 2 ⇒ Tare reset 3 ⇒ Manual serial, parallel print output 4 ⇒ Start load 5 ⇒ Stop load 6 ⇒ Start comparison 7 ⇒ Unload command 8 ⇒ Totalise weight and counts command 9 ⇒ Clear totalised weight and counts 10 ⇒ Hold mode 11 ⇒ Escape Hold mode(I / O DSP) 12 ⇒ Convert to Gross / Net / totalised weight / totalised Count			1	
FNC-05	“F1” function setting				0	



Item	Function	Setting value		Default
		Parameter	Description	
FNC-06	Front panel indication “◀” setting (top)	Parameter ⇒ Description		0
		0	⇒ Zero	
		1	⇒ MD	
		2	⇒ Gross	
		3	⇒ Net	
		4	⇒ Totalised weight (Accu. V)	
		5	⇒ Totalised transactions (Accu. C)	
		6	⇒ SP1	
		7	⇒ SP2	
		8	⇒ SP3	
		9	⇒ Hi	
		10	⇒ OK	
		11	⇒ Lo	
		12	⇒ Under	
		13	⇒ Over	
FNC-07	Front panel indication “◀” setting (next to top)	14	⇒ Discharge	1
		15	⇒ Running	
		16	⇒ Hold	
FNC-08	Front panel indication “◀” setting (next to bottom)	0	5 d	2
		1	10 d	
		2	20 d	
		3	40 d	
		4	60 d	
		5	80 d	
		6	100 d	
		7	150 d	
		8	200 d	
		9	250 d	
FNC-09	Front panel indication “◀” setting (bottom)	0	Hold	3
		1	Peak hold (positive 1)	
		2	Peak hold (negative)	
		3	Peak hold (absolute value)	
		4	Peak hold (positive 2)	
FNC-10	Return to zero band (d: refer to CSP-03)	0	No limitation	0
		1	20 times/s	
		2	10 times/s	
		3	5 times/s	
		4	1 time/s	
FNC-11	Hold	0	Hold	0
		1	Peak hold (positive 1)	
		2	Peak hold (negative)	
		3	Peak hold (absolute value)	
		4	Peak hold (positive 2)	
FNC-12	Rate for display rewrite	0	No limitation	0
		1	20 times/s	
		2	10 times/s	
		3	5 times/s	
		4	1 time/s	



Item	Function	Setting value		Default
		Parameter	Description	
FNC-13	Turn-on zero setting	0	Disable	0
		1	Enable	
FNC-14	Stand-by mode setting	0	Disable all the functions under stand-by mode	0
		1	Only turn off display but not disable other functions under stand-by mode	
FNC-15	Zero function record setting	0	Zero point record not saved into EEPROM	0
		1	Zero point record saved into EEPROM	
FNC-16	Internal calibration password setting	0000	No password	0000
		0001	Password is set	
FNC-17	Turn on/off watchdog	1	Turn on watchdog	1
		0	Turn off watchdog	

Serial Input/Output Interface (Build in OP-1)

Item	Function	Setting value		Default
		Para-meter	Description	
RS1- 01 RS2- 01	Transmit format	0	As display	0
		1	Gross only	
		2	Net only	
		3	As display (simple)	
		4	Gross (simple)	
		5	Net (simple)	
		6	Comparison + As display (simple)	
		7	Comparison +Gross (simple)	
		8	Comparison +Net (simple)	
		9	Tare	
		10	Totalised (Accu.) Weight and number of transactions	
RS1- 02 RS2- 02	Transmit mode	0	Transmit continuous + command mode	4
		1	Auto transmit + command mode	
		2	Manual transmit + command mode	
		3	Command mode	
		4	MODBUS RTU mode	
RS1- 03	Transmit speed	0	600	4
		1	1200	



RS1- 03	Transmit speed	2	2400	4
		3	4800	
		4	9600	
		5	19200	
		6	38400	
		7	57600	
		8	115200	
		0	600	
RS2- 03	Transmit speed	1	1200	2
		2	2400	
		3	4800	
		4	9600	
		5	19200	
		0	N, 8, 1	
RS1- 04	Parity Bit length Stop Bit	1	O, 7, 1	2
		2	E, 7, 1	
		0	N, 8, 2	2
RS2- 04	MODBUS MODE: Parity Bit length Stop Bit	1	O, 8, 1	
		2	E, 8, 1	
		0	No parity, 8 data bits, 1 Stop bit	
RS1- 05	Transmit times	1	Odd parity, 7 data bits, 1 Stop bit	0
		2	Even parity, 7 data bits, 1 Stop bit	
		0	No parity, 8 data bits, 2 Stop bit	
		1	Odd parity, 8 data bits, 1 Stop bit	
		2	Even parity, 8 data bits, 1 Stop bit	
RS2- 05	Transmit times	0	Open	0
		1	1 time/sec.	
		2	2 times/sec.	
		3	5 times/sec.	
		4	10 times/sec.	
RS1- 06	Transmission conditions	0 0 0 0 0 0	0 ⇒ transmit cont. 1 ⇒ Stop transmit	000000 000000
		 Negative (Net Wt.) Weight unstable Overload (OL)		
RS1- 07 RS2- 07	Indicator poling address	00 ↓ 99	When set to 0, Indicator addressing is not used	1 0



BCD Parallel Output Interface (OP – 02)

Item	Function	Setting value		Default
		Parameter	Description	
bCd- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
bCd- 02	Transmit mode	0	Transmit continuous	0
		1	Auto transmit	
		2	Manual transmit	
bCd- 03	Output Logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 04	Data ready Signal logic	0	Positive logic action	0
		1	Negative logic action	
bCd- 05	OL output code	0	FFFFFF	0
		1	999999	
bCd- 06	Data code	0	BCD Code	0
		1	Hex. Code	

Analogue Current/Voltage Output Interface (Op - 03)

Item	Function	Setting value		Default
		Parameter	Description	
AnL- 01	Data type	0	As display	0
		1	Gross	
		2	Net	
AnL- 02	Signal output	0	Current output	0
		1	Voltage output	
AnL- 03	Weight in Lo	000000 ~ 999999	When the weight reaches the value of that in AnL-03(the Max. weight is the max setting value (refer to CSP-04), the current / voltage(refer to AnL-02) output is changed to that configured in AnL-04	0
AnL- 04	Current / Voltage in Lo	4.0 mA ~ 20.0 mA or 0.0 V ~ 10.0 V		
AnL- 05	Weight in Hi	000000 ~ 999999	When the weight reaches the value of that in AnL-05(the Max. weight is the max setting value (refer to CSP-04), the current / voltage(refer to AnL-02) output is changed to that configured in AnL-06	30000
AnL- 06	Current / Voltage in Hi	4.0 mA ~ 20.0 mA or 0.0 V ~ 10.0 V		



External Parallel Input/Output Interface (Op-04 & Op-05)

OP-04 Control I/O (4 in / 4 out) + Setpoint Input (BCD code)




PIN	I/O	Signal	PIN	I/O	Signal
1	IN	Code 100	20	IN	Code 101
2	IN	Code 102	21	IN	Code 103
3	IN	Code 104	22	IN	Code 105
4	IN	Code 106	23	IN	Code 107
5	IN	Code 108	24	IN	Code 109
6	IN	Code 1010	25	IN	Code 1011
7			26		
8			27	OUT	OUT 1
9	OUT	OUT 2	28	OUT	OUT 3
10	OUT	OUT 4	29	IN	Vex
11		COM 2	30		COM 2
12			31		
13		COM 1	32		COM1
14	IN	IN 1	33	IN	IN 2
15	IN	IN 3	34	IN	IN 4
16			35		
17			36	IN	Code 1
18	IN	Code 2	37	IN	Code 4
19	IN	Code 8			

OP-05 Control I/O (8 in / 8 out)

PIN	I/O	Signal	PIN	I/O	Signal
1	IN	IN 1	20		COM 1
2	IN	IN 2	21		COM 1
3	IN	IN 3	22		COM 1
4	IN	IN 4	23		COM 1
5	IN	IN 5	24		COM 1
6	IN	IN 6	25		COM 1
7	IN	IN 7	26		COM 1
8	IN	IN 8	27		COM 1
9		COM 1	28		COM 1
10		COM 2	29		COM 2
11	OUT	OUT 1	30		COM 2
12	OUT	OUT 2	31		COM 2
13	OUT	OUT 3	32		COM 2
14	OUT	OUT 4	33		COM 2
15	OUT	OUT 5	34		COM 2
16	OUT	OUT 6	35		COM 2
17	OUT	OUT 7	36		COM 2
18	OUT	OUT 8	37		COM 2
19	IN	Vex			



Function Configuration Menu

Item	Function	Setting value		Default
		Parameter	Description	
SQ- 01	Batching mode	1	Normal batch	9
		2	Loss-in weight	
		3	Comparison mode	
		4	Normal batch (Built-in program)	
		5	Loss-in weight (Built-in program)	
		6	Hold mode (Built-in program)	
		9	Close flow control	
SQ- 02	Batching start delay time	0.0 ~ 25.5 (sec)	The built-in auto-program starts the batch comparison procedure after the input of the batch start signal	0.0
SQ- 03	SP1,SP2 Waiting time comparison	0.0 ~ 25.5 (sec)	No full flow comparison during this function's set time period. If the set value is 0, indicates this function is not in use	0.0
SQ- 04	Batch finish output signal delay time	0.0 ~ 25.5 (sec)	Output the batch finished signal after this delay time	0.5
SQ- 05	Batch finish Condition	0	Wait until the weight is stabilized	0
		1	No need to wait until the weight has stabilized	
SQ- 06	Batch finish Output signal time	0.0 ~ 25.5 (sec)	Batch finished output signal time. If set to 0, the output signal will be off until the next batch start	1.0
Batch finish signal		ON		
OFF				
SQ- 07	Number of Times the supplementary loading function operates	0 ~ 255	If the set value is 0, this function is not in use	0
SQ- 08	Supplementary loading gate open time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	0.1
SQ- 09	Supplementary loading gate close time	0.0 ~ 25.5 (sec)	Must be coordinate with times of supplementary loading, (SQ- 07)	1.0
Supplementary loading signal				
				



Item	Function	Setting value		Default
		Parameter	Description	
SQ- 10	Discharge start delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is ON	0.0
SQ- 11	Discharge stop delay time	0.0 ~ 25.5 (sec)	Delay time before Discharge signal is OFF	0.0
SQ- 12	Discharge time	0.0 ~ 25.5 (sec)	Won't activate internal discharge control function, if set to 0	0
<p>Discharge input signal</p> <p>Discharge output signal</p> <p>Weight reach zero band</p> <p>SQ- 10</p> <p>SQ- 11</p>				
SQ- 13	Restart delay time	0.0 ~ 25.5 (sec)	Delay time before Restart signal is ON	1.0
SQ- 14	Batching counts	0 ~ 255 (times)	Number of batch runs 0 ⇒ one batch only	0
SQ- 15	Set the zero band in to final weighing value	0	No setting	0
		1	Setting	
SQ- 16	Hi, OK, Lo	0	Comparison anytime	0
		1	To compare at batch finish	
		2	To compare at external input signal	
		3	To compare at batching finish and external input signal	
		4	Comparison auto	
SQ- 17	Auto totalise weight / counts	0	Disabled	0
		1	Enabled	
SQ- 18	The parameter source in weight comparison	0	Key in directly from front keypad	0
		1	Input directly from rear interface	
SQ- 19	Weight comparison delay time	0.0 ~ 25.5 (sec)	Comparison delay time for Hi, OK, Lo	0.5
SQ- 20	TARE auto.	0	Press keypad TARE to TARE	0
		1	TARE auto	
SQ- 21	Discharge auto	0	Input from external input or keypad	0
		1	Discharge auto + manual	



Appendix 3 MODBUS Data Address Table I

Data Register		Bit I/O		Bit I/O	
Function Code 03 (Read)		Function Code 01 (Read)		Function Code 05 and 15 (Write)	
Modbus	SCALE	Modbus	SCALE Output	Modbus	SCALE Input
40000 ~ 40001	As display value	00000	Stable status	01000	Zero
40002 ~ 40003	Gross weight	00001	Zero status	01001	Clear zero compensation
40004 ~ 40005	Net weight	00002	Gross	01002	Tare
40006 ~ 40007	Tare weight	00003	Net	01003	Clear Tare
40008 ~ 40009	Gross weight hold value			01004	Clear Pre-tare
40010 ~ 40011	Net weight hold value	00050	Zero Band	01005	Display the gross weight on main display
40012 ~ 40013	Weight final value	00051	Sp1	01006	Display the net weight on main display
40014 ~ 40015	Unit weight	00052	Sp2	01007	Enter/Exit the function mode
40016 ~ 40017	Percentage value	00053	Sp3	01008 ~ 01027	Switch unit from the 1 st to 20 th
40018 ~ 40019	Totalised value	00054	Batch Finish		
40020 ~ 40021	Totalised times	00055	Under	01049	Switch the operation modes
40022 ~ 40023	Totalised times of HI value	00056	Over	01050	Totalised the current net weight and add 1 to the totalised times
40024 ~ 40025	Totalised times of Lo value	00057	Unloading	01051	Deduct the last totalised value and deduct 1 to the totalised times
40026 ~ 40027	Totalised times of OK value	00058	Hi-Hi	01052	Clear the totalised value and times
		00059	Hi	01053	Running
Function Code 06 and 16 (Write)		00060	Go	01054	Stop
41000 ~ 41001	Pre-tare value	00061	Lo	01055	Discharge starts
41002 ~ 41003	Zero Band value	00062	Lo-Lo	01056	Hold mode ON/OFF
41004 ~ 41005	Target value	00063	Peak ready	01057	Release "Hold value"
41006 ~ 41007	SP1 value	00064	Running	01058	Output judgement
41008 ~ 41009	SP2 value	00065	ZERO calibration	01059	ZERO calibration
41010 ~ 41011	SP3 value	00066	SPAN calibration	01060	SPAN calibration
41012 ~ 41013	LO_LO value	00067	Calibrate ERR0		
41014 ~ 41015	LO value	00068	Calibrate ERR2		
41016 ~ 41017	HI_HI value	00069	Calibrate ERR6		
41018 ~ 41019	HI value				
41020 ~ 41021	Under value				
41022 ~ 41023	Over value				
41024 ~ 41025	Peak value setting				
41026 ~ 41027	Batch Finish delay time				
41100 ~ 41101	SPAN calibration value				

The settings marked in grey are not available.



Appendix 4 MODBUS Data Address Table II

(For Hitech and Pro-face Human Machine Interface)

Data Register		Bit I/O		Bit I/O	
Function Code 03 (Read)		Function Code 01 (Read)		Function Code 05 and 15 (Write)	
Modbus	SCALE	Modbus	SCALE Output	Modbus	SCALE Input
40001 ~ 40002	As display value	00001	Stable status	01001	Zero
40003 ~ 40004	Gross weight	00002	Zero status	01002	Clear zero compensation
40005 ~ 40006	Net weight	00003	Gross	01003	Tare
40007 ~ 40008	Tare weight	00004	Net	01004	Clear Tare
40009 ~ 40010	Gross weight hold value			01005	Clear Pre-tare
40011 ~ 40012	Net weight hold value	00051	Zero Band	01006	Display the gross weight on main display
40013 ~ 40014	Weight final value	00052	Sp1	01007	Display the net weight on main display
40015 ~ 40016	Unit weight	00053	Sp2	01008	Enter/Exit the function mode
40017 ~ 40018	Percentage value	00054	Sp3	01009 ~ 01028	Switch unit from the 1 st to 20 th
40019 ~ 40020	Totalised value	00055	Batch Finish		
40021 ~ 40022	Totalised times	00056	Under	01050	Switch the operation modes
40023 ~ 40024	Totalised times of HI value	00057	Over	01051	Totalised the current net weight and add 1 to the totalised times
40025 ~ 40026	Totalised times of Lo value	00058	Unloading	01052	Deduct the last totalised value and deduct 1 to the totalised times
40027 ~ 40028	Totalised times of OK value	00059	Hi-Hi	01053	Clear the totalised value and times
		00060	Hi	01054	Running
Function Code 06 and 16 (Write)		00061	Go	01055	Stop
41001 ~ 41002	Pre-tare value	00062	Lo	01056	Discharge starts
41003 ~ 41004	Zero Band value	00063	Lo-Lo	01057	Hold mode ON/OFF
41005 ~ 41006	Target value	00064	Peak ready	01058	Release "Hold value"
41007 ~ 41008	SP1 value	00065	Running	01059	Output judgement
41009 ~ 41010	SP2 value	00066	ZERO calibration	01060	ZERO calibration
41011 ~ 41012	SP3 value	00067	SPAN calibration	01061	SPAN calibration
41013 ~ 41014	LO_LO value	00068	Calibrate ERR0		
41015 ~ 41016	LO value	00069	Calibrate ERR2		
41017 ~ 41018	HI_HI value	00070	Calibrate ERR6		
41019 ~ 41020	HI value				
41021 ~ 41022	Under value				
41023 ~ 41024	Over value				
41025 ~ 41026	Peak value setting				
41101 ~ 41102	SPAN calibration value				

The settings marked in grey are not available.



Appendix 5 Examples for Input and Output of Modbus

Examples here use Appendix 3 and can also be applied to appendix 4, with different Modbus Data Address.

CRC : Error check code

Function code 03: Modbus (40000~40001) Weight Display

Name	Input	Description	Name	Output	Description
ID Address	01	Machine ID	ID Address	01	Machine ID
Function code	03		Function code	03	
Starting Address Hi	00	Register's starting address is 0 = 00 00 (HEX)	Byte Count	04	1 register per 2 bytes, and total of 4 bytes
Starting Address Lo	00		Data Hi (40000)	01	
No. of Points Hi	00	40000~40001, 2 registers are used	Data Lo (40000)	F4	500 (10) = 01 F4 (HEX)
No. of Points Lo	02		Data Hi (40001)	00	
			Data Lo (40001)	00	Data in 40001
CRC	04		CRC	BA	
	0B			3D	

Function code 05: Modbus (01000) write zero command

Name	Input	Description	Name	Output	Description
ID Address	01	Machine ID	ID Address	01	Machine ID
Function code	05		Function code	05	
Register's address	03	1000 ₍₁₀₎ = 03 E8 _(HEX)	Register's address	03	1000 ₍₁₀₎ = 03 E8 _(HEX)
	E8	this address for "zero on/off"		E8	this address for "zero on/off"
ON/OFF	FF	FF 00 :zero on	ON/OFF	FF	FF 00 :zero on
	00	00 00 : zero off		00	00 00 : zero off
CRC	0C		CRC	0C	
	4A			4A	

Function code 06: Modbus (41004) write zero band value

Name	Input	Description	Name	Output	Description
ID Address	01	Machine ID	ID Address	01	Machine ID
Function code	06		Function code	06	
Register's address	03	address for zero band value	Register's address	03	address for zero band value
	EC	1004 ₍₁₀₎ = 03 EC _(HEX)		E8	1004 ₍₁₀₎ = 03 EC _(HEX)
Setting value	01	500 ₍₁₀₎ = 01 F4 _(HEX)	Setting value	01	500 ₍₁₀₎ = 01 F4 _(HEX)
	F4			F4	
CRC	48		CRC	48	
	6C			6C	

**Function code 06: Modbus (41026): write batch finish delay time write**

Name	Input	Description	Name	Output	Description
ID Address	01	Machine ID	ID Address	01	Machine ID
Function code	06		Function code	06	
Register's address	04	Batch Finish delay time address 1026 ₍₁₀₎ = 04 02 _(HEX)	Register's address	04	Batch Finish delay time address 1026 ₍₁₀₎ = 04 02 _(HEX)
	02			02	
Setting value	00	Input value 7s is 0007 _(HEX)	Setting value	00	Input value 7s is 0007 _(HEX)
	07			07	
CRC	xx		CRC	xx	
	xx			xx	

Function code 01: Modbus (00000~00001): read current scale status

Name	Input	Description	Name	Output	Description
ID Address	01	Machine ID	ID Address	01	Machine ID
Function code	01		Function code	01	
Register's address	00	Starting Address	Bit	02	Read 2 Bit data: 2=10 ₍₂₎ , 00001 = 1 (return to zero) or 0 (non return to zero), 00000 = 0 (stable) or 1 (unstable)
	00				
Setting value	00	Read 2 status (2 Bit) 00000~00001			
	02				
CRC	BD		CRC	D0	
	CB			49	