


# Ball valve

Operating manual

Series C 10



---

Version BA-2022.08.16 EN  
Print-No. 302 451  
TR MA DE Rev001

STÜBBE GmbH & Co. KG  
Hollwieser Straße 5  
32602 Vlotho  
Germany  
Phone: +49 (0) 5733-799-0  
Fax: +49 (0) 5733-799-5000  
E-mail: [contact@stuebbe.com](mailto:contact@stuebbe.com)  
Internet: [www.stuebbe.com](http://www.stuebbe.com)

Subject to technical modifications.  
Read carefully before use.  
Save for future use.



## Table of contents

<b>1 About this document</b>	3
1.1 Target groups	3
1.2 Other applicable documents	3
1.3 Warnings and symbols	3
<b>2 Safety instructions</b>	4
2.1 Intended use	4
2.2 General safety instructions	4
2.2.1 Obligations of the operating company	4
2.2.2 Obligations of personnel	4
2.3 Specific hazards	4
2.3.1 Hazardous media	4
<b>3 Layout and Function</b>	4
3.1 Marking	4
3.1.1 Name plate	4
3.2 Description	5
3.3 Assembly	5
3.3.1 C10 manual	5
3.3.2 C10 electric drive	5
3.3.3 C10 pneumatic drive	5
<b>4 Transport, Storage and Disposal</b>	6
4.1 Unpacking and inspection on delivery	6
4.2 Transportation	6
4.3 Storage	6
4.4 Disposal	6
<b>5 Installation and connection</b>	7
5.1 Preparations for installation	7
5.2 Planning pipelines	7
5.3 Installing fitting in pipe	7
5.3.1 Connection with flange	7
5.3.2 Connection with sockets, spigot ends or female threads	7
5.4 Drive and limit switch box	8
5.5 Connection	8
5.5.1 Electrical connection	8
5.5.2 Pneumatic connection	8
5.5.3 Check sense of rotation of drive	9
5.6 Performing the hydrostatic test	9
<b>6 Operation</b>	9
6.1 Commissioning	9
6.2 Emergency manual operation	9
<b>7 Maintenance</b>	10
7.1 Servicing	10
7.2 Maintenance	10
7.2.1 Removing fitting	10
7.2.2 Fixing leaks in the port	10
7.2.3 Fix leakage at ball valve stem	10

7.3 Replacement parts and return	10
<b>8 Troubleshooting</b>	11
<b>9 Appendix</b>	12
9.1 Technical specifications	12
9.2 Flange installation	12
9.3 Operating torques	12
9.4 Replacement parts	13

## List of figures

Fig. 1 Name plate (example)	4
Fig. 2 C10 manual	5
Fig. 3 C10 electric drive	5
Fig. 4 C10 pneumatic drive	5
Fig. 5 Attach lifting gear (example)	6
Fig. 6 Electric drive	8
Fig. 7 Pneumatic drive	8
Fig. 8 Connect pneumatics	8
Fig. 9 Tightening torques	12
Fig. 10 Replacement parts	13

## List of tables

Tab. 1 Other application documents, purpose and where found	3
Tab. 2 Warnings and symbols	3
Tab. 3 Control pressure connections	8
Tab. 4 Troubleshooting	11
Tab. 5 Tightening torques	12
Tab. 6 Operating torques	12
Tab. 7 Replacement parts	13

## 1 About this document

This manual

- is part of the fitting
- applies to all series referred to
- describes safe and proper operation during all operating phases

### 1.1 Target groups

#### Operating company

- Responsibilities:
  - Keep this manual available at the place of operation, also for future use.
  - Ensure that employees read and observe this manual and other applicable documents, especially the safety instructions and warnings.
  - Observe any additional country-specific rules and regulations that relate to the system.

#### Qualified personnel, fitter








- Mechanics qualification:
  - Qualified employees with additional training for fitting the respective pipework
- Electrical qualification:
  - Qualified electrician
- Responsibility:
  - Read, observe and follow this manual and the other applicable documents, especially all safety instructions and warnings.

## 1.2 Other applicable documents

<p><b>Resistance lists</b> Resistance of materials used to chemicals</p> <p><a href="http://www.stuebbe.com/pdf/300051.pdf">www.stuebbe.com/pdf/300051.pdf</a></p>	
<p><b>Data sheet</b> Technical data and conditions of operation</p> <p><a href="http://www.stuebbe.com/pdf/302457.pdf">www.stuebbe.com/pdf/302457.pdf</a></p>	
<p><b>CE declaration of conformity</b> Conformity with standards</p> <p><a href="http://www.stuebbe.com/pdf/300168.pdf">www.stuebbe.com/pdf/300168.pdf</a></p>	
Electric drive operating manual	
Limit switch box operating manual	


Tab. 1 Other application documents, purpose and where found

## 1.3 Warnings and symbols

Symbol	Meaning
	<ul style="list-style-type: none"> <li>• Immediate acute risk</li> <li>• Death, serious bodily harm</li> </ul>
	<ul style="list-style-type: none"> <li>• Potentially acute risk</li> <li>• Death, serious bodily harm</li> </ul>
	<ul style="list-style-type: none"> <li>• Potentially hazardous situation</li> <li>• Minor injury</li> </ul>
	<ul style="list-style-type: none"> <li>• Potentially hazardous situation</li> <li>• Material damage</li> </ul>
	<p>Safety warning sign</p> <ul style="list-style-type: none"> <li>▶ Take note of all information highlighted by the safety warning sign and follow the instructions to avoid injury or death.</li> </ul>
	Instruction
1., 2., ...	Multiple-step instructions
✓	Precondition
→	Cross reference
	Information, notes

Tab. 2 Warnings and symbols


## 2 Safety instructions

 The manufacturer accepts no liability for damages caused by disregarding any of the documentation.

### 2.1 Intended use

- Only use the fitting to shut off pipes for appropriate media (→ Resistance list).
- Adhere to the operating limits (→ Data sheet).
- When using media that contains solids, the wear increases.

### 2.2 General safety instructions

 Read and observe the following regulations before carrying out any work.

#### 2.2.1 Obligations of the operating company

##### Safety-conscious working

- Only operate the fitting if it is in perfect technical condition and only use it as intended, remaining aware of safety and risks, and adhering to the instructions in this manual.
- Ensure that the following safety aspects are observed and monitored:
  - Intended use
  - Statutory or other safety and accident-prevention regulations
  - Safety regulations governing the handling of hazardous substances
  - Applicable standards and guidelines in the country where the pump is operated
- Make personal protective equipment available.

##### Qualified personnel

- Ensure all personnel tasked with work on the fitting have read and understood this manual and all other applicable documents, especially the safety, maintenance and repair information, before they start any work.
- Organize responsibilities, areas of competence and the supervision of personnel.
- The following work should be carried out by specialist technicians only:
  - Installation, repair and maintenance work
  - Work on the electrical system
- Make sure that personnel to be trained only work on the fitting under the supervision of specialist technicians.

#### 2.2.2 Obligations of personnel

- Observe the instructions on the fitting and keep them legible, e.g. name plate and identification marking for fluid connections.
- Only carry out work on the fitting if the following requirements are met:
  - System is empty
  - System has been flushed
  - System is depressurized
  - System has cooled down
  - System is secured against being switched back on again
- Do not modify the fitting in any way.

### 2.3 Specific hazards

#### 2.3.1 Hazardous media

- When handling hazardous media (e.g. hot, flammable, explosive, toxic, hazardous to health or the environment), observe the safety regulations for the handling of hazardous substances.
- Use personal protective equipment when carrying out any work on the fitting.
- Collect leaking pumped liquid and residues in a safe manner and dispose of them in accordance with environmental regulations.

## 3 Layout and Function

### 3.1 Marking

#### 3.1.1 Name plate




Fig. 1 Name plate (example)

- 1 Type
- 2 ID number
- 3 Nominal pressure [bar] / Nominal diameter [mm]
- 4 Materials (body, ball seals, other gaskets)
- 5 Date of manufacture - Series number

## 3.2 Description

Manually, electrically or pneumatically driven ball valve for shutting off pipes.

- Optional flow direction
- Optional installation position
  - Position electric drive laterally or over the fitting.
- Opening angle OPEN/CLOSE 90°
- Connection variants available
  - Female thread
  - Flange
  - socket end for solvent welding
  - fusion socket end
  - Fusion spigot end

## 3.3 Assembly

### 3.3.1 C10 manual




Fig. 2 C10 manual

- 1 T-handle
- 2 Union nut
- 3 Insert (here socket)
- 4 Housing with ball

### 3.3.2 C10 electric drive




Fig. 3 C10 electric drive

- 1 T-handle/Position indicator
- 2 Electric drive
- 3 Insert (here flange)
- 4 Housing with ball
- 5 Union nut
- 6 Bracket

### 3.3.3 C10 pneumatic drive




Fig. 4 C10 pneumatic drive

- 1 Position indicator
- 2 Pneumatic drive
- 3 Insert (here flange)
- 4 Housing with ball
- 5 Union nut
- 6 Bracket

## 4 Transport, Storage and Disposal

### 4.1 Unpacking and inspection on delivery

1. Unpack the fitting when received and inspect it for transportation damage.
2. Report any transportation damage to the manufacturer immediately.
3. Ensure that the information on the name plate agrees with the order/design data.
4. For immediate installation, damage packaging material according to local regulations.
  - For later installation, leave the fitting in the original packaging.

### 4.2 Transportation

#### **⚠ DANGER**

**Death or limbs crushed as a result transported items falling over or tilting.**

- ▶ Do not stand under suspended loads.
- ▶ Use lifting gear appropriate for the total weight to be transported. Weight specification (→ data sheet).
- ▶ Attach lifting gear in accordance with the following diagram.




Fig. 5 Attach lifting gear (example)

- ▶ Lift the fitting with properly installed lifting gear and position it at the place of installation.

### 4.3 Storage

#### **NOTE**

**Material damage due to inappropriate storage!**

- ▶ Store the fitting properly.

1. Make sure the storage room meets the following conditions:
  - Dry
  - Frost-free
  - Vibration-free
  - Not in direct sunlight
  - Storage temperature +10 °C to +60 °C
2. Store fitting in “Valve open” state, if possible in the original packaging.

### 4.4 Disposal

- ▶ Plastic parts can be contaminated by poisonous or radioactive media to such an extent that cleaning will not be sufficient.

#### **⚠ WARNING**

**Risk of poisoning and environmental damage from medium!**

- ▶ Use personal protective equipment when carrying out any work on the fitting.
- ▶ Before disposing of the fitting:
  - Collect escaping medium and dispose separately according to local regulations.
  - Neutralize residues of medium in the fitting.
- ▶ Remove plastic parts and damage them in accordance with local regulations.
- ▶ Dispose of the fitting in accordance with local regulations.

## 5 Installation and connection

### 5.1 Preparations for installation

1. Ensure the design of the fitting is consistent with the purpose intended:
  - Materials used (→ Type plate).
  - Medium (→ Order and design data).
2. Ensure the required operating conditions are met:
  - Resistance of body and seal material to the medium (→ resistance lists).
  - Media temperature (→ Data sheet).
  - Operating pressure (→ Data sheet).
3. Consult with the manufacturer regarding any other use of the device.

### 5.2 Planning pipelines

#### WARNING

#### Risk of poisoning and environmental damage from medium!

Leaks due to impermissible pipework forces.

- ▶ Ensure that the fitting is not subject to any pulling or thrusting forces or bending moments.

1. Plan pipes safely:
  - No pulling or thrusting forces
  - No bending moments
  - Adjust for changes in length due to temperature changes (compensators, expansion shanks)
  - Optional flow direction
  - Optional installation position and direction. Position electric drive laterally or over the fitting.
2. Dimensions (→ Data sheet).

### 5.3 Installing fitting in pipe

#### WARNING

#### Risk of poisoning and environmental damage from medium!


Leak due to faulty installation.

- ▶ Installation work on the pipes should only be performed by technicians who have been specially trained for the pipework in question.

#### NOTE

#### Material damage due to contamination of the fitting!

- ▶ Make sure no contamination reaches the fitting.
- ▶ Flush the pipe with a neutral medium.

 The fitting is installed according to the connection type of the pipes.

Any position of the compressed air drive.

Position electric drive laterally or over the fitting.


#### 5.3.1 Connection with flange

1. Open fitting completely.
2. Prepare pipe ends according to connection type.
3. Radially position the fitting and flat seal between the flange ends.
4. Screw fitting (flange screws, nuts and washers).
  - Observe tightening torques (→ [Tab. 5 Tightening torques, Page 12](#)).

#### 5.3.2 Connection with sockets, spigot ends or female threads

1. Open fitting completely.
2. Prepare pipe ends according to connection type.
3. Loosen the union nuts on the inserts and push same over the pipeline end.
4. Connect inserts with pipe ends.
5. Radially push the valve between the pipeline ends and tighten by hand using the union nuts.

## 5.4 Drive and limit switch box

 Limit switch box can only be used with pneumatic drive.




Fig. 6 Electric drive

- 1 Electric drive
- 2 Cable bushing for power supply / additional limit switch
- 3 Mounting set
- 4 Coupling





Fig. 7 Pneumatic drive

- 1 Pneumatic drive
- 2 Mounting set
- 3 Coupling

## 5.5 Connection

### 5.5.1 Electrical connection

 Connection plan (→ Data sheet).


### DANGER

#### Risk of electrocution!

► All electrical work must be carried out by qualified electricians only.

1. Connect limit switch in electric drive (→ electric drive operating manual).
2. Connect electric drive (→ Electric drive operating manual).
3. Connect limit switch in limit switch box (→ limit switch box operating manual).

### 5.5.2 Pneumatic connection

 Solenoid pilot valves are available for control of the pneumatic drive (→ Operating instructions for pilot valve):

- 3/2-way valve for single-acting drives
- 5/2-way valve for double-acting drives

### CAUTION

#### Risk of injury from compressed air!

► All work on the pneumatic system must be carried out by qualified technicians.




Fig. 8 Connect pneumatics

- A Connection A
- B Connection B

► Connect compressed air lines to the pneumatic drive (→ Fig. 8 Connect pneumatics, Page 8).

Function	Control pressure to connection	
	A	B
Normally closed (NC)	-	open
Normally open (NO)	-	close
Double acting (DA)	close	open


Tab. 3 Control pressure connections



### 5.5.3 Check sense of rotation of drive

1. Open and close fitting once via drive.
2. Check position of the fitting at the flow indicator:
  - Position indicator along the pipe: Fitting opened

## 5.6 Performing the hydrostatic test

 Pressure test using neutral medium, e.g. water.

1. Pressurize the fitting, ensuring:
  - Test pressure < permissible system pressure
  - Test pressure < 1.5 PN
  - Test pressure < PN + 5 bar
2. Check the fitting for leaks.

## 6 Operation

### 6.1 Commissioning

- ✓ Fitting correctly installed and connected


#### **WARNING**


#### **Risk of injury and poisoning due to medium spraying out!**

- ▶ Use personal protective equipment when carrying out any work on the fitting.

1. Opening and closing the fitting:
  - Hand lever/Position indicator along the pipe: Fitting opened
  - Hand lever/Position indicator perpendicular to the pipe: Fitting closed
2. After the initial stresses due to pressure and operating temperature, check if the fitting is sealed.

### 6.2 Emergency manual operation

 Only with electrically driven ball valve.



1. Ensure that the electricity supply is interrupted for the electric drive.
2. Set the clutch switch (2) from AUTO to MAN and hold it.
3. Remove the protective cap (1).
4. Turn the actuator shaft with the aid of an adjustable spanner until the fitting is in the desired position.
5. Put the protective cap back on.
6. Set the clutch switch back to AUTO.

## 7 Maintenance

### WARNING

**Risk of injury and poisoning due to hazardous media liquids!**

- ▶ Use personal protective equipment when carrying out any work on the fitting.

### 7.1 Servicing

1. Visual and function check (every three months):
  - Normal operating conditions unchanged
  - No leaks
  - No unusual operating noises or vibrations
2. Ensure that fitting functions properly (opening, closing).
3. Clean the fitting with a moist cloth if necessary.

### 7.2 Maintenance

#### DANGER

**Risk of electrocution!**

- ▶ All electrical work must be carried out by qualified electricians only.

### WARNING

**Risk of injury and poisoning due to hazardous or hot media!**

- ▶ Use personal protective equipment when carrying out any work on the fitting.
- ▶ Safely collect the media and dispose of it in accordance with environmental regulations.

### WARNING

**Risk of injury during disassembly!**

- ▶ Wear protective gloves, components can be very sharp-edged due to wear or damage.
- ▶ Remove components with springs (e.g. pneumatic drive) carefully, since spring tension can cause components to be ejected.

#### 7.2.1 Removing fitting

1. Ensure that:
  - System is empty
  - System has been flushed
  - System is depressurized
  - System has cooled down
  - System is secured against being switched back on again
2. Remove fitting from the pipe.
3. Decontaminate fitting if required.
  - Dead space in the fitting may still contain medium.

#### 7.2.2 Fixing leaks in the port

1. Removing fitting (→ 7.2.1 Removing fitting, Page 10).
2. Replace ball seals and/or ball.
3. Install fitting (→ 5.3 Installing fitting in pipe, Page 7 ).

#### 7.2.3 Fix leakage at ball valve stem

1. Removing fitting (→ 7.2.1 Removing fitting, Page 10).
2. Replace the O-rings on the ball valve stem.
3. Install fitting (→ 5.3 Installing fitting in pipe, Page 7 ).

### 7.3 Replacement parts and return

1. Have the following information ready to hand when ordering spare parts (→ Type plate).
  - Fitting type
  - ID number
  - Nominal pressure and diameter
  - Body and seal material
2. Please complete and enclose the document of compliance for returns (→ [www.stuebbe.com/en/service/download](http://www.stuebbe.com/en/service/download)).



3. Use only spare parts from STÜBBE.

## 8 Troubleshooting

### WARNING

**Risk of injury and poisoning due to hazardous or hot media!**

- ▶ Use personal protective equipment when carrying out any work on the fitting.
- ▶ Safely collect the media and dispose of it in accordance with environmental regulations.


Consult with the manufacturer regarding faults which are not identified in the following table, or which cannot be traced to the indicated causes.

Error	Possible cause	Corrective action
Control function is not right	Control connections mixed up	▶ Connect control connections correctly.
	Compressed air connection mixed up at pneumatic drive	▶ Check compressed air connection and correct if necessary (→ supplementary instructions for drives).
	Electrical connection faulty	▶ Check electric connect and correct if necessary (→ supplementary instructions for limit switch).
Medium is leaking out of the flange	Pre-tension of the O-ring too small	▶ Retighten flange fittings (→ <a href="#">9.2 Flange installation, Page 12</a> ).
Medium leakage at the stem	O-ring worn	▶ Replace fitting.
Fitting does not close completely	Ball seals worn Ball worn	▶ Fixing leaks (→ <a href="#">7.2.2 Fixing leaks in the port, Page 10</a> ).
	Control pressure too low	▶ Check compressed air supply. ▶ Ensure sufficient compressed air (→ data sheet)

Tab. 4 Troubleshooting

## 9 Appendix

### 9.1 Technical specifications

 Technical data (→ Data sheet).

### 9.2 Flange installation





Fig. 9 Tightening torques

d [mm]	ND [mm]	Tightening <sup>*1)</sup> MD [Nm] for the versions		
		Flat sealing ring max. 10 bar max. 40 °C	Profile seal max. 16 bar	O-ring max. 16 bar
20	15	10	10	10
25	20	12	12	12
32	25	15	12	12
40	32	20	15	15
50	40	25	15	15
63	50	30	20	20

Tab. 5 Tightening torques

1) Use a torque wrench

### 9.3 Operating torques

 The specified values are standard values for a manually operated ball valve under the following conditions:

- Water (H<sub>2</sub>O)
- Media temperature 20 °C

Material	Torque [Nm] for d [mm]						
	16	20	25	32	40	50	63
PVC-U / PP	–	4	5	6	8	10	16

Tab. 6 Operating torques

## 9.4 Replacement parts




Fig. 10 Replacement parts

Pos.	Piece	Designation
1	1	Housing with ball
2	1	T-handle
3	1	Circlip
4	1	pressure piece
5	1	Radial rotary shaft seal
6	2	Insert
7	2	Union nut
8	2	Radial rotary shaft seal
9	1	Bracket
10	1	Coupling
11	1	Mounting set
12	1	Electric drive
13	1	Pneumatic drive

Tab. 7 Replacement parts