

Pressure gauge with switch

G52D Series

JIS symbol







- Nonpolar connector as an option
- Activation confirmation lamp as an option

Oil-ProhR MedPresFR

PresSW

Shutoff

SlowStart

FImResistFR

No Cu/ PTFE FRL Outdrs FR

CompFRL

LgFRL

PrecsR

VacF/R

Clean FR ElecPneuR

AirBoost

SpdContr

Silncr CheckV

Jnt/tube

AirUnt

PrecsCompn

ElecPresSw

ContactSW

AirSens PresSW

Cool AirFloSens/ Contr

WaterRtSens TotAirSys

(Total Air) TotAirSys (Gamma)

RefrDry

DesicDry

HiPolymDry

MainFiltr

Dischrg etc

*1: Contact CKD when ordering NPT thread. *2: Contact CKD for indications other than MPa.

Features

- Pressure switch function added to the analog pressure gauge

Specifications

1 MPa = 10 bar

Сробинов			
Description	ns	Pressure gauge	
Working fluid		Compressed air	
Fluid temperature °C		5 (41°F) to 60 (140°F)	
Ambient temperature °C		-5 (23°F) to 60 (140°F) (no freezing)	
Accuracy *1		Full scale ±3%	
Shape		DT type (rear side screw, stock section hexagon)	
Material	Stock	Copper alloy	
	Bourdon tube	Phosphor bronze	
	Housing	Steel plate + chrome plating	
	Lens	Polycarbonate resin	
	Setting needle	ABS resin (green)	
Pressure range *2		0 (≈0 psi) to 1.0 MPa (≈150 psi)	
Port size R		1/4	
Weight g		150	
*4. The		real temperature is 20115°C	

^{*1:} The guaranteed indicator accuracy temperature is 20±15°C.

1 MPa = 10 bar Descriptions **Pressure switch** Pressure switch setting range 0.1 (≈15 psi) to 0.8 MPa (≈120 psi) 0.07 MPa (≈10 psi, 0.7 bar) Hysteresis Without lamp: 1ab (normally open, normally closed) Contact array With lamp: 1a (normally open) Setting needle error ±0.05 MPa (≈7.3 psi, 0.5 bar) 300 mm Lead wire length Without lamp: 3 lead wires Electrical connections With lamp: M12 connector (4-pin) Indicator lamp LED (load current: 8 to 30 mA)


Micro switch rating

Load	Resistance load			
Rated voltage	30 VDC	125 VAC		
Operating current range *1	0.1 to 2 A	0.1 to 5 A		


^{*1:} Use 12 VDC or more for 0.10 to 0.16 A.

Electrical wiring diagram


O Without indicator lamp




○ With indicator lamp/LED



How to order



Terminal layout of male connectors




^{*2:} Do not apply pressure exceeding the maximum indicated pressure. Otherwise, malfunctions may result.



Dimensions



Without indicator lamp



- screw to set the setting needle to
- * Turn the setting screw
- · Minus (-) side (clockwise)
- → set pressure decrease
- · Plus (+) side (counterclockwise)
- → set pressure increase

Safety precautions

The lamp turns ON when higher than the

set pressure, and OFF when less than

the set pressure.

Make sure that impact and vibration are not applied directly onto the body.

Lead wire with 4-pin connector

Repeated and sudden increases or decreases in pressure and pressure pulsations must be avoided as they could adversely affect the life of the pressure gauge. Ease the pressure fluctuation in the circuit.

Setting screw

- The pressure switch setting value is indicated with the green setting needle. Set the pressure switch value so that the setting needle turns clockwise. If the setting needle passes the setting position, turn the setting needle counterclockwise once, then reset.
- Set a difference of 0.1 MPa and over from the working pressure (including pressure drops). Malfunctions could result if the difference is small. Refer to the drawings above for details on setting the setting needle. When using the pressure switch in the normally open state, the switch may not turn ON when the pressure drops unless pressure, to which set indication error (±0.05 MPa), hysteresis (0.07 MPa), and indicated accuracy (±3% F/S) have been added, has been applied.
- Add the pressure gauge's indication accuracy to the maximum value of the setting indicator and indicator error (set indicator error).
- When a DC lamp is used, the internal voltage drop is to be 4 V or less and load current 8 to 30 mA at 24 VDC. Please be careful.
- Wire such that repeated bending or tension are not applied to the lead wires. Failure to do so could lead to disconnection or malfunction.
- Avoid using in an atmosphere containing silicone (siloxane). Contact failure could result.
- Setting needle error may increase depending on the operating environment and operating frequency. Check the operation periodically.

F.R.L

F (Filtr)

R (Reg) L (Lub)

PresSW

Shutoff

SlowStart

FImResistFR

Oil-ProhR

MedPresFR No Cu/ PTFE FRL

Outdrs FR

CompFRL

LgFRL

PrecsR VacF/R

Clean FR

ElecPneuR

AirBoost

SpdContr

Silncr

CheckV/ other

Jnt/tube

AirUnt

PrecsCompn

ElecPresSv ContactSW

AirSens

PresSW

AirFloSens/ Contr

WaterRtSens

TotAirSys (Total Air) TotAirSys

RefrDry DesicDry

HiPolymDry

MainFiltr

Dischrg etc Ending

