


FAQ Sheet

T6360B Room Thermostat Wiring & Operation



How do I wire a T6360B room thermostat?

Wiring diagram of T6360B terminals on T6360B




NOTE: Terminal 4 is the 'make on temperature rise' contact; this can be used to power a 'cooling' ventilation fan. Please note you can't wire both heating and cooling to the same thermostat.

The picture above left shows the diagram that is printed in the installation instructions. It is a diagram drawn to I.E.E. guidelines. The picture above right is a photograph of the actual thermostat terminals. Wire in the thermostat according to the number, not the order the terminals are positioned. The "heating load" could be a pump, boiler or motorised valve. There is NO colour coding in central heating wiring so we cannot recommend a "colour-to-a-number".

A room thermostat is basically a switch, making and breaking a 230V electrical signal according to room temperature. It is essential that a neutral connection is made to Terminal 2 to give accurate temperature control. (The T6360B will not work on 24V)

On the T6360B range of thermostats Terminal 1 is the Live IN (LINE) and Terminal 3 is the Switched Live OUT (LOAD). In order to respond to temperature change accurately, the room thermostat must have a separate Neutral connection on Terminal 2. If replacing an existing thermostat that does not have a separate neutral wire, the T6360B cannot be used. Alternatively, use a volt-free DT200 thermostat or CM900 series programmable thermostat as the replacement.

Typical wiring configurations



honeywelluk.com

Honeywell

This FAQ sheet is for guidance only and at the time of production represented the latest information available to Honeywell from various sources. Honeywell reserves the right at any time and without notice to change any product, specification or any other information contained in this publication and cannot accept any responsibility for loss or damage arising out of any errors that may inadvertently be contained herein.

Technical support: Ring 08457 678999 (local rate charge), +44 (0)1344 656125 (calls from outside the UK) or email technical.support@honeywell.com
Sales enquiries: Ring 01344 656591 or e-mail uk.infocentre@honeywell.com
Sales support literature: Visit the Downloads section of honeywelluk.com, ring 0800 521121 (UK only) or e-mail literature@honeywell.com