

350 470 E

Lenze

Antriebstechnik

Technical description

***Speed controllers
for DC motors
490 Series***



Part no. 350 470

This technical description is valid for
Control board type 4091.2

3rd edition of: 15.11.1993

Date of print: 29.11.1993

Safety information

The equipment described is intended for use in industrial electrical drive systems.



This equipment can endanger life through rotating machinery and high voltages, therefore it is essential that guards for both electrical and mechanical parts are not removed.

The following points should be observed for the safety of the personnel:

- **Only qualified personnel familiar with the equipment are permitted to install, operate and maintain the devices.**
- **System documentation must be available and observed at all times.**
- **All non-qualified personnel are kept at a safe distance from the equipment.**
- **The system must be installed in accordance with local regulations.**

A qualified person, is someone who is familiar with all safety notes and established safety practices, with the installation, operation and maintenance of this equipment and the hazards involved. For more detailed definitions see IEC 364.

It is recommended that anyone who operates or maintains electrical or mechanical equipment should have a basic knowledge of First Aid. As a minimum, they should know where the First Aid equipment is kept and the identity of the official First Aiders.

These safety notes do not represent a complete list of the steps necessary to ensure safe operation of the equipment. If you wish further information, please contact your nearest Lenze representative.

The information in this technical description applies only to the hardware versions that are indicated on the cover page. If the version of your equipment is not listed, then this manual must not be used. Lenze cannot be held responsible for any malfunction resulting from the above.

The specifications, processes and circuitry described in this manual are for guidance only and must be adapted to your own specific applications. Lenze does not guarantee the suitability of the processes and circuitry described in this technical description for individual applications.

The specifications in this manual describe the features of the products, without guarantee.

Lenze personnel have carefully checked this manual and the equipment it describes, but cannot be held responsible for its accuracy.

Technical alterations reserved.

Table of contents	page
1. Special features	2
2. Technical data	2
3. Connecting diagram	3
4. Installation instructions	4
5. Connecting instructions	4
6. Special field voltages	5 - 6
7. Setting instructions	7 - 9
8. Switch operation	9 - 11
9. Connecting terminals	11 - 14
10. Optical display for the most important functions with LEDs	14 - 15
11. Additional soldering posts	15
12. Dimensions	16 - 17
13. Items supplied	17

The Simplatron controller series 490 comprises five 4-quadrant DC speed controllers with 6.4 to 80 kW output power in compact design.

1. Special features

- Compact controllers with potential-free heatsink
- Highly dynamic due to six-pulse three-phase bridge design and discontinuous current adaptation
- Isolation due to current transformers
- Operation by tacho or armature voltage feedback with IxR compensation
- Self synchronisation of the phase shifter for 50-60Hz mains
- High interference margin by built-in synchronizing filters
- Pulse series firing in the power stage
- High operational safety due to static and dynamic voltage surveillance
- Display of operational states by LED


2. Technical data

Controller		492	493	494	495	496
Output power	P_{el}/kW	6.4	10	22	44	80
Mains voltage	U_{3LN}	340 - 460V \pm 0%, 50-60Hz				
Field voltage	U_F	$0.9 \times U_{L1}, U_{L2(N)}$				
Field current	I_F/A	3	8			
Armature voltage	U_A/V	400				
Armature current	I_A/A	16	25	55	110	200
Nominal master voltage	U_{LN}/V	10 - 180				
Nominal tacho voltage	U_{TN}/V	10 - 180				
Field fuse	F 101 part no.	1x FF4A (6.3x32) 308 054	1 x FF 16 A/500V (6.3 x 32) 305 725			
Electronic fuse	F 102 F 103 F 104	3 x F1A/450V (5x25) part no. 307 290				
Temperature range	$T_U/^\circ C$	0 - 45				
Set value potentiometer	R_1	10 k Ω /1W/lin.				
approx. weight	kg	5.5	8.1	8.1	11	11
Control board 4091.2	part no.	325 333				
Chassis controller E	part no.	325 592	325 332	325 335	332 336	325 337

Accessories (to be ordered separately)

Recommended mains fuses F1, F2, F3 (3 off needed)	part no.	FF 20 A 14 x 51 305 321	FF 32 A 14 x 51 307 943	FF 63 A 22 x 57 305 239	FF125 A 00.80 307 247	FF200 A 00.80 321 542
Recommended armature circuit fuse F4	part no.	FF 20 A 14 x 51 305 321	FF 32 A 14 x 51 307 943	FF 80 A 22 x 57 307 174	FF125 A 00.80 307 247	FF200 A 00.80 321 542
Fuse holders 4 off needed	part no.	332 721	332 721	308 291	326 308	326 308
Three-phase mains choke L_K	part no.	3x1.2mH 322 149	3x1.1mH 322 148	3x750 μ H 307 343	3x270 μ H 307 346	3x165 μ H 308 234

3. Connecting diagram



1. Screen cables for transmission of electronic signals
 2. If the signals must be changed-over via relays, use suitable relay contacts (e.g. gold-plated contacts).

4. Installation instructions

- 4.1 When installing in an enclosure, ensure adequate ventilation. The ambient temperature must not exceed 45°C. Install the controller vertically with the terminals at the top. Ensure that there is adequate ventilation. Observe power losses. See 12.3.
- 4.2 When the switch RFR is closed, the controller is released.
- 4.3 Connect the potentiometer case to ground (PE).
- 4.4. Replace defective fuses only by the specified type.


5. Connecting instructions

- 5.1 Control cables must be screened. Connect screen at one side of the controller with PE.
- 5.2 The control electronics carries mains potential when using armature voltage feedback with IxR compensation.
- 5.3 Before switching off the mains, the motor must have come to standstill by opening the switch RFR or actuating the quick stop.
For automatic mains switch-off, see 9, terminal 46.
- 5.4 Two-quadrant operation. If only one motor direction is required, e.g. clockwise rotation, terminal E of the set value potentiometer is to be connected to terminal 9 or (in case of anticlockwise rotation to terminal 7) and terminal A to terminal 10. See chapter 3 connecting diagram.
- 5.5 Four-quadrant operation. If both motor directions are required, terminal A of the set value potentiometer is to be connected to terminal 7 and terminal E to terminal 9. See chapter 3 connecting diagram. Zero speed results, when the set value potentiometer n_{sol1} (n_{set}) is in the middle position.
- 5.6 Separate supply of power stage and control electronics.
Caution: In case of separate supply of power stage and control electronics, ensure a correct phase connection between power stage and control electronics.
 - 5.6.1 Switch on control electronics and power stage at the same time (standard application).
 - 5.6.2 When switching on control electronics and then power stage, note:
Caution: As long as the power stage is without current the control inhibit must be active, see chapter 8.4 inching.

- 5.7 When connecting, check for the clockwise rotating field. In case of an anticlockwise rotating field the wrong phase sequence is displayed by lighting of the LED SEQ, the firing pulses are inhibited.
- 5.8 Capacity of the +Vcc supply. For a supply of external option boards, a total output current of 50mA is available.


6. Special field voltages

6.1 Field voltage $U_F = 0.9 \times U_{L1, L2 (N)}$



F5 for the protection against earth fault


6.2 Field supply by autotransformer



F5 for protection against earth fault

For T1 an isolation transformer can be used. See chapter 6.3.

6.3 Nominal mains voltage < 340V, 3L



With a mains voltage of less than 380V, the control electronics must be supplied separately or by transformer as shown in the drawing. The wire bridges BR1, BR2, BR3 and BR4 on the boards 4092 or 4093 must be removed.

Caution: Ensure by all means correct phase connection. Incorrect connection results in fuse failure.

6.4 Please contact the factory, if your mains voltage is higher than 415V.

7. Setting instructions

7.1 Turn trimmer n_{\max} , V_p , I_{xR} fully anticlockwise. The trimmers U_{leit} and n_{fein} are factory set for a standard set value potentiometer connection. Only when operating with a master voltage, U_{leit} must be turned fully anticlockwise and n_{fein} to middle position in order to enable subsequently a basic setting. The trimmer I_{\max} is factory set to nominal controller current.

7.2 Setting of the current limit

This setting is only necessary when the motor current is lower than the nominal controller current.

Turn trimmer I_{\max} fully anticlockwise.

Connect a moving coil instrument in order to measure the current to the armature cable; observe the polarity.

For positive set value the polarity at the motor terminal A is (+) and at terminal B (-).

For negative set value the polarity at the motor terminal A is (-) and at terminal B (+).

Block armature or disconnect when without voltage.

For armature voltage control disconnect cable to terminal 1.

Caution: Observe current capacity of the motor when at standstill!

Switch on the mains supply. LED $\pm V_{cc}$ and RSP light up. Close switch RFR. LED RSP is not lit anymore.

Set speed setting potentiometer fully clockwise or set master voltage to nominal value. LED I_{\max} lights up. Turn I_{\max} clockwise, until the desired armature current flows. The permissible output current of the controller must not be exceeded. See page 2, chapter 2, armature current.

Open switch RFR. Connect the field. Reconnect supply cable to terminal for armature voltage control.

7.3 Conditions for setting see chapters 7.3.1 and 7.3.2

Connect a moving iron instrument as voltmeter to terminals A and B of the motor. When setting the speed, ensure that the armature voltage does not exceed the permissible value of $U_{A\max} = 400V$.

7.3.1 Armature voltage control with I_{xR} compensation

Connect terminal A of the motor to terminal 1 of the controller and terminal B of the motor to terminal 2 as shown in the connecting diagram. Set the set value potentiometer or master voltage to 0V. Open switch RFR. Switch on mains. LEDs RSP and $\pm V_{cc}$ are lit. Set the set value potentiometer or master voltage to maximum. For master voltage operation turn trimmer U_{leit} clockwise until +10 VDC are applied at the measuring point M1 (measured to terminal 3). Set the set value potentiometer or master voltage to approx. 10% of the final value. Close switch RFR. LED RSP is not lit.

Caution: If the drive accelerates in an uncontrolled way, open switch RFR immediately.

Terminals I and K of the field or armature voltage feedback are interchanged. After having checked and corrected the wiring, the commissioning can start again.

When the speed is stable, the desired maximum speed can be set. Set the set value potentiometer or master voltage to maximum. Turn trimmer n_{max} clockwise, until the desired maximum speed is obtained. Trimmer n_{fein} is used for the fine setting of the maximum speed.

Turn trimmer V_p clockwise, until the drive becomes instable (speed oscillations), then turn trimmer V_p back by approx. 20%, until the drive is stable again. Using trimmer I_{xR} the speed is stabilized such that a minimum change results for the smallest speed between idle running and nominal load. Subsequently, the compensation of higher speeds must be checked.

7.3.2 Speed control using tacho feedback

For tacho feedback the trimmer I_{xR} must be set fully anticlockwise. Set the set value potentiometer or master voltage to 0V. Open switch RFR. Switch on mains. LED RSP and $\pm V_{cc}$ are lit. Set the set value potentiometer or master voltage to maximum. For master voltage operation, turn U_{leit} clockwise, until +10VDC are applied at the measuring point M1. Then set the set value potentiometer or master voltage to approx. 10% of the final value. Close switch RFR. LED RSP is not lit anymore.

Caution: If the drive accelerates in an uncontrolled way, open switch RFR immediately.

Terminals I and K of the field or armature voltage feedback are interchanged. After having checked and corrected the wiring, the commissioning can be start again.

When the speed is stable, the desired maximum speed can be set. Set the set value potentiometer or master voltage to maximum. Turn trimmer n_{max} clockwise, until the desired maximum speed is obtained. Trimmer n_{fein} is used for the fine setting of the maximum speed. Turn trimmer V_p clockwise, until the drive becomes unstable (speed oscillations), then turn trimmer V_p back by approx. 5%, until the drive is stable again.

For special applications (improved speed control behaviour for exacter control pathes, speed control without overshoot), a differential component can be installed. This should only be done together with tachogenerators which have an output voltage with very low ripple (KTD3 or TDP02).

Approximate values for the differential component: resistance 10kΩ, R101 capacitor 10μF or two electrolytic capacitors 22μF antiserial C102.

Caution: Ensure that the components mentioned above have suitable voltage values.

7.4 Trimmer n_{offs}


The offset of the trimmer is factory set; however, if a correction should be required, zero can be adjusted at the trimmer n_{offs} for set value provision.

8. Switching operation

8.1 Quick stop

When the switch quick stop is closed, the drive is decelerated to standstill with the nominal current. (Set value is set to zero.)

Quick stop




Use low current contact (15V/1.5mA)

See chapter 9, terminal 46 for mains switching off with standstill logic

8.2 Controller release

When switch RFR is closed, the controller is released. When switch controller release is open, the controller is inhibited. The firing pulses are set to the inverted limit position.




Use low current contact (15V/1.5 mA)

Caution: The controller must be released only at motor standstill.

8.3 Controller inhibit

The previously used function RSP (inhibiting the controller using a normally open contact) is still available.

When the switch controller inhibit is closed, the firing pulses are set to the inverted limit position.




Use low current contact
(15V/1.5 mA)

Caution: The switch RSP must only be opened at motor standstill.

8.4 Inching

The wire bridges BR1, BR2 and BR3 on the boards 4092 or 4093 must be removed.




Configuration of mains contactors

Caution:
When inching with K1 the electronic supply is still maintained. The mains is completely separated by a mains switch.


Application proposal for fast inching

Inching is done via S4 (switch).

The switching using quick stop causes fast deceleration in the inverter mode.



REL/TRP-15
part no. 321 351



- BR braking time of the drive
- S1 drive off
- S2 drive on
- K4, K5 relay with gold-plated contacts
- S3 1 inching
 2 automatic
- S4 inching

9. Connecting terminals

- 1 Input for armature voltage control using IxR compensation (motor terminal A), see 7.3.1.
- 2 Input for armature voltage control using IxR compensation (motor terminal B), see 7.3.1

For tacho operation with $U_{TN} > 45V$ terminal 2 instead of terminal 4 can be used in order to obtain a better resolution of the n_{max} trimmer. C 101 must be removed in this case.

- 3 GND, controller reference point
- 4 Input for actual speed value with nominal tacho voltages from 10 to 180V. For high nominal tacho voltages ($\geq 60V$) the setting sensitivity of the n_{max} trimmer, which is used as an attenuator, can be reduced by soldering a series resistor R 101 instead of the normally used wire bridge. C 101 must be removed in this case.

The resistance of R 102 can be determined according to the following equation:

$$R\ 102 = \left(\frac{U_{TN}}{10V} - 1 \right) 30\ k\Omega$$


See also terminal 2.

Note:

The position R 101 appears on the control boards 4091.2 (see red label on latest design). For older boards with the designation 4091.1 (see red label) this resistor is named R 102.

- | | |
|----|--|
| 7 | -Vcc = -15V = stabilized. Maximum external load is 50 mA |
| 8 | Input for actual speed value or master voltage from ± 10 to ± 180 V. |
| 9 | +Vcc = +15V = stabilized. Maximum external load is 50 mA |
| 10 | GND, controller reference point |
| 16 | controller release, see chapter 8 |
| 17 | controller inhibit, see chapter 8 |
| 19 | transistor output fault indication |

In the controllers 495 and 496 the temperature of the power semiconductors is supervised by a temperature sensor. If the heat sink exceeds the limit temperature $\vartheta_{\text{limit}} = 90^\circ\text{C}$, the controller inhibit RSP is activated inside the controller and the firing pulses are set to the inverter limit position, i.e. the motor is without current and idles. An electrical latching system prevents an automatic switch-on even after the controller has cooled (The self-holding circuit can only be released by switching the mains off and on again!) At terminal 19 $U \leq 0.6\text{V}$ are applied. The output can be loaded with maximum $R_{\text{min}} = 600\Omega$ and is suitable for the direct connection of a relay.



Relay: e.g. REL/TRP-15
part no. 321 351

For applications, where the motor must not automatically be without current after having exceeded the maximum cooling temperature of the motor, the resistor R 311 (on soldering posts) must be removed. In case of a controller fault only a fault indication is displayed.


Caution: The cause of the fault must always be removed as soon as possible, otherwise the operating safety of the controller is not maintained anymore.

20 quick stop, see chapter 8

31 output armature current signal

The output terminal **31** supplies a signal proportional to the armature current. (U_{31}) = 5V corresponds approximately to the nominal current of the controller and can be used for the direct current display with a measuring instrument.

The maximum load of terminal **31** is 10mA.



33 GND


38 Speed controller input

Terminal **38** leads to the summation point of the speed controller via $R_i \approx 50 \text{ k}\Omega$. The permissible input voltage range is between +10V and -10V. When switching the controller inhibit the input is switched to zero. In this case $R_i \approx 25 \text{ k}\Omega$. For positive set value or positive master voltage and negative actual value a positive armature voltage is applied at terminal A.

39 GND, controller reference point

40 input, current control, $R_i \approx 10 \text{ k}\Omega$

44 output speed controller, $R_i \approx 200 \Omega$. The terminals **40** and **44** are connected internally via the resistor R 705 on soldering posts. For current ratio control or connection of an external current potentiometer this resistor must be removed. The desired maximum armature current is set using the internal trimmer I_{\max} with fully open external current potentiometer.



Current set value 10 k/1 W lin
Remove R 705

10.2 LED RSP

RSP is lit when:

- switch is open, controller release, see 8
- switch is closed, controller inhibit, see 8
- excessive temperature of the heatsink (for 495 and 496)
- bridge changeover
- phase failure.

When RSP is lit, the firing pulses are in the inverter limit position.

10.3 LED I_{\max}

I_{\max} is lit when the speed controller is operating at its limit.

10.4 LED SEQ

SEQ is lit when the rotating field is incorrect (CCW rotation) and the firing pulses are suppressed.


11. Additional soldering posts

* no standard element

C 107*	integral component of the speed controller
C 102, R 101	actual speed value (differential component), standard wire bridge
R 103	No n_{offs} when the 1.5m Ω resistor is removed
R 207	} for option board
R 209	
R 305	
R 309	quick stop for option boards SWI, standard 24K3 Ω
R 310	When actuating the quick stop, the integral component of the speed controller is inhibited
R 311	Hysteresis of the direction sensor, standard 100 Ω
R 621	When removing R 311 only fault indication at terminal 19 without controller inhibit
R 705	Amplification for I control, standard 39 k Ω
R 719	Speed controller output for external I_{\max} potentiometer
V 714	Adaptation of the current controller, standard 3K3 Ω
	For fully compensated motors it may be necessary to increase the resistance in order to stabilize the current controller
	n_0 indication with $I_A = 0$ indication


12. Dimensions

12.1 Controller



Type	a		b		c		d		e	
	mm	in.	mm	in.	mm	in.	mm	in.	mm	in.
492	240	9.4	280	11	224	8.8	260	10.2	165	6.5
493	285	11.2	280	11	271	10.6	260	10.2	200	7.8
494	285	11.2	280	11	271	10.6	260	10.2	200	7.8
495	285	11.2	430	16.9	271	10.6	310	12.2	200	7.8
496	285	11.2	430	16.9	271	10.6	310	12.2	200	7.8

12.2 Mains choke



Type	part no	L	I	a		b		c		d		e	
				mm	in.	mm	in.	mm	in.	mm	in.	mm	in.
492 L _K	322 149	3x1.2 mH	3x17 A	120	4.7	66	2.6	110	4.3	53	2.1	162	6.3
493 L _K	322 148	3x1.1 mH	3x25 A	150	5.9	75	3.0	140	5.5	60	2.8	180	7.0
494 L _K	307 343	3x750 μH	3x45 A	180	7.0	85	3.3	163	6.4	69	2.7	218	8.5
495 L _K	307 346	3x270 μH	3x105A	228	9.0	107	4.2	207	8.1	91	3.6	273	10.7
496 L _K	308 234	3x165 μH	3x170A	264	10.4	128	5.0	240	9.4	104	4.0	260	10.2

L_K = commutating choke
(mains choke)

12.3 Power losses

Series

	492	493	494	495	496
Pv/W current controller	60	108	185	288	577
Pv/W mains and armature fuse	18	33	63	112	140
Pv/W mains choke	30	55	80	130	170

13. Items supplied

Installed field and electronic fuses,
set value potentiometer 10 kΩ

You must order separately: mains choke
knob and scale for set value
potentiometer, mains fuses,
armature fuse and fuse holder

Lenze

in aller Welt
worldwide



Head Office / Mechanical Drives

Lenze GmbH & Co KG Extertal
Postfach 12 50, D-32696 Extertal
Sitz: Bösingfeld, Breslauer Straße 3
D-32699 Extertal
☎ (0 52 62) 4 01-0, Telex 9 31 526
Teletex 52 62 810
Telefax (0 52 62) 40 15 10

Head Office / Electronic Drives

Lenze GmbH & Co KG Aerzen
Postfach 10 13 52, D-31763 Hameln
Sitz: Groß Berkel, Hans-Lenze-Straße 1
D-31855 Aerzen
☎ (0 51 54) 82-0, Telex 9 2 853
Teletex 51 54 11, Telefax (0 51 54) 40 40

Augsburg

Lenze GmbH & Co KG
Vertriebsbüro Augsburg
Elmayer Weg 11 F
D-86163 Augsburg
☎ (08 21) 66 36
Telefax (08 21) 6 44 00

Bad Nenndorf

Lenze GmbH & Co KG
Antriebstechnik Nordwest
Niederlassung Bad Nenndorf
Im Niedernfeld 1 3
D-31542 Bad Nenndorf
☎ (0 57 23) 20 17-19
Telefax (0 57 23) 68 08

Berlin

Lenze Antriebstechnik
Vertriebsbüro Berlin
Straße der Solidarität 9
D-16727 Velten
☎ (0 33 04) 3 11 23 (ab Anfang Sept. 93)

Bremen

Lenze GmbH & Co KG
Antriebstechnik Nordwest
Vertriebsbüro Bremen
Ahiker Dorfstraße 11 d
D-28279 Bremen
☎ (04 21) 82 67 13
Telefax (04 21) 82 68 13

Döbeln

Lenze GmbH & Co KG
Antriebstechnik Döbeln
Großbauchlitz, Grimmaische Straße 78
D-04720 Döbeln
☎ (0 34 31) 23 04 - 05
Telefax (0 34 31) 4 11 41

Hamburg

Lenze GmbH & Co KG
Antriebstechnik Nordwest
Niederlassung Hamburg
Stormarnring 20, D-22145 Stapelfeld
☎ (0 40) 6 77 70 59
Telefax (0 40) 6 77 80 86

Herborn

Lenze GmbH & Co KG
Antriebstechnik Mitte
Niederlassung Herborn
Postfach 14 63, D-35724 Herborn
Sitz: Westewaldstraße 36
D-35745 Herborn
☎ (0 27 72) 5 30 75-8
Telefax (0 27 72) 5 30 79

Karlsruhe

Lenze GmbH & Co KG
Antriebstechnik Süd
Niederlassung Karlsruhe
Saarlandstraße 85, D-76187 Karlsruhe
☎ (07 21) 9 56 85 0
Telefax (07 21) 55 70 46

Magdeburg

Lenze GmbH & Co KG
Antriebstechnik Nordwest
Vertriebsbüro Magdeburg
Hängelsbreite 20
D-39116 Magdeburg
☎ + Telefax (03 91) 60 42 56

Moers

Lenze GmbH & Co KG
Antriebstechnik West
Niederlassung Moers
Postfach 18 09, D-47408 Moers
Sitz: Uerdinger Str. 48, D-47441 Moers
☎ (0 28 41) 2 39 06
Telefax (0 28 41) 1 83 42

München

Lenze GmbH & Co KG
Antriebstechnik Süd
Niederlassung München
Erlenstraße 1, D-82166 Lochham
☎ (0 89) 8 54 40 10
Telefax (0 89) 8 54 41 98

Nürnberg

Lenze GmbH & Co KG
Antriebstechnik-Vertrieb Wendelstein
Niederlassung Nürnberg
Wendelsteiner Straße 2
D-90530 Wendelstein
☎ (0 91 29) 90 11 - 0
Telefax (0 91 29) 81 19

Rotthweil

Lenze GmbH & Co KG
Antriebstechnik Süd
Niederlassung Rotthweil
Zimmerner Straße 54-56
D-78628 Rotthweil
☎ (07 41) 85 20
Telefax (07 41) 4 29 01

Sömmerda

Lenze GmbH & Co KG
Antriebstechnik Döbeln
Vertriebsbüro Sömmerda
Rembrandtstraße 1
D-99610 Sömmerda
☎ (0 36 34) 2 15 21

Stadtbergen

Lenze Antriebstechnik
Vertriebsbüro Stadtbergen
Mohnweg 13
D-86391 Stadtbergen
☎ (08 21) 43 10 43
Telefax (08 21) 43 10 41

Teterow

Lenze GmbH & Co KG
Antriebstechnik Nordwest
Vertriebsbüro Teterow
Am Rhedebruch 11
D-17166 Teterow
☎ (0 39 96) 75 12
Telefax (0 39 96) 75 13

Waiblingen

Lenze GmbH & Co KG
Antriebstechnik Süd
Niederlassung Waiblingen
Postfach 14 33, D-71304 Waiblingen
Sitz: Schänzle 8, D-71332 Waiblingen
☎ (0 71 51) 5 90 24
Telefax (0 71 51) 5 73 41

Walldorf

Lenze Antriebstechnik
Vertriebsbüro Walldorf
Eichendorffstraße 7
D-69190 Walldorf
☎ (0 62 27) 6 44 50
Telefax (0 62 27) 6 45 59

Argentina

Mocbos S. A.
Mom 3099
RA-1437 Buenos Aires
☎ + Fax: (01) 922 2299 / 922 3684 /
922 2892 / 922 6818
Telex 17210 ANJOY AR

Australia

FCR Automation Pty. Ltd.
Automation Place
23 McArthur's Road
P.O. Box 359, Altona North
AUS-3025 Melbourne, Australia
☎ (03) 3 99 15 11
Telefax (03) 3 99 14 31

Austria

Lenze Antriebstechnik Ges.m.b.H.
Postfach 21, Mühlenstraße 3
A-4470 Enns
☎ (0 72 23) 34 21-0
Telefax (0 72 23) 229 166
Telefax (0 72 23) 32 80

Belgium

Lenze b.v.b.a.
Noorderlaan 133, bus 15
B-2030 Antwerpen
☎ (03) 5 42 62 00
Telefax (03) 5 41 37 54

Bosnia-Herzegovina

see Austria

Bulgaria

see Austria

Canada

see USA

Chile

Mocbos Chile S.A.
Cienfuegos 161
RCH-Santiago Centro / Chile
☎ (02) 6 97 27 73
Telefax (02) 6 97 27 75

Croatia

see Austria

Czech Republic

Lenze Antriebstechnik GmbH,
informační a poradenské středisko
ul. 17. listopadu 510
CR-549 41 Červený Kostelec
☎ (04 41) 63 12 49
Telefax (04 41) 63 12 48

Denmark

Leomotor A/S
Ingenior- & Handelsfirma
Stubbøllevvej 35-37
Postbox 438
DK-2450 København SV
☎ 36 30 66 66
Telex 19 166
Telefax 36 30 64 33

Leomotor A/S
Enebrvej 11
DK-8653 Them
☎ 86 84 75 33
Telefax 86 84 83 53

Finland

Refimex Oy
P.O. Box 35
SF-02271 Espoo
Hannuksentie 1
SF-02270 Espoo
☎ (0) 80 48 61
Telex 125 252, Telefax (0) 88 09 41

France

Lenze S.A.
Z.A. de Chanteloup
Rue Albert Einstein
F-93603 Aulnay s/s Bois Cedex
☎ (1) 48.79.62.00
Telefax (1) 48.69.40.99

Succ. Rhône-Alpes:
42, Chemin des Pivoles
F-69150 Décines-Charpieu
☎ 72.15.40.20
Telefax 78.26.88.36

Agence Sud-Ouest:
B.P. 67
20 Rue Alsace Lorraine / Pujolles
F-47300 Villeneuve sur Lot
☎ 53.40.20.97
Telefax 53.40.21.04

Great Britain / Northern Ireland

Simplatro Ltd.
Caxton Road
GB-Bedford MK 41 OHT
☎ (02 34) 35 00 44
Telefax (02 34) 26 18 15

Greece

Georg P. Alexandris AG
K. Mavromichali Str. 12
P.O. Box 86 009
GR-185,03 Piräus
☎ (1) 4 11 18 41, Telex 212 796
Telefax (1) 4 12 70 58
Monastiriou Str. 153
GR-546,27 Thessaloniki
☎ (31) 52 75 21-2, Telex 418 300
Telefax (31) 51 18 15

Hong Kong

Laden Trading Company Ltd.
Room 1134-5 Nan Fung Centre
246-298 Castle Peak Road
HK Tsuen Wan, Kowloon
Hong Kong
☎ (0) 4 99 29 23
Telex 36 863 laden hx
Telefax (0) 4 11 40 27

Hungary

Lenze Antriebstechnik GmbH.
Szerviz és Információs Iroda
Bognár u. 3/B II.3
H-1021 Budapest
☎ + Telefax 176 - 04 96

Iceland

see Denmark

India

Emco Dynatorq Transmissions Pvt. Ltd.
106, Industrial Area, Sion
IND-Bombay 400 022
☎ (22) 40 76 371, (22) 40 71 816,
(22) 40 76 432
Telex 011-76010 EEPL IN
011-73077 DYNA IN
Telefax (022) 409 04 23
Cab e EMCOTROLL

Indonesia

P.T. Temasindo Prakarsa
Jl. Hariangbanga 5
Bandung 40116 Indonesia
☎ 0 22 - 43 11 81, 43 00 35
Telefax 0 22 - 43 11 18

Iran

Pars Textile Co. Ltd.,
Ayatollah Sadr Highway, Dastour Jonobi
Habibi Alley, No. 44
P.O.Box 19395-5177
IR-Tehran 19396
☎ (021) 266 766
Telefax (021) 200 288 3
Telex 2 24 332 pate r

Israel

Greenshpon Eng., Works Ltd.
20 Haamelim St
P.O. Box 10 108
IL-Haifa-Bay 26110
☎ (04) 72 11 87
Telex green 45 108
Telefax (04) 72 62 31

Italy

Gerit Trasmissioni S.p.A.
Viale Monza 338
I-20128 Milano
☎ (02) 26 00 04 56
Telex 320 017 gerit i
Telefax (02) 2 55 29 70

Japan

Miki Pulley Co. Ltd.
461 Imai-Minami-Cho, Nakahara-Ku
J-Kawasaki-City
☎ (0 44) 7 33 - 51 51, Telex 03 842 110
Telefax (0 44) 7 11 24 31, 7 33 12 41

Korea

In Kok Industrial Co. Ltd.
Room No. 101
Solpyo Choseon Mooyack Bldg.
339 1, Dae Bang Dong
Dong Jack-Gu
C.P.O. Box 37 21
ROK-Seoul/Korea
☎ (02) 8 16 - 06 52-5
Telex K 26 919 Inkoktd
Telefax (02) 8 16 - 50 16

Kuwait

Ammar & Partners Electrical Co.
P.O. Box 1871, Safat
KWT-Kuwait
☎ 83 01 22
Telex 44 486 a/b APPECO

Luxembourg

see Belgium

Macedonia

see Austria

Malaysia/Asean

see Singapore

Mexico

see USA

Netherlands

Lenze B.V.
Postbus 31 01
NL-5203 DC 's-Hertogenbosch
Ploegweg 15
NL-5232 BR 's-Hertogenbosch
☎ (0 73) 41 00 96
Telefax (0 73) 41 15 45

Norway

DtC-Lenze A/S
Elveveien 26-28
N-1472 Fjellhamar
☎ (0 67) 97 19 50
Telefax (0 67) 97 20 25

Republic South Africa

Integrated Machines (Pty.) Ltd.
P.O. Box 52 33, ZA-Benoni-South 1502
22 Ba four Ave.
ZA-Benoni-South 1501 Ext. 7
Industrial Sites
☎ (011) 845 - 19 15; 845 - 19 22
Te fax (011) 845 - 19 26

Romania

see Austria

Singapore/Asean

Asia-Mech Engineering Pte Ltd.
10 Tuas Avenue 1
SGP-Singapore 2263
☎ 86 22 511, 86 22 051
Telex asiamec 34 883
Telefax 8 61 07 67

Slovak Republic

see Czech Republic

Slovenia

see Austria

Spain

S.A. Sistel
Santanac, 25
E-08206 Sabadell (Barcelona)
☎ (93) 7 27 00 74
Telefax (93) 7 25 35 76

Sweden

Lenze Transmissioner AB
Box 10 74
S-58110 Linköping
☎ (0 13) 11 14 70
Telex 50 033 Te efax (013) 10 36 23

Switzerland

Lenze Bachofen AG
Ackerstraße 42, Postfach
CH-8610 Uster Zurich
☎ (01) 9 44 12 12
Telex 826 107, Telefax (01) 9 44 12 33

Bureau de Suisse Romande:
Lenze Bachofen S.A.
Grands Champs 4
CH-1033 Cheseaux s.L.
☎ (0 21) 7 31 02 12
Telefax (0 21) 7 31 07 17

Taiwan

ACE Pillar Trading Co. Ltd.
No.12, Lane 61, Sec 1 Kuanfu Road
San-Chung-City
R.O.C. Taipei HSIEN
☎ (02) 9 95 - 84 00
Te fax (02) 9 95 - 34 66

Thailand

Weinmann & Schneider Co. Ltd.
G.P.O. Box 845
T-Bangkok 10501
☎ (2) 3 94 33 22
Telex 87 973 aluon th
Telefax (2) 3 84 04 47

USA

Lenze Power Transmission
175 Route 46 West
USA-Fairfield NJ 07004
☎ (2 01) 2 27 - 53 11
Telefax (2 01) 2 27 - 74 23

Venezuela

Text tec Breznik S.R.L.
Calle Maracay Qta. Myriam E. Marqués
YV-Caracas
☎ + Fax (02) 34.09.52
Ofic. Charal ave
☎ (0 39) 98.04.95
Te fax (0 39) 97.131

Yugoslavia

see Austria

