
## **OPERATING MANUAL**

# 9 Stage Profile Controller PRC-1202





## **Technical Specification**

| Model          | PRC-1202                                     |
|----------------|--|
| Display        | UPPER:- 4 Digit 7 seg 0.56",red LED Display  |
|                | LOWER:- 4 Digit 7 seg 0.4",green LED Display |
| Size           | 96(H) X 96 (W) X 100 (D) mm                  |
| Panel Cutout   | 92 X 92 mm                                   |
| Range          | 0 to 1200°C                                  |
| Input          | K Type thermocouple                          |
| Output         | 2 Relay, 5A, 230V AC Relay contact           |
| Control Action | ON/OFF                                       |
| Power Supply   | 100 to 250V AC,50/60Hz,Approx 4VA            |


#### Working

- 1). Make all connection as shown in connection diagram and turn on the instrument.
- 2). As the Power turns ON, Upper Display Shows Room Temperature / Process Temperature. Lower Display shows of rate of temperature.
- 3). Relay-R1 is for controlling the temperature and relay-2 is for alarm.
- 4). When process temperature reach at set1 value during that period RELAY 1 will turn off and hold time for that relay1 starts. Again when it reaches 5EŁ-HY5, it will again Relay turn on.
- 5). Alarm will (relay-R2) turn ON at alarm set point.
- 6). When hold-1 time is over, stage-2 process starts and process temperature increase @ rate of RATE-2. This 9-stage process continues as process temperature varies.
- 7). By pressing both 🔗 & 💟 keys one can see on the lower display which particular rate or which particular hold time is going on.


#### **Key Operations**

- 1) Press Key to enter in parameter menu.
- 2) Press (SET) Key to go to next parameter.
- 3) Use Or Wkey to change value of parameter.
- 4) Press (ENT) Key to save change in setting


## **Procedure of stage selection**



# **User Configuration**



# **Connection Diagram**



Product improvement and upgrade is a constant procedure. So for more updated operating information and support, Please contact our Helpline: +91-9978991474/76/82 or Email at service@multispanindia.com Ver:2008