

BT651000 • EAN 4042146780923

8-pcs. Strut nut kit

Kit utensili ammortizzatori | 8 pz.

Fjederbens-værktøjsæt, 8 dele

Audi / Seat / Skoda
Volkswagen / Mercedes



1/2"



BT651050 • EAN 4042146780916

39-pcs. Strut/shock installation tool kit

Set utensili ammortizzatore | 39 pz.

Støddæmper-værktøjsæt, 39 dele



VAG / Mercedes / Austin



	14 • 16 • 17 • 18 • 19 • 21 • 22 • 24 • 27 mm
	4 • 5,2 • 6 • 6,3 • 7 • 8 • 9 • 10 • 12 mm
	3 • 3,5 • 4 mm
	T50 • T60
	M12
	D5 • D10
	5 • 6 • 7 • 8 mm
	8 • 9 • 10 • 11 mm
	10,5 • 12,5 • 14 • 14,5 • 14,5 mm

BT651100 • EAN 4042146780930

8-pcs. Macpherson strut expander tool set

Utensile di montaggio per ammortizzatori con molla | 8 pz.

Monteringsværktøj til støddæmpere med trækanslagsfjeder, 8 dele



BT651150 • EAN 4042146780947

8-pcs. Strut coil clamp spring compressor set, Universal

Kit tenditore | 8 pz.

Fjederspændersæt, 8 dele



**McPherson: BMW, Toyota,
Ford, Opel, VW, Audi, Saab,
Nissan, Honda, Subaru, Volvo,
Mitsubishi**

BT651200 • EAN 4042146780954

Strut coil clamp spring compressor set, 7-pcs. plastic protective, universal

Kit tenditore | 7 pz. | con inserto protettivo in plastica

Fjederspændersæt, 7 dele, med plastbeskyttelsesindlæg

7
pcs/
pz./dele



McPherson: BMW, Toyota, Ford, Opel, VW, Audi, Saab, Nissan, Honda, Subaru, Volvo, Mitsubishi



BT651250 • EAN 4042146780961

Shock absorber remover/installer kit, 18-pcs.

Set utensili ammortizzatore | 18 pz.

Støddæmper-værktøjssæt, 18 dele

18
pcs/
pz./dele

1/2"



		16 • 17 • 18 • 19 • 21 • 22 • 24 mm
		5 x 8 • 6 x 8 • 7,1 x 9,6 mm
		T50
		6 • 7 • 8 mm
		7 • 8 • 9 mm
		250 mm

