

M 15 Epoxy Product Packing



945ml part A/B



3.7L part A/B

M 15 Epoxy is a “15-Minute” epoxy filler

REPAIRS ABOVE OR BELOW WATER

Longer pot life version of M 5.

M 15 Epoxy is based on a unique blend of liquid epoxy polymer and proprietary curing agents, which is able to displace water from wet surfaces in order to make a permanent bond. The formulation is solvent-free to ensure safety and maximum technical performance. Kevlar®* fibers are incorporated for reinforcement and viscosity management to assure reliable application even under adverse conditions.

M 15 Epoxy is supplied in a standard white base, which is mixed with an equal volume of haze grey curing agent to yield a lighter grey when thoroughly mixed. The formula is uniquely field-friendly using advanced low toxicity ingredients and can be shipped airfreight “Non-Regulated” by USDOT, IATA and IMO.

* Kevlar is a trademark of E. I. DuPont de Nemours Co.

Recommended Uses:

REPAIR COMPOUND:

Patching, leak sealing etc. under all conditions.

ADHESIVE:

Excellent all-purpose adhesive for use above and below water.

Product	Part A	Part B	Mixed Colour
M 15 Epoxy	White	Haze Grey	Light Grey

Technical Information:

VEHICLE TYPE : Epoxy/proprietary

PIGMENTATION : Colour/Inert/fibrous reinforcement

COLORS : Light grey

FINISH : Slight texture

THINNER : Not normally required

CLEANER : MEK or lacquer thinner

MIXING RATIO : 1.0/1.0 v/v

INDUCTION TIME : Not required

POT LIFE : Approx. 10' / 25°C

FLASH POINT : Over 94°C

SOLIDS BY VOLUME : 100%

SPREADING RATE/GAL : 39.4 mil/sq. m²./L

DRY TIME, (Dust free) : 15 mins. at 25°C

DRY TIME, (Service) : 20 – 30 mins. Light duty

APPLICATION METHOD : Spatula

STORAGE CONDITIONS : Normal, Freezing OK

VOC : Essentially zero

Initial Preparation:

Before beginning to mix the **M 15 Epoxy** components, make a mental “run-through” of the job and prepare as much as possible beforehand. A pot life of 10 minutes gives ample time to take care of most situations but time quickly runs out if tools have to be found or valves turned off during a job.

Surface Preparation:

Scrape or remove all loose contamination around the immediate repair site. Abrade the area using coarse abrasive paper or a mechanical grinder to provide a firm anchor for the repair material.

Mixing Procedure:

M 15 Epoxy is supplied in equal volumes of white epoxy base and grey curing agent. Remove equal quantities of base and curing agent from their cans and place them side-by-side on a surface of plastic, fibreboard etc. Mixing is easily accomplished by folding the components into each other using a spatula. Once mixing begins there will be about 10 minutes of working time available at 27°C, mixing will consume not more than 1 minute of this time. When mixing is complete the product will be a uniform Light Grey colour with no streaks of unmixed white or darker grey components. Pot life will be extended underwater by immediately immersing the mixed materials.

Application:

- 1) **UNDER WATER:** Take the mixed **M 15 Epoxy** underwater in a can or bucket. It will free up a hand to have a hook on a belt to hold the can during application. Applicators such as broad putty knives or plastic straight-edged glue spreaders work well on most surfaces. Industrial latex gloves work well on small-diameter tubular sections such as risers. **M 15 Epoxy** is resistant to the effects of wave application during curing and will be found to be easier to apply than traditional "splash-zone" compositions and much less messy than lower viscosity underwater "paints". **M 15 Epoxy** has a strong tendency to stick to underwater surfaces so expensive equipment should be protected using plastic suits or sacks to cover exposed surfaces. If MAC tape is to be wrapped onto the repair, several layers are recommended for strong repairs.
- 2) **ABOVE WATER:** Use as a regular adhesive by mixing the quantity desired and applying to clean surfaces until set in 10 – 15 minutes. When used with MAC tape for leak sealing, apply the tape to the repair area down and wrap it around holding firm pressure on the free end. Overlap previous wraps by at least 1/2" in a spiral fashion and avoid wrinkles. At least three (4) wraps are recommended for excellent strength around a pipe repair.

WE URGE YOU TO READ THE SAFETY DATA SHEET (SDS) BEFORE USING AND TO CALL METALOK360, AS NECESSARY FOR ADVICE OR INFORMATION BEFORE ANY ACTUAL OR CONTEMPLATED APPLICATION.

METALOK360
Unit 105, 9-3151 Lakeshore Road, Kelowna, British Columbia, Canada, V1W 3S9
Tel: +1 236 795 3794 / WhatsApp: +6016 296 3710
Email: info@metalok360.com

SAFETY: This is a hazardous material if misused. Read and understand the Safety Data Sheet (SDS) before use.

WARRANTY DISCLAIMER: The technical data given herein has been compiled for your help and guidance and is based on our experience and knowledge. However, as we have no control over the use to which this information is put, no warranty, express or implied, is intended or given. We assume no responsibility whatsoever for coverage, performance or damages, including injuries resulting from the use of this information or of products recommended herein.