

# CULMI CA BLACK SEAL ADHESIVE X 1L (24-CAN/BOX)



## The snap-on method



### Step 1

Use a sharp knife to slit open one side.



### Step 2

Wrap slit insulation over the pipe.



### Step 3

Apply adhesive on slit surfaces and prevent both side from touching while allowing adhesive to dry.



### Step 4

Remember always to test adhesive dryness before joining.



### Step 5

Continue to apply pressure to entire joint to assure full banding.



### Step 6

For double-layer work, apply adhesive at end joints.