

Low side sample hose should be attached to analyzer during calibration (See below image):



High side sample hose SHOULD NOT be attached to analyzer during calibration (see below image):

