

RESCUE AND FIRST AID

FIRST AID, PREVENTION AND SIGNALIZATION



Mod. SZ-56

Insulating shoes

A pair of overshoes made of insulating material to move around the accident area with insulation from the floor.
Up to 1000 V.

| Code | Ref. |
|--------|-------|
| 715110 | SZ-56 |

sofamel