



JP™ Titanium Putty



Application Procedure

1. Clean surface thoroughly by sandblasting to SA 2 ½ Swedish Standard or power brush surface to bare metal.
2. Decontaminate surface with thinner to ensure that it is free from dirt or oil.
3. Mix Base thoroughly. Once done, add in Hardener and continue mixing for 5 minutes.
*Mixing ratio: 800g Base + 200g Hardener (4:1)
4. Apply mixture to desired surface using a putty knife or finger with rubber gloves on.
5. Do **NOT** add thinner to JP™ Titanium Putty.
6. Touch Dry in 30 minutes depending on climate.
7. Profile to desired finishing and thickness after 3 hours of curing using lathe machine or flap disc.
8. Full Curing after 24 hours depending on climate.

Store in Cool Environment

“We thank you for choosing JP™, and we assure you our best services and quality at all times.”