



SUPER FIBRE R45

Fibreglass Tissue Mat

SUPER FIBRE R45 is a fiberglass tissue mat with added yarn reinforcement for higher strength. It is suitable to be used as a crack-bridging reinforcement with Dritech's Stucco range, Super Lastic range, or Dri-Floor range.

FEATURES/BENEFITS

- ✓ Suitable to be used with Dritech's range of repair, waterproofing or flooring systems
- ✓ Increases tensile strength
- ✓ Quick application
- ✓ Easily moulded around surface details
- ✓ Enhances crack bridging properties

APPLICATION AREAS

- ✓ Sports flooring system
- ✓ Acrylic flooring systems
- ✓ Challenging wall crack repairs
- ✓ Roofs with many details & complex geometries
- ✓ Total or partial waterproofing reinforcement
- ✓ New or refurbishment projects
- ✓ Repair of old waterproofing membranes



DRITECH CHEMICALS SDN. BHD. (1184082-K)

A-13-02, Atria SOFO Suite, Jalan SS22/23, Damansara Jaya, 47400, Petaling Jaya, Selangor, Malaysia.
TEL: +603 9212 8510, FAX: +603 9212 8519, WEB: www.dritechchemicals.com

Product Data

Appearances / Colors	White
Packaging	Approximately 1m x 200m
Storage Conditions	Stored properly in original, unopened and undamaged sealed packaging in dry conditions, flat and wrinkle-free

Technical Data

Origin	Fibreglass tissue mat
Density	45 g/m ²
Space between Yarns	Approximately 15 mm

APPLICATION

Detail work/embedment: When working on protrusions, up-stands, parapets or other fixtures and fittings which are not part of the main horizontal or vertical substrate, pre-cut required lengths of SUPER FIBRE R45. Apply coating to the area to be reinforced using a brush or roller. Immediately lay the precut lengths of SUPER FIBRE R45 reinforcement onto the wet coating and firmly embed.

Large area/embedment: Apply the coating at the correct coverage rate, working on 4 – 6 m² at a time. Lay SUPER FIBRE R45 onto the wet coating and firmly embed.

Prior to the application, the substrate must be prepared, and the priming coat must have cured tack free. For the waiting time/overcoating please refer to the chosen coating system PDS of the appropriate primer. First apply a sufficient quantity of the chosen coating system by roller/brush/spray to be able to thoroughly wet the SUPER FIBRE R45. Roll in the SUPER FIBRE R45 such that there are no bubbles or creases and apply the next layers of coating to achieve the required total film thickness. Please refer to the chosen coating system PDS for the total materials consumption required. Overlap SUPER FIBRE R45 by at least 50mm. At borders to other waterproofing membranes overlap by a minimum of 100mm.

HEALTH & SAFETY

For information and advice on the safe handling, storage and disposal of chemical products, users shall refer to the most recent Material Safety Data Sheet containing physical, ecological, toxicological and other safety-related data.

LEGAL NOTE

The information, and, in particular, the recommendations relating to the application and end-use of these products, are given in good faith based on current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance to the manufacturer recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the product must test the product's suitability for the intended application and purpose. The manufacturer reserves the right to change the properties of its products. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request.