

JOINT METHODS AND SPECIAL APPLICATION



1. Remove the rubber gasket from coupling, put the coupling onto the pipe body.



2. Put the rubber gasket onto the spigot of the pipe.



3. Insert the fittings spigot into the rubber gasket.



4. Slide the coupling onto the rubber gasket.



5. Tighten the bolt with screw-driver. Assembly complete.