

## 3 steps to change the code to a new set


1 → 2 →








3




## 3 steps to copy the code of a remote controller to another unit


1 →







3



Intelligent Network Sdn. Bhd. http://www.dcmoto.my