








Xe FAN-COIL THERMOSTAT

Installation Sheet




T6373A1108/T6373A1132/T6373A1215
T6373A1116/T6373A1207

220...240 V ~
N L




T6373B1130/T6373B1189
T6373B1148

220...240 V ~
N L




T6375B1153/T6375B1278

220...240 V ~
N L




T6375B1286

230 V ~
N L



T6373B1197

N L
230 V ~



Honeywell

No user serviceable parts. Do not dispose of in a fire.

Home and Building Control