

CULMI AIR-COND & REFRIGERATION PARTS SUPPLY SDN BHD

TIF 9055 Digital Programmable Charging Scale



A) Programming a Charge

1) Turn on unit by pressing "I/O" Key. The unit will "beep" once and after a brief segment display of all 8's, it will display zeros.

2) Select the unit of measure that you require by pressing the KG/LBS key.

3) Press the ◀ 0 ▶ (zero) Key

4) Place the refrigerant tank in the center of the platform. The gross weight will be displayed.

B) Programming a Normal Charge

5) Press the SET Key. The "Set" enunciator will flash.

6) Use the numeric keypad to enter the value. Entering always starts from the left most character. Blanks are not accepted, zeroes must be entered if a numeric value is not desired. Example : _ _ _ .500 (500 Grams)

7) When programming, is complete, press the SET Key again to lock in programmed value.

8) Press GO.

