ISSUE 1.0 SL2100

2.5.7 IP7WW-60D DSS-A

The DSS console gives a multiline terminal user a Busy Lamp Field (BLF) and one-button access to extensions, trunks and system features. Mainly designed for operator use, the 60-button DSS console provides an additional 60 programmable keys.

 Connect this console to extension port No. 8 at 308U/ 008U of each Chassis.

Programmable keys: 60Angle Adjustment: 2-stepsWall-Mounting kit: Built-in



2.5.8 IP4WW-WALL MOUNT UNIT

The Wall Mount Unit is used for IP7[]-8IPLD Terminal and IP4[]-24TIXH-C Terminal only.



2.5.9 DP-D-1A/1D/HS.D503DOR-A

This is the Doorphone Box.

- Connect to Hybrid/Analog extension port No. 6 or No. 7 on the 308U.
- · Wall-Mounting kit: Built-in



Hardware Manual 1-13