

# ACCESSORIES FOR POLES

## INSULATING POLES



### Mod. SM-02R

#### Metric-10 maneuvering hook

Code		Ref.
630100	Maneuvering hook with M-10 thread.	SM-02R



### Mod. SM-02C

#### Hexagonal-12 maneuvering hook

Code		Ref.
630110	Maneuvering hook with Hexagonal-12 head.	SM-02C



### Mod. SM-02K

#### Universal-K maneuvering hook

Code		Ref.
630120	Maneuvering hook with Universal-K head.	SM-02K



### Mod. ADAP. B-UK

#### Bayonet to Universal-K adapter

Code		Ref.
630107	Adapter from Bayonet to Universal-K head.	ADAP. B-UK



### Mod. ADAP. B-M10

#### Bayonet to M-10 adapter

Code		Ref.
630108	Adapter from Bayonet head to M-10 thread.	ADAP. B-M10



### Mod. ADAP. H12-M10

#### Hexagonal-12 to M-10 adapter

Code		Ref.
630101	Adapter from Hexagonal-12 head to M-10 thread.	ADAP. H12-M10



### Mod. GS-49

#### Rescue hook

Code		Ref.
630130	Rescue hook with M-10 thread.	GS-49

# ACCESSORIES FOR POLES

## INSULATING POLES



### Mod. GA-TML

#### Operating hook

Code		Ref.
<b>630116</b>	Operating hook for the high voltage overhead lines earthing equipments model PATL-TML.	<b>GA-TML</b>



### Mod. ADAP. UK-B

#### Universal-K to Bayonet adapter

Code		Ref.
<b>630162</b>	Adapter from Universal-K to Bayonet head.	<b>ADAP. UK-B</b>



### Mod. ADAP. UK-P

#### Universal-K to Polivalent adapter

Code		Ref.
<b>630163</b>	Adapter from Universal-K to Polivalent head.	<b>ADAP. UK-P</b>



### Mod. ADAP. H12-UK

#### Hexagonal-12 to Universal-K adapter

Code		Ref.
<b>630109</b>	Adapter from Hexagonal-12 to Universal-K head.	<b>ADAP. H12-UK</b>



### Mod. ADAP. M10-UK

#### M-10 to Universal-K adapter

Code		Ref.
<b>630106</b>	Adapter from M-10 thread to Universal-K head.	<b>ADAP. M10-UK</b>



### Mod. ADAP. UK-M10

#### Universal-K to M-10 adapter

Code		Ref.
<b>630102</b>	Adapter from Universal-K head to M-10 thread.	<b>ADAP. UK-M10</b>