ltems		Pre-ride Check ₽ P. 52	Frequency *1										
			× 1,000 km	1	6	12	18	24	30	36	Annual Check	Regular Replace	Refer to page
			× 1,000 mi	0.6	4	8	12	16	20	24			page
Fuel Line	1							1					-
Fuel Level													-
Throttle Operation	1	-											93
Air Cleaner *2	1						ß			0			63
Crankcase Breather *3					С	С	С	С	С	С			94
Spark Plug	×			Every 24,000 km (16,000 mi): Every 48,000 km (32,000 mi): <b>R</b>									-
Valve Clearance	1												-
Engine Oil				ß		ß		ß		ß	R		76
Engine Oil Filter				ß				ß					78
Engine Idle Speed	1												-
Radiator Coolant *4												3 Years	80
Cooling System	1												-
Secondary Air Supply System	*												-
Evaporative Emission Control System	*												-

## **Maintenance Level**

- Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled.
  - Procedures are provided in an official Honda Shop Manual.
- : Technical. In the interest of safety, have your motorcycle serviced by your dealer.

## Maintenance Legend

- II : Inspect (clean, adjust, lubricate, or replace, if necessary)
- C : Clean
- R : Replace
- L : Lubricate

ltems		Pre-ride Check ₽ P. 52	Frequency *1										
			× 1,000 km	1	6	12	18	24	30	36	Annual Check	Regular Replace	Refer to page
			× 1,000 mi	0.6	4	8	12	16	20	24			
Drive Chain		-	Every 1,000 km (600 mi): 📘 📘										86
Drive Chain Slider													89
Brake Fluid *4												2 Years	82
Brake Pads Wear													83
Brake System													52
Brakelight Switch													84
Headlight Aim													95
Lights/Horn													-
Engine Stop Switch													-
Clutch System													90
Side Stand													85
Suspension	1												-
Nuts, Bolts, Fasteners	1												-
Wheels/Tyres	×												60
Steering Head Bearings	Ж												-

## Notes:

\*1 : At higher odometer reading, repeat at the frequency interval established here.

\*2 : Service more frequently when riding in unusually wet or dusty areas.

\*3 : Service more frequently when riding in rain or at full throttle.

\*4 : Replacement requires mechanical skill.