Keysight Technologies E4990A Impedance Analyzer 20 Hz to 10/20/30/50/120 MHz

Configuration Guide





Ordering Guide

The following steps will guide you through configuring your E4990A.

Standard furnished item

Description	Additional information
Installation guide	Contains the information necessary to start up with the E4990A.
CD ROM IO libraries	
100 Ω resistor	100 Ω load resistor module for 4-terminal pair extension. See Available Accessories (General/Miscellaneous
	Measurement Accessories) for additional information.
Powercable	
Certificate of calibration	

Step 1. Choose frequency (Mandatory)

Frequency range	Option no.	Support fixtures	Support fixtures				
		4-terminal pair fixtures	42941A impedance probe	42942A + 7mm fixtures			
20 Hz to 120 MHz	E4990A-120	Support	Support	Support			
20 Hz to 50 MHz	E4990A- 050	Support	Not support	Not support			
20 Hz to 30 MHz	E4990A- 030						
20 Hz to 20 MHz	E4990A- 020						
20 Hz to 10 MHz	E4990A- 010						

Step 2. Choose frequency reference (if not required, go to Step 3)

Description	Option no.	Requires	Not compatible	Additional information
High stability frequency reference	E4990A-1E5	None		This option improves the frequency accuracy and stability of the E4990A. BNC Adapter is supplied with E4990A-1E5.

Note: Refer to Hardware Upgrade for retrofit information on the above options.

Step 3. Choose software option (If not required, go to Step 4)

Description	Option no.	Requires	Not compatible	Additional information
Enhanced measurement speed	E4990A-001	E4990A-050, 030, 020 or 010	E4990A-120	Make the measurement speed faster as the same as E4990A-120. See the measurement time data in the E4990A datasheet (5991-3890EN).

Step 4. Choose accessory option (If not required, go to Step 5)

Description	Option no.	Requires	Not compatible	Additional information
Rackmount kit	E4990A-1CM	None	E4990A-1CP	
Front handle kit	E4990A-1CN	None	E4990A-1CP	
Handle/rackmount kit	E4990A-1CP	None	E4990A-1CM E4990A-1CN	
Keyboard	E4990A-810	None	None	
Mouse	E4990A-820	None	None	

Note: Refer to Hardware Upgrade for retrofit information on the above options.

Step 5. Choose calibration certificate option (If not required, go to Step 6)

Description	Option no.	Additional information
ISO 17025 compliant calibration	E4990A-1A7	ISO 17025 compliant calibration
ANSI Z540 compliant calibration	E4990A-A6J	ANSI Z540 compliant calibration

Step 6. Choose warranty plan

3-year Return-to-Keysight Warranty and Service Plan are standard. For extended warranty options and additional information, contact your local Keysight Technologies, Inc. sales office or visit the Keysight home website.

Hardware Upgrade

Option no.	Description	Upgrade model no. or equivalent part no.	Customer installable	Requires (Instrument must already include the following)	Not compatible	Additional information
E4990A-1E5	High stability frequency reference	E4990AU-1E5	No		None	Installable at service center only
E4990A-020	Upgrade from 10 MHz to 20 MHz	E4990AU-020	No	E4990A-010	None	_
E4990A-030	Upgrade from 10 MHz to 30 MHz	E4990AU-030	No	E4990A-010	None	
E4990A-050	Upgrade from 10 MHz to 50 MHz	E4990AU-050	No	E4990A-010	None	
E4990A-120	Upgrade from 10 MHz to 120 MHz	E4990AU-120	No	E4990A-010	None	•
E4990A-030	Upgrade from 20 MHz to 30 MHz	E4990AU-031	No	E4990A-020	None	-
E4990A-050	Upgrade from 20 MHz to 50 MHz	E4990AU-051	No	E4990A-020	None	-
E4990A-120	Upgrade from 20 MHz to 120 MHz	E4990AU-121	No	E4990A-020	None	•
E4990A-050	Upgrade from 30 MHz to 50 MHz	E4990AU-052	No	E4990A-030	None	•
E4990A-120	Upgrade from 30 MHz to 120 MHz	E4990AU-122	No	E4990A-030	None	•
E4990A-120	Upgrade from 50 MHz to 120 MHz	E4990AU-123	No	E4990A-050	None	•
E4990A-1CM	Rackmount kit	5063-9216	Yes	None	E4990A-1CP	
E4990A-1CN	Front handle kit	5063-9229 E4990-20001	Yes	None	E4990A-1CP	
E4990A-1CP	Handle/rackmount kit	5188-4430 E4990-20001	Yes	None	E4990A-1CM E4990A-1CN	

Software Upgrade

Option no.	Description	Upgrade model no.	Customer installable	Requires (Instrument must already include the following)	Additional information
E4990A-001	Enhanced measurement speed	E4990AU-001	Yes	E4990A-050, 030, 020 or 010	Make the measurement speed faster as the same as E4990A-120. See the measurement time data in the E4990A datasheet (5991-3890EN).

Available Accessories - General/Miscellaneous Measurement Accessories

Description	Model no.	Requires (Instrument must already include the following)	Additional information
Impedance probe kit	42941A	E4990A-120	20 Hz – 120 MHz impedance probe kit. Contains pin probe, spare pin set, BNC-SMB Adapter, 3.5 mm short and load terminations, clip lead, grounding lead, carrying case and operation and service manual.
	42941A-ABA	E4990A-120	U.S. – English localization
	42941A-ABJ	E4990A-120	Japan – Japanese localization
4-terminal to 7 mm terminal adapter	42942A	E4990A-120	20 Hz – 120 MHz terminal adapter for using RF component test fixtures such as the 16092A, 16192A, 16194A, 16196A/B/C/D and 16197A. Operation note is furnished.
	42942A-700	E4990A-120	Adds 7 mm open/short/load terminations set
	42942A-ABA	E4990A-120	U.S. – English localization
	42942A-ABJ	E4990A-120	Japan – Japanese localization
Test leads	16048G	None	1 m BNC connector leads. DC – 120 MHz. Usable with the 4294A and E4990A.
	16048G-001	None	Adds BNC Bracket
	16048G-ABA	None	U.S. – English localization
	16048G-ABJ	None	Japan – Japanese localization
	16048H	None	2 m BNC connector leads. DC – 120 MHz. Usable with the 4294A and E4990A.
	16048H-001	None	Adds BNC Bracket
	16048H-ABA	None	U.S. – English localization
	16048H-ABJ	None	Japan – Japanese localization
SMD test fixture	16034E	None	For SMD; (0.1 to 8)L x (0.5 to 10)W x (0.5 to 10)H mm. DC - 40 MHz. Operation and service manual is furnished.
	16034G	None	For SMD; (0.1 to 5)L x (0.3 to 1.6)W x (0.3 to 1.6)H mm. DC – 120 MHz. 100 Ω SMD resistors set is furnished.
	16034G-ABA	None	U.S. – English localization
	16034G-ABJ	None	Japan – Japanese localization
	16034H	None	For array-type SMD; (0.1 to 5)L x (\leq 15)W x (0.6 to 3)H mm. DC – 120 MHz. 100 Ω SMD resistors set and operation manual are furnished.

Available Accessories — General/Miscellaneous Measurement Accessories (continued)

Description	Model no.	Requires (Instrument must already include the following)	Additional information
SMD test fixture	16047A	None	For axial or radial lead device. DC – 13 MHz. Operation and service manual is furnished.
	16047A-701	None	Adds Shorting plate
	16047E	None	For axial or radial lead device. DC – 120 MHz.
	16047E-ABA	None	U.S. – English localization
	16047E-ABJ	None	Japan – Japanese localization
Tweezers test fixture	16334A	None	For SMD; \leq 10 mm L. Tweezers type; cable length 1 m. DC – 15 MHz. Shorting block and Operation and Service Manual are furnished.
Kelvin clip leads	16089A	None	2 large clips. 5 Hz – 100 kHz. Choose mandatory option 16089A-800 or C20. Operation and service manual is furnished.
	16089A-800	None	Cable length: 1 m (standard)
	16089A-C20	None	Cable length: 2 m
	16089B	None	2 medium clips. 5 Hz – 100 kHz. Choose mandatory option 16089B-800 or C20. Operation and service manual is furnished.
	16089B-800	None	Cable length: 1 m (standard)
	16089B-C20	None	Cable length: 2 m
Kelvin IC clip leads	16089C	None	2 IC clips; cable length 1 m. 5 Hz – 100 kHz. Operation and service manual is furnished.
External voltage bias fixture	16065A	None	± 200 V dc max., for axial or radial lead device. 50 Hz – 2 MHz. Shorting plate and Operation and Service Manual are furnished.
Dielectric test fixture	16451B	None	Test fixture for measuring permittivity of dry solid sheet material; Cable length 1 m. DC – 30 MHz. 38 mm and 5 mm diameter electrodes for measuring bare material and two types of electrodes for measuring material with pre-formed electrodes are furnished.
	16451B-ABA	None	U.S. – English localization
	16451B-ABJ	None	Japan – Japanese localization
Liquid test fixture	16452A	None (16048G and four of 1250-0216 BNC(m) to BNC(m) adapters)	Test fixture for measuring permittivity of liquid material. 20 Hz – 30 MHz. Required volume of material; 3.4, 3.8, 4.8 or 6.8 ml. Temperature range: –20 ° to +125 °C. Shorting plate, spacers, SMA-BNC adapters, fixture stand, carrying case and operation and service manual are furnished.
Test leads	16452-61601	None	Heat-proof test leads for use with the 16452A. Temperature range: -20 ° to +125 °C
100 Ω resistor	E4990-61001	None	100Ω load resistor module for 4-terminal pair extension. Furnished with the E4990A.

Note: For more detailed information, refer to Accessories Selection Guide for Impedance Measurements.

Available Accessories - for Calibration and Maintenance

Description	Model no.	Requires (Instrument must already include the following)	Additional information
Open termination	42090A	None	4-terminal pair open termination. Required for performing calibration.
Short termination	42091A	None	4-terminal pair short termination. Required for performing calibration.
4-terminal pair standard capacitor set	16380A	None	1 pF, 10 pF, 100 pF and 1000 pF standard capacitor set with carrying case. Calibration report and operation note are furnished.
4-terminal pair standard capacitor set	16380C	None	0.01 μF, 0.1 μF and 1 μF standard capacitor set with carrying case. Calibration report and operation note are furnished.
	16380C-001	None	Adds 10 μF standard capacitor.
4-terminal pair standard resistor set	42030A	None	9 standard resistors from 1 m Ω to 100 k Ω in decade steps; Carrying case, calibration report and operation and service manual are furnished.
Performance test kit	16190A	None	Contains 7 mm open, short, 50Ω load terminations, calibrated air-line, wrench, calibration data diskette, carrying case and operation note.
4 Terminal pair to BNC interface box	04294-61002	None	Terminal adapter for test signal and DC bias performance tests

Note: For more detailed information, refer to Accessories Selection Guide for Impedance Measurements

Literature Resource

Title	Publication no.	Additional information
E4990A Data Sheet	5991-3890EN	
E4990A Brochure	5991-3888EN	
LCR Meters, Impedance Analyzers and Test Fixtures Selection Guide	5952-1430E	
Accessories Selection Guide for Impedance Measurements	5965-4792E	
Impedance Measurement Handbook	5950-3000	
Power of Impedance Analyzer — Comparison to Network Analyzer	5992-0338EN	

Note: More literature is available on the Keysight home website.

Web Resource

Have access to the following website to acquire the latest news, product and support information, application literature and more. www.keysight.com/find/impedance www.keysight.com/find/e4990a

Evolving

Our unique combination of hardware, software, support, and people can help you reach your next breakthrough. We are unlocking the future of technology.







From Hewlett-Packard to Agilent to Keysight

myKeysight

myKeysight

www.keysight.com/find/mykeysight

A personalized view into the information most relevant to you.

KEYSIGHT SERVICES Accelerate Technology Adoption. Lower costs.

Keysight Services

www.keysight.com/find/service

Our deep offering in design, test, and measurement services deploys an industry-leading array of people, processes, and tools. The result? We help you implement new technologies and engineer improved processes that lower costs.



Three-Year Warranty

www.keysight.com/find/ThreeYearWarranty

Keysight's committed to superior product quality and lower total cost of ownership. Keysight is the only test and measurement company with three-year warranty standard on all instruments, worldwide. And, we provide a one-year warranty on many accessories, calibration devices, systems and custom products.



Keysight Assurance Plans

www.keysight.com/find/AssurancePlans

Up to ten years of protection and no budgetary surprises to ensure your instruments are operating to specification, so you can rely on accurate measurements.

Keysight Channel Partners

www.keysight.com/find/channelpartners

Get the best of both worlds: Keysight's measurement expertise and product breadth, combined with channel partner convenience.

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: www.keysight.com/find/contactus

Americas

Canada	(877) 894 4414
Brazil	55 11 3351 7010
Mexico	001 800 254 2440
United States	(800) 829 4444

Asia Pacific

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 11 2626
Japan	0120 (421) 345
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Other AP Countries	(65) 6375 8100

Europe & Middle East

0800 001122
0800 58580
0800 523252
0805 980333
0800 6270999
1800 832700
1 809 343051
800 599100
+32 800 58580
0800 0233200
8800 5009286
800 000154
0200 882255
0800 805353
Opt. 1 (DE)
Opt. 2 (FR)
Opt. 3 (IT)

For other unlisted countries: www.keysight.com/find/contactus (BP-11-29-16)

0800 0260637



United Kingdom

www.keysight.com/go/quality

Keysight Technologies, Inc.
DEKRA Certified ISO 9001:2015
Quality Management System

