






Feel free to distribute these cards to the single line telephone users.






Customise your own Quick Reference Guide using the icons found in the "Button_SLT" folder.

Numbers in parentheses indicates that the feature numbers are different from those of "Plan 1" when "Plan 2" or "Plan 3" is selected.

Quick Reference Guide for Single Line Telephone

To make calls	
Intercom:	Extension no.
Operator:	0 / 9
The default operator call number varies depending on your country/area.	
Outside party:	9 / 0 / 1 + Phone no.
The default automatic line access number varies depending on your country/area.	
Personal speed dialling:	1 * / # (or 1 * / ##) + Personal speed dialling no.
System speed dialling:	* + System speed dialling no.
Redialling the last dialled number:	80 / # # (or 80 / ###)
Calling a doorphone:	31 (or #31) + Doorphone no.
When a line is busy	
Reserving a busy line:	6
Sending a call waiting tone:	2
To pick up someone's call	
Specified extension:	4 (or #41) + Extension no.
Group:	40 (or #40)
During a conversation	
Holding:	 + 
Retrieving a call on hold:	 + Extension no.
Transferring:	 + Extension no.
Paging through built-in and external speakers:	33 * / 339 (or #33 * / #339)
Answering a paged announcement:	43 (or #43)
Opening a door:	 + 5
Frequently used features	

Quick Reference Guide for Single Line Telephone


To make calls	
Intercom:	Extension no.
Operator:	0 / 9
The default operator call number varies depending on your country/area.	
Outside party:	9 / 0 / 1 + Phone no.
The default automatic line access number varies depending on your country/area.	
Personal speed dialling:	1 * / # (or 1 * / ##) + Personal speed dialling no.
System speed dialling:	* + System speed dialling no.
Redialling the last dialled number:	80 / # # (or 80 / ###)
Calling a doorphone:	31 (or #31) + Doorphone no.
When a line is busy	
Reserving a busy line:	6
Sending a call waiting tone:	2
To pick up someone's call	
Specified extension:	4 (or #41) + Extension no.
Group:	40 (or #40)
During a conversation	
Holding:	 + 
Retrieving a call on hold:	 + Extension no.
Transferring:	 + Extension no.
Paging through built-in and external speakers:	33 * / 339 (or #33 * / #339)
Answering a paged announcement:	43 (or #43)
Opening a door:	 + 5
Frequently used features	

PSQX3429ZA KK1004HK0

PSQX3429ZA

				dialling no.																	
--	--	--	--	--------------	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

#33 * / #339)



KK1004HK0