

Adaptors for rods

Low Medium High Voltage

Overhead lines and cabins

Adaptors for rods





ADATT/DIN-U

Adaptor for rods with bayonet **DIN** attack. It allows to use voltage detectors and maneuvering hooks for switches disconnections with universal **U** tang.

ADATT/CH12-DIN

Adaptor for rods with bayonet CH12 attack. It allows to use voltage detectors, maneuvering hooks for switches disconnections, contact clamps and clamp holder heads with hexagonal DIN tang.

Adaptors for rods





ADATT/U-EF

Adaptor for rods with universal **U** attack. It allows to use voltage detectors, maneuvering hooks for switches disconnections and clamp holder heads with hexagonal **CH12** or **M10** tang.

ADATT/U-DIN

Adaptor for rod with universal U attack. It allows to use voltage detectors, maneuvering hooks for switches disconnections, contact clamps and clamp holder heads with bayonet DIN tang.