


**Section A - A, Oil Filter/Check Valve Assy**



**COMPRESSOR SERVICE KIT GROUP**



Itm #	Qty	Rec	Part Number	Description
0800	1		06NA660001	COMPR OIL SOLENOID VALVE PKG.
0801	1		8TB0884	OIL SOLENOID VALVE
0802	4		8TB0670	M8X1.25X25 S.H.C.S.
0803	1		8TB0274	OIL SOLENOID VALVE O-RING
0804	1		8TB0276	OIL SOLENOID VALVE O-RING
0805	1		8TB0847	FILTER PLUG O-RING
0806	1		KLE-LLM6	6MM ALLEN HEAD WRENCH
0807	1		99TA516057	INSTRUCTION SHEET
0808	1		06NA660002	COMPR TERM. JUMPER BAR KIT
0809	3		1TB0459	JUMPER BAR
0810	15		8TB0705	JAM NUT
0811	1		FC024A	3/4" CROWSFOOT WRENCH
0812	1		99TA516059	INSTRUCTION SHEET
0813	1		06NA660003	COMPR TERM. BOX KIT
0814	1		3TB0817	TERMINAL BOX
0815	1		3TB0818	TERMINAL BOX GASKET
0816	4		8TB0671	M6X1.25X10 S.H.C.S.
0817	1		3TB0688	TERMINAL BOX COVER
0818	1		2TB0684	TERMINAL BOX COVER GASKET
0819	4		2TB0716	TERMINAL BOX SCREW
0820	4		8TB0683	TERMINAL BOX COVER SCREW WASHER
0821	1		2TB0713	LABEL, INTERNAL TERM. BOX
0822	1		06DA508142	LABEL, WARNING
0823	1		2TB0713	LABEL, WIRING
0824	1		2TB0846	LABEL, METRIC
0825	1		06DA502503	LABEL, WARNING
0826	1		99TA516060	INSTRUCTION SHEET
0827	1		06NA660004	COMPR CHECK VALVE/MUFF. KIT
0828	1		0TB0231	MUFFLER BAFFLE PLATE
0829	1		2TB0254	SUPPORT TUBE
0830	1		8TB0291	MUFFLER CASING O-RING
0831	1		8TB0285	DISCHARGE LINE O-RING
0832	1		1TB0946	DISCHARGE CHECK VALVE
0833	1		2TB0774	SHOCK ABSORBER
0835	8		8TB0400	M12 X 1.75 X 45 TORX BOLT
0836	1		PSLE140	TORX HEAD WRENCH (E14)
0837	1		99TA516061	INSTRUCTION SHEET
0838	1		06NA660005	COMPR SUCTION SCREEN PKG.
0839	1		2TB0773	SUCTION SCREEN
0840	1		8TB0677	SUCTION O-RING
0841	1		06NA680001	O-RING GREASE
0842	1		99TA516062	INSTRUCTION SHEET
0843	1		06NA660006	COMPR ROTOR INJECT. OIL LINE PKG.
0844	1		0TB0652	ROTOR INJECTION OIL LINE
0845	2		8TB0654	ROTOR INJECTION OIL LINE FITTIN
0846	1		99TA516063	INSTRUCTION SHEET
0847	1		06NA660007	COMPR ECONOMIZER SCREEN PKG.
0848	1		8TB0676	ECONOMIZER SCREEN
0849	1		8TB0415	ECONOMIZER O-RING
0850	1		99TA516064	INSTRUCTION SHEET
0851	1		06NA660008	COMPR DISCH. SHIPPING PLATE PKG.
0852	1		1TB0247	DISCHARGE COVER PLATE
0853	1		8TB0455	CAST COLLAR
0854	1		8TB0285	DISCHARGE LINE O-RING
0855	4		8TB0454	M14X2.00X65
0856	1		99TA516065	INSTRUCTION SHEET
0857	1		06NA660009	COMPR ECON. SHIPPING PLATE PKG.
0858	1		1TB0886	ECONOMIZER COVER PLATE
0859	1		8TB0415	ECONOMIZER O-RING
0860	2		8TB0396	M12X1.75X35
0861	1		99TA516066	INSTRUCTION SHEET
0862	1		06NA660010	COMPR SUCTION SHIPPING PLATE PKG.



Itm #	Qty	Rec	Part Number	Description
0863	1		1TB0534	SUCTION COVER PLATE
0864	1		8TB0677	SUCTION O-RING
0865	4		8TB0454	M14X2.00X65
0866	1		99TA516067	INSTRUCTION SHEET
0867	1		06NA660011	COMPR UNLOADER SOLENOID PKG.
0868	1		8TA0049D	SOL.VALVE(COIL S/S,SEE ITEMS489A-D)
0869	2		8TB0675	M8X1.25X15 S.H.C.S.
0870	3		8TB0279	UNLOADER VALVE O-RING
0871	1		KLE-LLM5	5MM ALLEN HEAD WRENCH
0872	1		99TA516058	INSTRUCTION SHEET
0872A	1		06DA401834	COIL,24V DC(FOR ITEM#486)
0872B	1		EF19ZE024	COIL,24V AC(FOR ITEM#486)
0872C	1		EF19ZE120	COIL,120V AC(FOR ITEM#486)
0872D	1		EF19ZE240	COIL,202/240V AC(FOR ITEM#486)
0873	1		06NA660016	COMPR OIL FILTER ELEMENT(INTERNAL)
0874	1		8TB0847	FILTER PLUG O-RING
0875	1		8TB0320	OIL FILTER ELEMENT
0875A	1		99TA516075	INSTRUCTION SHEET
0876	1		8TB0462	COMPR OIL FILTER PLUG
0877	1		8TB0677	COMPR SUCTION O-RING
0878	1		8TB0285	COMPR DISCHARGE O-RING
0879	1		8TB0415	COMPR ECONOMIZER O-RING
0880	1		0TB0889	COMPR 7/16 SAEX1/4 FITTING W/SCHR
0881	1		8TB0474	COMPR LIFTING LUG-M14
0882	1		06NA660012	SUCTION O-RING PKG.
0883	1		8TB0677	SUCTION O-RING
0884	1		99TA516072	INSTRUCTION SHEET
0885	1		06NA680001	O-RING GREASE
0886	1		06NA660013	COMP. INSTALLATION PKT
0887	1		3TB0818	TERMINAL BOX GASKET
0888	1		8TB0677	SUCTION O-RING
0889	1		8TB0285	DISCHARGE LINE O-RING
0890	1		8TB0415	ECONOMIZER O-RING
0891	1		06NA680001	O-RING GREASE
0892	1		HK01CB002	ANTI ROTATION PRESS.SWITCH
0893	1		KLE-LLM5	5 MM ALLEN HEAD WRENCH
0894	1		KLE-SL16	1/4" ALLEN HEAD WRENCH
0895	1		FC024A	3/4" CROWSFOOT WRENCH
0896	1		DC80SA005	STR. THREAD COMPR. FITTING
0897	2		HY69DS044	QUICK CONNECT (M)
0898	1		HY69DS054	QUICK CONNECT (F)
0899	1		99TA516068	INSTRUCTION SHEET
0900	1		06NA660001	OIL FILTER CHECK VALVE PKG.
0901	1		06NA660001	OIL CHECK VALVE ASY
0902	1		99TA516057	INSTRUCTION SHEET
0903	1		06NA660015	COMPR SERVICE TOOL PKG.
0904	1		KLE-LLM5	5 MM ALLEN HEAD WRENCH
0905	1		KLE-LLM6	6 MM ALLEN HEAD WRENCH
0906	1		PSLE140	TORX HEAD WRENCH(E14)
0907	1		SIPR436	1-1/8,4 POINT DEEP SOCKET
0908	1		KLE-SL16	1/4" ALLEN HEAD WRENCH
0909	1		FC024A	3/4" CROWSFOOT WRENCH
0910	1		06NA660017	LOAD/UNLOAD SOLENOID O-RING KIT
0911	3		8TB0279	O-RING
0912	1		99TA516058	INSTRUCTION SHEET
0913	1		06NA660018	MUFFLER O-RING KIT
0914	1		8TB0291	O-RING
0915	1		8TB0285	O-RING
0916	1		99TA516061	INSTRUCTION SHEET
0917	1		06NA660019	1/4" SAE PLUG KIT
0918	1		0TB0889	1/4"SAE PLUG(7/16-20)
0919	1		99TA519003	INSTRUCTION SHEET

Model/Sales Pkg.: 06NA/NW



Itm #	Qty	Rec	Part Number	Description
0920	1		06NA660020	1/8" SAE PLUG KIT
0921	1		8TA0141C	1/8" SAE PLUG(5/16-24)
0922	1		99TA519003	INSTRUCTION SHEET
0923	1		06NA660021	1/4" SAE PLUG KIT
0924	1		8TA0142C	1/4" SAE PLUG(7/16-20)
0925	1		99TA519003	INSTRUCTION SHEET
0926	1		06NA660022	3/8" SAE PLUG KIT
0927	1		8TB0220	3/8" SAE PLUG(9/16-18)
0928	1		99TA519003	INSTRUCTION SHEET
0929	1		06NA660023	1-1/4" SAE PLUG KIT
0930	1		8TB0692	1-1/4" SAE PLUG(1-5/8-12)
0931	1		99TA519003	INSTRUCTION SHEET
0932	1		06NA660024	2" SAE PLUG KIT
0933	1		8TB0462	2" SAE PLUG(2-1/2-12)
0934	1		99TA519003	INSTRUCTION SHEET
0935	1		06NA660025	OIL CONTROL SOLENOID O-RING KIT
0936	1		8TB0274	O-RING
0937	1		8TB0276	O-RING
0938	1		99TA516057	INSTRUCTION SHEET
0940	1		06NA660026	TERMINAL PIN SEAL REPLACEMENT KIT
0941	6		AU61ML301	TERMINAL PIN LOCKWASHER
0942	6		8TB0663	TERMINAL PIN SEAL
0943	6		8TB0878	TERMINAL PIN FLAT WASHER
0944	18		8TB0928	TERMINAL PIN NUT
0945	1		3TB0818	COMPRESSOR TERMINAL BOX GASKET
0946	6		8TB0883	TERMINAL PIN INSULATOR BLOCK
0947	1		99TA526296	INSTRUCTION SHEET
0948	1		06NA660027	COMPRESSION END SEAL KIT
0948A	1		8TB0285	O-RING,DISCHARGE FLANGE
0948B	1		8TB0291	O-RING,MUFFLER
0948C	1		8TB0279	O-RING,BEARING COVER OIL PASSAGE
0948D	1		8TB0282	O-RING,BEARING COVER DISCHARGE PORT
0948E	1		8TB0292	O-RING,BEARING COVER/OUTLET CASE
0948F	1		8TB0911	O-RING,BEARING COVER/OUTLET CASE
0948G	1		8TB0293	O-RING,GEAR COVER TWO PIECE GROOVE
0948H	1		8TB0912	O-RING,GEAR COVER GROOVE IN ROTOR HSG
0948I	1		19XL680001	O-RING GREASE
0948J	1		99TA526299	INSTRUCTION SHEET