

Figure 1: General Wiring Connection for XP-GT with MAS-RBT




Figure 2: General Wiring Connection for 2 units XP-GT with MAS-RBT




Figure 3: Connection for XP-GT with MAS-RBT with Sounder Feature




Figure 4: Connection for XP-GT with MAS-RBT using Fire Alarm Release Feature