

## How to download SECOLINK PRO app from Google Play?

1. Launch the *Play store* app on your phone.



Play Store

2. Tap on message Google Play at the top of the screen and begin typing in SECOLINK PRO. Now scroll down the list of available apps and find SECOLINK PRO. To select it, simply tap on the app.
3. Tap the green *Install* button.
4. Before you can begin downloading an app to your phone you must accept the App permissions.
5. The app will begin downloading to your device. It will automatically install itself.
6. Tap the green *Open* button.

## How to sync application with your alarm system?

### Important!

1. SECOLINK PRO application uses SMS service to communicate with alarm system. Please be sure that your phone and your alarm system can send and receive SMS. To check this, please send the SMS with status inquiry command.
2. If the present status of your alarm system is not received, then try to call your system to be sure that you can control it.
3. **Please try to sync the application with your alarm system only when you are sure that you can control the system and receive all its notifications via SMS.**

<p><b>1</b></p> <p>1. Select language. 2. Click on <i>Let's start</i>.</p>	<p><b>2</b></p> <p>1. Select <i>Home alarm</i>. 2. Enter object's name. 3. Enter your phone number. 4. Enter your name. 5. Click on <i>Next</i>.</p>	<p><b>3</b></p> <p>1. Go to your alarm system's keypad. 2. Go to alarm system keypad, select service mode and press key [ENT].</p> <p>3. Enter your PIN.</p> <p>4. Ignore suggestion to enter service PIN. Press the [CLR] key several times</p>	<p><b>4</b></p> <p>1. Enter your system's PIN code. 2. Select <i>System with keypad</i>. 3. Select <i>Connected to GSM</i>. 4. Click on <i>Next</i>.</p>
<p><b>5</b></p> <p>1. Enter your alarm system's phone number. 2. Select <i>SMS plan in SIM</i>. 4. Select <i>Talk plan in SIM</i>. 5. Click on <i>Next</i>.</p>	<p><b>6</b></p> <p>1. Select <i>Only by SMS</i>. 2. Click on <i>Next</i>. Application will send a special text message to your alarm system. Alarm system will process the received SMS and if everything is ok (correct PIN, phone number) it will start sending information about system configuration back to your phone. The application will "read" all received SMS and include all received data in the application database.</p>	<p><b>7</b></p> <p>1. All data from the system has been received. 2. Click on <i>Next</i>.</p>	<p><b>8</b></p> <p>1. Application is ready to use. Enjoy!</p>