

Telephone Control Summary (VG1-16z-V1)

ViVOS

System Call Out

Answer Call \Rightarrow Key In
4 digits Password + #

Call In to System

Dial Phone Number \Rightarrow 4 digits Password + #

Note:

Telephony will automatically cut off when no key press detected within 60 seconds.

Telephony will automatically cut off when key in wrong password after 5 times.

Only User 1 to 4 able to control the system through telephony.

Press Number

- [1] System Arm / Disarm
- [2] Siren ON / OFF
- [3] Zone Bypass / Restore 01 to 16 Zone
00 = All Zone
- [4] Home Automation 01 to 16 HA Points
ON / OFF 00 = All HA Points
- [0] System Status Report
 - System Arm / Disarm
 - Siren ON / OFF
 - Service Trouble Report
 - Duress User 1 / 2 / 3
 - Zone Bypass / Open
 - Home Automation ON / OFF
 - Panic!!!
- [9 + #] To End the Call
- [*] Voice Guide Menu

电话遥控操作目录 (VG1-16z-V1)

ViVOS

系统呼出

接听电话 \Rightarrow 按密码
4 位数密码 + # 号

呼入到系统

输入电话号码 \Rightarrow 4 位数密码 + # 号

注意:

当没有任何按键入在60秒之内,电话会自动停止通话.

当输入超过5次的错误密码,电话会自动停止通话.

只有用户1~4才可以通过电话遥控来操作系统.

按号码

- [1] 系统启动 / 关闭
- [2] 警笛开 / 关
- [3] 绕行防盗地区 / 恢复 01 至 16 地区
00 = 全部地区
- [4] 家居遥控开 / 关 01 至 16 家居遥控
00 = 全部家居遥控
- [0] 查询系统报告
 - 系统启动 / 关闭
 - 警笛开 / 关
 - 系统问题报告
 - 威胁用户 1 / 2 / 3
 - 防盗地区绕行 / 开着
 - 家居遥控开 / 关
 - 惊慌!!!
- [9 + #] 停止通话
- [*] 操作指导目录