

User Manual K13

Add Password

123456#1888#(Pin)#(Repeat Pin)#

Add Card

123456#1(3 Digit Last Card Number)#Touch Card#

Delete Password

123456#2888#

Delete Card

123456#2(3 Digit Last Card Number)#