

# CCS-CMx CCS Chairman Unit

www.boschsecurity.com



**BOSCH**  
Invented for life



- ▶ Incorporates all functions of the CCS-Dx CCS Delegate Units (with the exception of the Possible-To-Speak functionality/LED)
- ▶ Priority button for chairman microphone
- ▶ Temporary or permanent muting of delegate microphones
- ▶ Optional chime tone facility for preceding chairman announcements
- ▶ Modern, unobtrusive styling to match the CCS-Dx CCS Delegate Units

The CCS-CMx CCS Chairman Units are equipped with enhanced functionality that enables the user to take the role of chairman in a conference or meeting.

## Functions

### Priority button for chairman microphone

In addition to the 'microphone on' button the chairman units feature a 'chairman priority' button. When pressed the priority button causes all currently active delegate microphones to be temporarily or permanently muted.

### Temporary or permanent muting of delegate microphones

The 'chairman priority' button can be set to mute delegate microphones on a temporary or permanent basis. On the temporary setting, delegate microphones are muted only as long as the chairman has the priority button pressed down. On the permanent setting delegates must reactivate their microphone after a 'chairman priority' announcement by pressing the 'microphone on' button on their delegate unit. Activation of the permanent mute option is carried out by setting an internal switch, which can be accessed by removing a small plastic plate on the base of the chairman unit.

### Optional chime tone facility for preceding chairman announcements

An optional chime tone can be selected to precede chairman priority calls. Activate the chime tone option by setting an internal switch; this can be accessed by removing a small plastic plate on the base of the chairman unit.

### Standard or extended length microphone stems

The chairman units are available with standard 313 mm (12.3 in) or extended 488 mm (19.2 in) microphone stem lengths.

### Controls and Indicators

- Microphone on/off button
- Chairman priority button
- Rotary volume control for adjusting headphone volume
- Loudspeaker, automatically muted when microphone is on and/or headphones are connected
- Internal switch for selection of chairman announcement chime tone
- Internal switch for temporary or permanent muting of delegate microphones when chairman priority button is pressed
- Microphone has 'on' indicator (red LED)
- Light ring indicator on microphone stem, lights up red when microphone is on

- No Possible-To-Speak functionality and indicator is required because a Chairman Unit can always switch-on the microphone, no matter the number of delegates speaking

**Interconnections**

- 1 x 2 m (78.7 in) cable terminated with a molded 7-pole circular male connector, for loop-through interconnection to delegate unit or Control Unit
- 1 x 7-pole circular female connector for loop-through interconnection to delegate units
- 2 x 3.5 mm (0.14 in) stereo headphone sockets

**Technical specifications**

**Mechanical**

Dimensions unit without microphone (H x W x D)	71 x 220 x 140 mm (2.8 x 8.7 x 5.5 in)	
Height with microphone in horizontal position	134 mm (5.3 in)	
Length of microphone from mounting surface	CSS-CMS	CCS-CML
	313 mm (12.3 in)	488 mm (19.2 in)
Weight	approx. 1 kg (2.2 lb)	
Mounting	tabletop (portable or fixed)	
Material (top)	polymer	
Material (base)	painted metal	
Color (base)	charcoal (PH10736)	
Color (top)	charcoal (PH10736)	

**Ordering information**

**CCS-CMS CCS Chairman Unit Short Microphone**

microphone stem length 313 mm (12.3 inch)

Order number **CCS-CMS**

**CCS-CML CCS Chairman Unit Long Microphone**

microphone stem length 488 mm (19.2 inch)

Order number **CCS-CML**

**DCN-DISCLM Cable Clamp (25 pcs)**

25 pieces

Order number **DCN-DISCLM**

**Represented by:**

**Americas:**

Bosch Security Systems, Inc.  
12000 Portland Avenue South  
Burnsville MN 55337, USA  
Phone: +1-800-392-3497  
Fax: +1-800-955-6831  
audiosupport@us.bosch.com  
www.boschsecurity.com

**Europe, Middle East, Africa:**

Bosch Security Systems B.V.  
P.O. Box 80002  
5617 BA Eindhoven, The Netherlands  
Phone: + 31 40 2577 284  
Fax: +31 40 2577 330  
emea.securitysystems@bosch.com  
www.boschsecurity.com

**Asia-Pacific:**

Robert Bosch (SEA) Pte Ltd, Security Systems  
11 Bishan Street 21  
Singapore 573943  
Phone: +65 6571 2808  
Fax: +65 6571 2699  
apr.securitysystems@bosch.com  
www.boschsecurity.asia

**China:**

Bosch (Shanghai) Security Systems Ltd.  
201 Building, No. 333 Fuquan Road  
North IBP  
Changning District, Shanghai  
200335 China  
Phone +86 21 22181111  
Fax: +86 21 22182398  
www.boschsecurity.com.cn

**America Latina:**

Robert Bosch Ltda Security Systems Division  
Via Anhanguera, Km 98  
CEP 13065-900  
Campinas, Sao Paulo, Brazil  
Phone: +55 19 2103 2860  
Fax: +55 19 2103 2862  
al.securitysystems@bosch.com  
www.boschsecurity.com