

LONGLIFE hospital



Disinfectant - resistant emulsion polish

- Disinfectant-proof ■ Long-lasting ■ Easy application

Product profile

- LONGLIFE hospital is resistant to non-alcoholic surface disinfectants. The wear and tear resistance protects floors.
- The disinfectant-proof emulsion polish is time- and cost-saving and is suitable for areas with specific hygiene requirements.
- LONGLIFE hospital is recommended wherever an excellent look or durability of the protection film is desired.
- As a safety aspect LONGLIFE hospital is slip-resistant because of the contained powerful care components (according to DIN51131) even under strong frequentation.
- LONGLIFE hospital is highly resistant to heel marks and soils. It reduces resoilings and enables lasting cleanness.
- With its uniform look it is fast and simple in processing and shows an excellent flow further high-speed-polishing increases the durability.

Area of application

- LONGLIFE hospital is very suitable for the maintenance of water resistant floorings especially in health facilities, for example hospitals, doctor's surgeries, retirement and nursing homes, rehab centers etc.
- Do not apply on unsealed wood. Before using the product on elastomer coverings please install a testing area.

Ingredient declaration

For the ingredients list, please see the Safety Data Sheet

Sustainable development and production



Product safety, storage and environmental instructions

Safety: For professional use only. For further information see Safety Data Sheet.

Storage: Store at room temperature in the original container. Keep from freezing.

Environmental: Only give completely emptied packaging to a special waste disposer.

Application and Dosing



Dose in relation to application. Follow below instructions.




Floor preparation: strip the floor, remove all dirt and old dispersion layers.



Initial treatment: apply 2-3 thin and uniform layers. Drying time between the applications at least 30min.



Large areas: work in sections and apply wet in wet. Usage: approx. 2 L / 100 m².



Coating refreshment: remove slight scratches using the spray-cleaner-method and a highspeed machine with red pad.



After awaiting the fair drying time (one day) polish with Ultra High-Speed-Method (>1000 U).

Sales units

Order No. 713365 2 x 5 L
Order No. 702652 1 x 10 L

Your trusted partner on site

pH-Value

