# **Blue-White**

# **Variable Area Flow Meters**

Industries, Ltd.	Engineering and Technical Data
<b>F-410N</b>	
— 3/4", 1" F/NPT	GPW 210
- Rod Guided Float	

# **Features:**


- Tough machined acrylic meter body, highly polished to a clear finish.
- Direct reading permanent scale.
- White back reflector for easy reading.
- F/NPT adapters with high grade Viton o-ring seals and aluminum "stress ring" thread supports.
- 316 stainless steel or Hastelloy rod guided floats.
- Acceptable in direct sunlight applications.

# **Materials of Construction:**


Meter Body: Adapters:	
Guide Rod Holder:	Polypropylene
O-ring seals:	Viton <sup>®</sup> (optional EP)
Float:	
Standard Series	316SS
K- Series	Hastelloy
Guide Rod:	
Standard Series	316SS
K- Series	Hastelloy

# **Specifications:**





# **Dimensions:**



¥

1-3/4"

44mm

A



# **Installation Requirements:**

## 1. Misalignment will damage the meter!

Flowmeter must be installed in an exact vertical plane to ensure accuracy. Be certain of proper plumbing alignments. Misalignment may cause the o-ring seals to leak.

#### 2. Pipe dope and glue will damage the meter!

Use only Teflon® tape on the threaded adapters. The meter body and plastic fittings cannot tolerate PVC Glue and/or pipe dope. Even fumes can cause severe damage. If you are installing your flowmeter to a glued pipe configuration, install the flowmeter after all glued fittings are dried and lines are purged of all fumes. Never hold the meter body with pliers or like tools. DO NOT OVER-TIGHTEN!

#### 3. Vibration and heavy loads will damage the meter!

Wall, floor and ceiling mounts and supports must be carefully aligned with the meter body and sturdy enough to support the plumbing and prevent vibration. Never allow the flowmeter to support the weight of related piping.

#### 4. Solenoid valves will damage the meter!

Avoid a system that will impose a sudden burst of flow to the meter. Such a burst will cause the float to impact the float stop with destructive force. Solenoid valves, or other quick opening valves cannot be used unless meter is protected against sudden bursts of flow.

#### 5. High pressures and temperatures will damage the meter!

The maximum acceptable temperature and pressure is interdependent. The maximum acceptable working pressure is dependant on the actual fluid temperature. The maximum acceptable fluid temperature is dependant on the actual working pressure. (see Temperature Vs. Pressure chart).

# Flow Range and Model Options:

## **Standard Series**

- Equipped with 316 SS guide rod

## **Models for Liquid**

MODEL NUMBER	Dual Sca GPM	lle Range LPM	Adapter F/NPT	Adapter Material	Float Material
F-40750LN-12	1 to 10	4 to 38	3/4"	Polypropylene	316 SS
F-40750LN-16	1 to 10	4 to 38	1"	Polypropylene	316 SS
F-41017LN-12	1 to 17	4 to 64	3/4"	Polypropylene	316 SS
F-41017LN-16	1 to 17	4 to 64	1"	Polypropylene	316 SS
F-41000LN-12	2 to 20	8 to 80	3/4"	Polypropylene	316 SS
F-41000LN-16	2 to 20	8 to 80	1"	Polypropylene	316 SS

## **Models for Air**

MODEL NUMBER	Dual Sca SCFM	le Range M³HR	Adapter F/NPT	Adapter Material	Float Material
F-40750GN-12	4 to 45	8 to 80	3/4"	Polypropylene	316 SS
F-40750GN-16	4 to 45	8 to 80	1"	Polypropylene	316 SS
F-41017GN-12	5 to 75	10 to 125	3/4"	Polypropylene	316 SS
F-41017GN-16	5 to 75	10 to 125	1"	Polypropylene	316 SS
F-41000GN-12	10 to 80	20 to 140	3/4"	Polypropylene	316 SS
F-41000GN-16	10 to 80	20 to 140	1"	Polypropylene	316 SS

## **K-Series**

- Equipped with Hastelloy guide rod

#### K-Series models are specially equipped for highly corrosive applications.

### Models for Liquid

MODEL NUMBER	Dual Sca GPM	le Range LPM	Adapter F/NPT	Adapter Material	Float Material
F-40750LK-12	1 to 10	4 to 38	3/4"	Polypropylene	Hastelloy
F-40750LK-16	1 to 10	4 to 38	1"	Polypropylene	
F-41017LK-12	1 to 17	4 to 64	3/4"	Polypropylene	Hastelloy
F-41017LK-16	1 to 17	4 to 64	1"	Polypropylene	Hastelloy
F-41000LK-12	2 to 20	8 to 80	3/4"	Polypropylene	Hastelloy
F-41000LK-16	2 to 20	8 to 80	1"	Polypropylene	Hastellov

## Correction factor formulas for AIR models

SSURE CORRECTION	TEMPERATURE CORRECTION
14.7 + Working PSIG 14.7	$\sqrt{\frac{520}{460 + \text{Working Temp °F}}}$

Notes:

2) Liquid models calibrated with water, Sp.Gr. 1.0. Custom Sp.Gr. calibrations available. Contact the factory.
2) Air models calibrated at standard Conditions (70°F @ 14.7 PSIa). Temperature and pressure correction may be required. Contact the factory for custom calibrations.



PRESSURE

**Blue-White** 5300 Business Drive, Huntington Beach, CA 92649 Tel: 714-893-8529 Fax: 714-894-9492 Industries, Ltd. www.blue-white.com Email: sales@blue-white.com

