YK500XGLC

Arm length 500mm
Maximum payload 4kg

■ Ordering method

YK500XGLC- 150

No entry: None F: With tool flange

RCX240S

Usable for CE

N, P: Standard I/O 16/8 N1, P1: 40/24 N2, P2: 64/40 N3, P3: 88/56 N4, P4: 112/72

No entry: None CC: CC-Link DN: DeviceNet
PB: Profibus
EN: Ethernet
EP: EtherNet/IP

No entry: None VY: iVY (Vision) TR: iVY+Light +Tracking LC: iVY+Light No entry: None GR: Gripper

Note 1. Use N to N4 when NPN is selected on the I/O board, and P to P4 when PNP is selected. Note 2. Available only for the master. See P.39 for details on YC-Link system.

■ Basic specifications					
		X axis	Y axis	Z axis	R axis
Axis specifications	Arm length (mm)	250	250	150	-
	Rotation angle (°)	+/-129	+/-144	-	+/-360
AC servo motor output (W)		200	150	50	100
Repeatability Note 1 (XYZ: mm) (R: °)		+/-0.01		+/-0.01	+/-0.004
Maximum speed (XYZ: m/sec) (R: °/sec)		5.1		1.1	1020
Maximum payload (kg)		4			
Standard cycle time: with 2kg payload (sec) Note 2		0.74			
R-axis tolerable moment of inertia Note 3 (kgm²)		0.05			
User wiring (sq × wires)		0.2×10			
User tubing (Outer diameter)		ф4×4			
Travel limit		1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
Robot cable length (m)		Standard: 3.5 Option: 5, 10			
Weight (kg)		25			
Degree of cleanliness		Class ISO 3 (ISO 14644-1) Note 4+ESDNote 5			
Intake air (Nl/min)		30 Note 6			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)
Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).
Note 3. There are limits to acceleration coefficient settings. See P.478.
Note 4. Class 10 (0.1µm) equivalent to FED-STD-209D

Note 5. ESD (ElectroStatic Discharge) prevention is an option. Please contact our distributor. Note 6. The necessary intake amount varies depending on the use conditions and environment.

Controller Controller Power capacity (VA) Operation method Programming / I/O point trace / Remote command / RCX240S 1000 Operation using RS-232C communication

Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.) See our robot manuals (installation manuals) for detailed information

Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below http://www.yamaha-motor.co.jp/global/industrial/robot/



