

LONGLIFE vario



Ich bin ein
Platzhalter

Application and Dosing



Dose in relation to application. Follow below instructions.



Floor preparation: strip the floor, remove all dirt and old dispersion layers. Leave to dry.

concentrated



Initial treatment: apply 2-3 thin and uniform layers. Drying time between the applications at least 30min.



Large areas: work in sections and apply wet in wet. Usage: approx. 2 L / 100 m².



Coating refreshment: remove slight scratches using the spray-cleaner-method and a highspeed machine with red pad.

Polish for a variable gloss with excellent processing properties

- Variable gloss
- Versatile use
- Easy application

Product profile

- LONGLIFE vario emulsion polish is an emulsion polish with excellent processing properties. Belonging to the longlife family it shows particular resistance against wear and tear and at the same time provides exceptional optics.
- LONGLIFE vario can be set on two level of shine. The standard gloss level is a silk gloss. High-speed-polishing of the LONGLIFE vario protection film enables a high gloss level.
- The specially developed formula generates a homogenous flow and mistakes cannot come up.
- The combination of specific acrylate and urethane polymers as well as waxes guarantees highest durability and can be removed completely in case of stripping.

Area of application

- For all water resistant, elastic floor coverings, especially suitable for linoleum and PVC.
- Do not use on unsealed wood floors and unpolished stone floors.

Ingredient declaration

For the ingredients list, please see the Safety Data Sheet

Sustainable development and production



Product safety, storage and environmental instructions

Safety: For professional use only. For further information see Safety Data Sheet.

Storage: Store at room temperature in the original container. Keep from freezing.

Environmental: Only give completely emptied packaging to a special waste disposer.

Sales units

Order No. 713769 2 x 5 L

Your trusted partner on site

pH-Value

