




**LU-CHU**  
綠 | 聚 | 實 | 業

**LC-213LC**

## *Refrigeration system controller*

Panel :



Technical data :

- Power supply : 110V/220V /AC/50~60Hz
- Display : Seven segment LED
- Mounting : Snap-in (Panel)
- Fit-in size : 137\*28\*32mm<sup>3</sup>(Panel)
- Fit-in size : 165\*140\*53mm<sup>3</sup>(Rear box)
- Maximum output rating : (1)Compressor 30A/250V (2) Fan 8A/250V  
(3)Lamp 8A/250V (4) Defog 8A/250V (Resistance load)
- Temperature range : -50°C ~ +80. 0°C
- Working temperature : -15°C ~ +70°C
- Accuracy : ±1°C
- Resolution : 0. 1°C

System parameter table :

No.	Symbol	Description	Range	Default
1.	tS	Set compressor stop temperature	-50°C ~ +80. 0°C	+4. 0°C
2.	td	Define differential temperature	+0. 1°C ~ +15. 0°C	+2. 0°C
3.	Sd	Compressor start time delay after stop	0 ~ 15 Min.	2 Min.
4.	di	Defrost interval time	0 ~ 24 Hour	4 Hour
5.	dd	Defrost duration time	0 ~ 60 Min.	20 Min.
6.	CL	condenser cleaning time interval	0 ~ 250day	0day
7.	tA	Sensor calibration adjustment	-10°C ~ +10. 0°C	0. 0°C

Lock system parameter table :

No.	Symbol	Description	Range	Default
1.	Lo	Select system parameters to lock or unlock	y: lock / n: unlock	y
2.	tH	The upper temperature limit	tS ~ +80. 0°C	+50. 0°C
3.	tL	The lower temperature limit	-50°C ~ tS	-50°C
4.	AH	High temperature alarm	tS ~ +80. 0°C	+50. 0°C
5.	Ht	Temperature reach『AH』, after『Ht』value , alarm start working	0 ~ 180Min.	90Min.
6.	AL	Low temperature alarm	-50°C ~ tS	-30°C
7.	Lt	Temperature reach『AL』, after『Lt』value , alarm start working	0 ~ 180Min.	60Min.

Note : (1) After choose『y』on the first lock system parameter『Lo』; means you select to lock the system parameters, display will show system parameter『tS』only, and it can only be adjusted within the highest,『tH』, and lowest,『tL』temperature limit, no other system parameters can be changed, thereafter. On the contrary, if『n』is selected, then all system parameters can be modified.

Self test function :

Error code	Description
E1H	Sensor shorted or temperature higher than +80. 0°C
E1L	Sensor opened or temperature lower than -50°C
AH	High temperature alarm
AL	Low temperature alarm
CLn	Condenser need to be clean

Operation :

### A. System parameter setting:

1. Press [SET] key, the display flashes pattern『888』for 3 times, then shows the symbol of the first system parameter『tS』, this means the controller entering the parameter modifying phase, can press [▲] or [▼] key to scroll up/down the parameter that is going to be adjust, . Press [SET] key, the display shows set value, can push [▲] or [▼] key to increase or decrease the value by one unit, press the [SET] key, the controller goes to modify the next parameter. Press [SET] key, the display shows『888』, then display cabinet-room temperature mean that you finish parameters setting.

### B. Lock system parameter setting:

1. Press [SET] key for three seconds, the display begins flashing pattern『888』. While flashing, press both [▲] and [▼] keys together until display shows『Lo』(which means into parameters lock). Press [SET] again, the modified value would be showed. At this time, press [▲] or [▼] to lock by choosing『y』or to unlock by choosing『n』.
2. After select system parameters to unlock push [SET] key, the display shows pattern『tH』, can press [▲] or [▼] key to scroll-move to the next parameter.



## Refrigeration system controller

### C. Other operations:

- Once connect to power source, pressing [ON/OFF] button to Power-on 『Pon』 or Power-off 『PoF』.
- After power 『ON』, the compressor is delaying for protecting. If you want to bypass the delay time and start immediately running the compressor, then you can push [▼] key until display shows 『Fon』. The controller then forces compressor to start up immediately. This special function is only effective on the power on stage.
- Total operation hours (tot):** The total compressor running time can be showed on display by showing three sets digits through push Press [▲] button and [▼] button simultaneously. For example if the total running time is 1234 hours, the display will show first set "tot" (means total running time), then followed by the second digit set 『001』, then the last digit set 『234』.
- If there is no any key was pressed within 30 seconds, the controller automatically finish system setting procedure,

Press (exit key) you can jump back normal operation mode.

\*\*While " CLn " is flashing , press [▼] to cease alarm.

\*\*To reset the "CLn" error code, use 『ON/OFF』key to turn Off power and turn on power again . The system will re-count the cleaning time.

### Function keys :

Symbol	Name	Function description
	Power on/off	The controller power supply key
	Increase/Decrease	To increase or decrease one unit value
	Set	Request for setting the parameter
	Manual defrost	Push this key to do manual defrost
	Door heater	To on/off the door heater for clarify the showcase door
	Light on/off	To on/off the indoor light appliance

### LED Indicators :

Symbol	Color	Description
	Yellow	Lamp on , power supply
	Green	Lamp flash , compressor start up delay Lamp on , compressor running
	Red	Lamp on , system defrosting
	Yellow	Lamp on , fan is running
	Yellow	Lamp on , door heater is on
	Yellow	Lamp on , indoor light appliance is on

### Sensor description :

<p>Isolation wire NTC sensor with BLACK PVC/1.5M/5cm 6φ copper head</p>	<p><b>Correct connection method :</b></p> <p>If you want to lengthen the NTC sensor probe , for isolating the noise , the extension wire must be shielded, and use the shielded wire as the ground wire. (as shown above).</p>
---	--

### Wiring diagram :

