Honeywell | Pressure Reducing Valves

D06FN

Pressure reducing valve with balanced seat

Low pressure pattern

APPLICATION

According EN 806-2 pressure reducing valves of this type protect household water installations against excessive pressure from the supply. They can also be used for industrial or commercial applications within the range of their specification.

By installing a pressure reducing valve, pressurisation damage is avoided and water consumption is reduced.

The set pressure is also maintained constant, even when there is wide inlet pressure fluctuation.

Reduction of the operating pressure and maintaining it at a constant level minimizes flow noise in the installation.

SPECIAL FEATURES

- Inlet pressure balancing no influence on outlet pressure by fluctuating inlet pressure
- Up to size 1¹/₄" approved by LGA for low noise, Group 1 without limitations
- The valve insert is of high quality synthetic material and can be fully exchanged
- The outlet pressure is set by turning the adjustment knob
- The set pressure is directly indicated on the set point scale
- The adjustment spring is not in contact with the drinking water
- Integral fine filter
- Easily retrofittable to convert valve to a reverse-rinsing filter combination
- Can be retrofitted with an inlet check valve
- Also available without fittings
- All materials are UBA conform
- All materials are ACS approved




TECHNICAL DATA

| Media | |
|------------------------------------|----------------|
| Medium: | Drinking water |
| Connections/Sizes | |
| Connection sizes: | 1/2" - 2" |
| Nominal sizes: | DN15 - DN50 |
| Pressure values | |
| Max. inlet pressure: | 25 bar |
| Outlet pressure: | 0.5 - 2 bar |
| Preset outlet pressure: | 1.5 bar |
| Minimum pressure: | 0.5 bar |
| Operating temperatures | |
| Max. operating temperature | 60 °C |
| medium: | |
| Max. operating temperature medium: | 70 °C * |
| * may aparating procesure 10 har | |

^{*} max. operating pressure 10 bar

CONSTRUCTION



METHOD OF OPERATION

Spring loaded pressure reducing valves operate by means of a force equalising system. The force of a diaphragm operates against the force of an adjustment spring. If the outlet pressure and therefore diaphragm force fall because water is drawn, the then greater force of the spring causes the valve to open. The outlet pressure then increases until the forces between the diaphragm and the spring are equal again.

The inlet pressure has no influence in either opening or closing of the valve. Because of this, inlet pressure fluctuation does not influence the outlet pressure, thus providing inlet pressure balancing.

TRANSPORTATION AND STORAGE

Keep parts in their original packaging and unpack them shortly before use.

The following parameters apply during transportation and storage:

| Parameter | Value |
|---------------------------|--------------------------|
| Environment: | clean, dry and dust free |
| Min. ambient temperature: | 5°C |
| Max. ambient temperature: | 55 °C |
| Min. ambient relative | 25 % * |
| humidity: | |
| Max. ambient | 85 % * |
| relative humidity: | |

^{*}non condensing

INSTALLATION GUIDELINES

Setup requirements

- Install in horizontal pipework with filter bowl downwards
- Install shut-off valves
- The installation location should be protected against frost and be easily accessible
 - Pressure gauge can be read off easily
 - Simplified maintenance and cleaning
- Install downstream of the filter or strainer
 - This position ensures optimum protection for the pressure reducing valve against dirt
- Provide a straight section of pipework of at least five times the nominal valve size after the pressure reducing valve (in accordance with EN 806-2)
- Requires regular maintenance in accordance with EN 806-5

Installation Example




Fig. 1 Standard installation example for the pressure reducing valve

- 1 Water meter
- 2 Shut-off valve
- 3 Check valve
- 4 Filtering unit
- 5 Pressure reducing valve

| Connection sizes: | ¹ / ₂ " | ³ / ₄ " | 1" | 1 ¹ / ₄ " | 1 ¹ / ₂ " | 2" |
|----------------------|-------------------------------|-------------------------------|----|---------------------------------|---------------------------------|----|
| Distance in mm (W*): | 55 | 55 | 60 | 60 | 70 | 70 |

^{*} Required installation distances between the centerline of the pipework and the surrounding in dependency of the connection size.

TECHNICAL CHARACTERISTICS

kvs-Values

| Connection sizes: | 1/2" | 3/4" | 1" | 1 ¹ /4" | 11/2" | 2" |
|--------------------------------------|------|------|-----|--------------------|-------|------|
| k_{vs} -value (m ³ /h): | 2.4 | 3.1 | 7.6 | 9.1 | 12.6 | 12.0 |

Pressure drop characteristics





Fig. 2 Pressure drop within the valve in dependency of the flow rate and the used connection size

DIMENSIONS



| Parameter | | Values | | | | | |
|------------------------|----|--------|------|-----|--------------------|----------------|-----|
| Connection sizes: | R | 1/2" | 3/4" | 1" | 1 ¹ /4" | $1^{1}/_{2}$ " | 2" |
| Nominal size diameter: | DN | 15 | 20 | 25 | 32 | 40 | 50 |
| Weight: | kg | 1.4 | 1.6 | 2.4 | 2.8 | 4.4 | 5.6 |
| Dimensions: | L | 140 | 160 | 180 | 200 | 225 | 255 |
| | l | 80 | 90 | 100 | 105 | 130 | 140 |
| | Н | 148 | 148 | 185 | 185 | 210 | 210 |
| | h | 56 | 56 | 77 | 77 | 113 | 113 |
| | D | 73 | 73 | 83 | 83 | 102 | 102 |

Note: All dimensions in mm unless stated otherwise.

ORDERING INFORMATION

The following tables contain all the information you need to make an order of an item of your choice. When ordering, please always state the type, the ordering or the part number.

Options

The valve is available in the following sizes: $^1/_2$ ", $^3/_4$ ", 1 ", $^1/_4$ ", $^1/_2$ " and 2 ".

- standard
- not available

| | | D06FNB |
|------------------------------------|--|--------|
| Max. operating temperature medium: | 70 °C | • |
| Filter bowl: | brass | • |
| Connection type: | external threaded connection set on in- and outlet | • |

Note: ... = space holder for connection size

Note: Ordering number example for $1^{1}/_{4}$ " and type B valve: D06FN-11/4B

Note: Special Versions available on request

Accessories

| | Descripti | on | Dimension | Part No. | | | |
|---------------|-----------|--|-----------|-------------|--|--|--|
| | M07M | Pressure gauge | | | | | |
| | | Housing diameter 63 mm, rear connection thread G ¹ / ₄ " | | | | | |
| | | Note: Please indicate upper value of pressure range when | | | | | |
| 8- | | Range: 0 - 4 bar | | M07M-A4 | | | |
| Honeywood C12 | | Range: 0 - 10 bar | | M07M-A10 | | | |
| | | Range: 0 - 16 bar | | M07M-A16 | | | |
| | | Range: 0 - 25 bar | | M07M-A25 | | | |
| | ZR06K | Double ring wrench | | | | | |
| | | For removal of spring bonnet and filter bowl | | | | | |
| | | | | ZR06K | | | |
| | | | | | | | |
| | | | | | | | |
| 6 | VST06A | SA Connection set | | | | | |
| | | Threaded connections | | | | | |
| | | | 1/2" | VST06-1/2A | | | |
| | | | 3/4" | VST06-3/4A | | | |
| | | | 1" | VST06-1A | | | |
| | | | 11/4" | VST06-11/4A | | | |
| | | | 11/2" | VST06-11/2A | | | |
| | | | 2" | VST06-2A | | | |
| ő | VST06B | Connection set | | | | | |
| | | Solder connections | | | | | |
| | | | 1/2" | VST06-1/2B | | | |
| | | | 3/4" | VST06-3/4B | | | |
| | | | 1" | VST06-1B | | | |
| | | | 11/4" | VST06-11/4B | | | |
| | | | 11/2" | VST06-11/2B | | | |
| | | | 2" | VST06-2B | | | |

Spare Parts

Pressure Reducing Valve D06FN, from 1997 onwards

| Overview | | Description | Dimension | Part No. |
|-----------------------|---|------------------------|------------------------------------|-------------|
| | 1 | Spring bonnet complete | | |
| | | | 1/2" + 3/4" | 0901513 |
| | | | 1" + 11/4" | 0900154 |
| | | | $1^{1}/_{2}" + 2"$ | 0900155 |
| | 2 | Valve insert comp | lete (without filter) | |
| | | | 1/2" + 3/4" | D06FNA-1/2 |
| | | | 1" + 1/4" | D06FNA-1 |
| | | | $1^{1}/_{2}" + 2"$ | D06FNA-11/2 |
| | 3 | Union seal washer | (10 pcs.) | |
| | | | 1/2" | 0901443 |
| Ŏ | | | 3/4" | 0901444 |
| ed with 2 | | | 1" | 0901445 |
| | | | 11/4" | 0901446 |
| d with 2 | | | 1 ¹ /2" | 0901447 |
| | | | 2" | 0901448 |
| | 4 | Blanking plug with | h O-ring R¹/₄" (5 pc | s.) |
| | | | ¹ / ₂ " - 2" | S06K-1/4 |
| \bigcirc \bigcirc | 5 | Replacement filte | | |
| | | | 1/2" + 3/4" | ES06F-1/2A |
| 4) | | | 1" + 11/4" | ES06F-1B |
| | | | $1^{1}/_{2}" + 2"$ | ES06F-11/2A |
| | 6 | O-ring set (10 pcs | .) | |
| | | | 1/2" + 3/4" | 0901246 |
| | | | 1" + 11/4" | 0901247 |
| | | | 11/2" + 2" | 0901248 |
| | 7 | Brass filter bowl w | _ | |
| | | | 1/2" + 3/4" | SM06T-1/2 |
| | | | 1" + 11/4" | SM06T-1B |
| d with 2 | | | 11/2" + 2" | SM06T-11/2 |
| | | | | |
| (5) | | | | |
| 6 | | | | |
| | | | | |

Environmental & Energy Solutions

Honeywell GmbH Hardhofweg 74821 MOSBACH GERMANY

Phone: (49) 6261 810 Fax: (49) 6261 81309

http://ecc.emea.honeywell.com

Manufactured for and on behalf of the Environmental and Combustion Controls Division of Honeywell Technologies Sàrl, Z.A. La Pièce 16, 1180 Rolle, Switzerland by its Authorised Representative Honeywell GmbH ENOH-1004GE23 R0916
Subject to change
© 2016 Honeywell GmbH

