# Wall Mount Semicircular LED Signal Towers

# SWT/ SWTE



Thank you for purchasing Qlight's products. Please read this user manual carefully prior to installation and operation to ensure safe and correct use.

#### Precautions for Safety

Failure to follow the instructions below may cause a loss of life or serious physical injury.

- 1. During wiring or maintenance, please completely turn off the power of the product. (Failure to follow this may lead to an electric shock.)
- Do not install the product in locations that subjects it to excessive dust or water other than the conditions designated by the IP protection ratings indicated for each product. (Failure to follow these instructions may cause a fire to the product, electric shock, physical injury, malfunction or damage to the product.)
- 3. Do not alter or repair this product. If maintenance or repair service is required, please contact your local Qlight contact point. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 4. Please apply the correct voltage to the product. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 5. When the product is applied to a condition that may impact lives or property, please make sure to have a double safety device. (Failure to follow this may cause damage to property, fire, electric shock and loss of life.)

#### A Precautions for Correct Use

Failure to follow the proper instructions may cause damage to property, the product, or malfunction of the product that would void the warranty.

- 1. Please remove any objects that can interrupt ventilation around the product.
- 2. Please turn off the power of the product immediately if it fails to operate properly.
- 3. Carefully wire the product according to each product's specification.
- 4. Please be careful in preventing chemicals such as thinner, benzene, etc. in contact with the surface of the product.
- 5. Do not apply excessive force/impact to the product.
- 6. Failure to follow any of the instructions above may cause malfunction or damage to the product, fire, and electric shock.

## **Ordering Specifications**

| SWTL -                        | 3          | - 220                    | - RAG      |  |
|-------------------------------|------------|--------------------------|------------|--|
| [Model<br>number]             | [Layer]    | [Voltage]                | [Color]    |  |
| I.                            | I.         | I                        | I          |  |
| SWTL                          | • 2-2Layer | • 12/24                  | • RAG-Red/ |  |
| SWTLF                         | • 3-3Layer | - DC12V-24V              | Amber/     |  |
| <ul> <li>SWTL-BZ</li> </ul>   |            | • 110 - AC110V Gre       |            |  |
| <ul> <li>SWTLF-BZ</li> </ul>  |            | • 220 - AC220V • RG-Red/ |            |  |
| SWTEL                         |            |                          | Green      |  |
| SWTELF                        |            |                          |            |  |
| <ul> <li>SWTEL-BZ</li> </ul>  |            |                          |            |  |
| <ul> <li>SWTELF-BZ</li> </ul> |            |                          |            |  |

#### **Product Specifications**

| Model<br>number                                      | Layer | Voltage   | Current        | Certificate | Weight | Color              |
|--|-------|-----------|----------------|-------------|--------|--------------------|
| SWT(E)L<br>Steady                                    |       | DC12V-24V | Max.<br>0.130A | CE          | 0.27kg | R-Red<br>G-Green   |
| SWT(E)L-BZ   | 2     | AC110V    | 0.050A         |             | 0.42kg |                    |
| Steady /<br>w built-in buzzer                        | er    | AC220V    | 0.025A         |             | 0.42kg |                    |
| SWT(E)LF<br>Steady/Flashing                          | 3     | DC12V-24V | Max.<br>0.195A | (UL)        | 0.30kg | R-Red              |
| SWT(E)LF-BZ<br>Steady/Flashing/<br>w built-in buzzer |       | AC110V    | 0.050A         |             | 0.45kg | A-Amber<br>G-Green |
|  |       | AC220V    | 0.025A         |             | 0.45kg |                    |

※ CE compliant : DC12V-24V

※ UL Listed : DC24V

• Built-in buzzer : Max.90dB at 1m


• Protection rating : IP55

Ambient operating temperature : -30°C to +50°C




Please scan the QR code for more detailed product information.

www.qlight.com





#### SWT/ SWTE



#### Wiring Instructions

- SWT series can be wired with either external contact or transistor.
- When using a transistor, please choose between the NPN transistor or PNP transistor which best matches the voltage and product type, then connect them correctly according to the wiring diagram below.
- · Product can be wired regardless of polarity.






• DC steady type cable specification: External power/ signal line - UL1007 AWG22(0.3sq) 400mm

AC steady, AC/DC steady/flashing type cable specification : External power line - UL1015 AWG18(0.75sq)×2C 400mm
 External signal line - UL1007 AWG22(0.3sq) 400mm


#### Parts Definition/ Installation



- Remove the cover ② by loosening the housing ①.
- Machine taps or holes on the mounting surface (5).
- The mounting hole of this product is 4.2mm in diameter(hole).
- When machining taps, fasten the bolt through the mounting hole of the product.
- When machining holes, insert the bolt through the hole of the product, and tighten the nut from the opposite side of the mounting surface.
- $\bullet$  Insert hook(3) under cover and press hook(4) on top of cover.

#### **Mounting Hole Specifications**

• Machine holes on the mounting surface referring to the diagram below.



SWT/ SWTE


#### Installation Environment and Protection Rating

- This product is designed for use with protection rating of IP55.
- If the product is installed in locations that subject it to excessive dust or water other than the designated IP protection rating indicated(IP55), it may cause malfunction or damage to the product.
- In case of outdoor applications, install the product in the upright position. Do not install the product horizontal or upsidedown positions where water can potentially penetrate into the product and impact it's operation.
- For further information, please visit our website (www.qlight.com).

## **Technical Certification**

• Qlight products are designed to meet strict quality and technical standards. Thus, the Qlight brand is widely recognized for its high quality and technical innovations from leading institutions around the world.





Specification and dimensions listed in this catalogue subject to change without notice for product quality improvement. The newest product information is available on our website.(www.qlight.com) Please read the instruction manual attached to the product carefully before installation and use.

#### Qlight Co., Ltd. www.qlight.com | trade@qlight.com

Head Office | Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea Tel. +82-2-2679-6152(Toll free. +82-80-328-2222) Fax. +82-2-2679-6154

Factory | 185-25, Mukbang-ro, Sangdong-myeon, Gimhae-si, Gyeongsangnamdo, Korea Tel. +82-55-328-1111(Toll free. +82-80-328-1111) Qlight OverSEAs Sales Dept | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel : +82-51-620-4100 Qlight Public Relations & Marketing Team Office | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel. +82-51-245-0017

Qlight USA, Inc. www.glight.com www.glightusa.com | sales@glightusa.com 3003 North First Street, Suite #341, San Jose, CA 95134 USA Tel. +1-408-519-5740 Fax. +1-408-519-5739

SHANGHAI Qlight Electronic Co., Ltd. www.glight.com www.glightcn.com | glightcn@glight.com China Factory/ Shanghai Sales Office | #19, Nanda Road, Baoshan Area, Shanghai, China Tel. +86-21-6651-7100 Fax. +86-21-6315-3929 China Factory Site 2 (Qidong) | #33, Haiyan Road, Qidong High-tech Industrial Development Zone, Qidong, Jiangsu Province, China Tel +86-513-8384-9999 Fax +86-513-8384-9910



Sightec Solution such as model name, symptom, telephone number and address. \*ALL PRODUCT, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE TO IMPROVE RELIABILITY FUNCTION OR DESIGN OR OTHERWISE

RELIABILITY, FUNCTION OR DESIGN OR OTHERWISE. Head office : Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea (Postal Code : 08507) Factory : 185-25, Mukbang-Ro, Sangdong-Myeon, Gimhae-Si, Gyeongsangnam-Do, Korea (Postal Code : 50805)