# Warning Lights & Electric Horns Combinations





Thank you for purchasing Qlight's products. Please read this user manual carefully prior to installation and operation to ensure safe and correct use.

### Precautions for Safety

Failure to follow the instructions below may cause a loss of life or serious physical injury.


- 1. During wiring or maintenance, please completely turn off the power of the product. (Failure to follow this may lead to an electric shock.)
- 2. Do not install the product in locations that subjects it to excessive dust or water other than the conditions designated by the IP protection ratings indicated for each product. (Failure to follow these instructions may cause a fire to the product, electric shock, physical injury, malfunction or damage to the product.)
- 3. Do not alter or repair this product. If maintenance or repair service is required, please contact your local Qlight contact point. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 4. Please apply the correct voltage to the product. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 5. When the product is applied to a condition that may impact lives or property, please make sure to have a double safety device. (Failure to follow this may cause damage to property, fire, electric shock and loss of life.)

## A Precautions for Correct Use

Failure to follow the proper instructions may cause damage to property, the product, or malfunction of the product that would void the warranty.

- 1. Please remove any objects that can interrupt ventilation around the product.
- 2. Please turn off the power of the product immediately if it fails to operate properly.
- 3. Carefully wire the product according to each product's specification.
- 4. Please be careful in preventing chemicals such as thinner, benzene, etc. in contact with the surface of the product.
- 5. Do not apply excessive force/impact to the product.

# **Ordering Specifications**





Please scan the QR code for more detailed product information.

# **Product Specifications**

### Warning Lights S100R

Model number	Voltage	Current	Bulb specifications					
			Volts/ Watts	Configuration	Part#	Certificate	Weight	Color
S100R	DC12V	0.966A	12V10W	T16x35 15S	9	CE	-	R-Red A-Amber G-Green B-Blue
	DC24V	0.566A	24V10W		10			
	AC110V	0.130A	12V10W		9		0.60kg	
	AC220V	0.065A	12V10W		9			

\* CE compliant : DC12V/24V

Protection rating : IP44(IP rating may be varied depending on configuration of the product.)

Ambient operating temperature : -20°C to + 50°C


### Dimensions




Model number	Voltage	Current	Sound pattern	Certificate	Weight
SRN	DC12V -24V	Max. 0.320A	WS - 5 Warning Sounds		0.72Kg
	AC110V	0.075A	WM - 5 Melodies WA - 5 Alarms	CE	0.98Kg
	AC220V	0.035A	WV - 5 Customiz- able sounds		0.98Kg

\* CE compliant : DC12V-24V


(Units : mm)






SC1


# Wiring Instructions





- External power line UL1007 AWG22(0.3sq) 400mm
- External signal line UL1015 AWG18(0.75sq) x 2C 400mm

### Sound Selection - Using Internal Switch (Standard Type)




Standard unit has 5 built-in sound tones.
Select different built-in sounds using the sound setting switch(①).

#### Sound Type by Group


Category	Sound pattern	Channel	Sound Tone	volume (Max.)	
		Ch1	Fire.A-ANG		
ws	E Manuality of	Ch2	Emergency WA-U	115dB	
	5 Warning sounds	Ch3	Ambulance PI-PO		
	Sounds	Ch4	Machinery Fault		
		Ch5	High Expansion		
		Ch1	Sweet Home		
	5 Melodies	Ch2	For Elise		
WM		Ch3	Cuckoo's Waltz	115dB	
		Ch4	Piano Sonata		
		Ch5	Turkish March		
WA	5 Alarms	Ch1	Beep Intermittent	113dB	
		Ch2	Door Chime		
		Ch3	Phone Ring		
		Ch4	PI.PI.PI Short		
		Ch5	Tripping Beat		
wv	5 Customiz- able sounds	Ch1- Ch5	Available upon request (customized voice type)	108dB	

# Wiring Instructions for LC Type

LC type product with exposed sound selection signal line is avaliable upon request. Please refer to the diagram below for wiring.



#### EXTERNAL TRANSISTOR-NPN



• External power line - UL1007 AWG22(0.3sq) 400mm

- External signal line UL1015 AWG18(0.75sq) x 2C 400mm
- This product can be wired regardless of polarity.

# Volume Adjustment



• The volume output of this product is adjustable.

- Turn the volume dial clockwise to increase the volume, and turn counter clockwise to decrease the volume.
- There will be no sound when the dial is put at MIN.

### Precautions for installation

 In case of outdoor applications, install the product in the upright position. Do not install the product horizontal or upside-down positions where water can potentially penetrate into the product and impact it's operation.



Reverse direction




Right direction



[Installation]

### Parts Definition/ Installation/ Adjusting the Angle of the Horn housing



#### Installation

- First, machine taps or holes on the mounting surface.
- The mounting hole of this product is 9mm in diameter(hole).
- When machining taps, fasten the bolt through the mounting hole of the product.
- When machining holes, insert the bolt through the hole of the product, and tighten the nut from the opposite side of the mounting surface
- When assembling using bolt and nut, please make sure to use flat washer and spring washer.


#### Adjusting the Angle of the Horn housing

• When adjusting the phase and lower angle of the mixed housing (signalling angle) after product cancellation Loosen the bracket fixing bolts on the side of the product slightly to adjust the desired angle.


### Mounting Hole Specifications/ Bulb Replacement Instructions

#### ■Mounting Hole Specifications

• Machine holes on the mounting surface referring to the diagram below.



#### Bulb Replacement Instructions




- Please wait at least 1 minute after turning off the power before replacing the bulb.
- Lightly press the light bulb(①) and turn it counterclockwise, then the light bulb is removed from the socket(②).
- In order to put the bulb in to the unit, please place the bulb(①) in the socket(②) and screw it clockwise while lightly pushing down the bulb.

### Installation Environment and Protection Rating

- This product is designed for use with protection rating of IP44(IP rating may be varied depending on configuration of the product).
- If the product is installed in locations that subject it to excessive dust or water other than the designated IP protection rating indicated(IP44), it may cause malfunction or damage to the product.
- For further information, please visit our website (www.qlight.com).

# **Technical Certification**

• Qlight products are designed to meet strict quality and technical standards. Thus, the Qlight brand is widely recognized for its high quality and technical innovations from leading institutions around the world.





Specification and dimensions listed in this catalogue subject to change without notice for product quality improvement. The newest product information is available on our website.(www.qlight.com) Please read the instruction manual attached to the product carefully before installation and use.

#### Qlight Co., Ltd. www.qlight.com | trade@qlight.com

Head Office | Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea Tel. +82-2-2679-6152(Toll free. +82-80-328-2222) Fax. +82-2-2679-6154

Factory | 185-25, Mukbang-ro, Sangdong-myeon, Gimhae-si, Gyeongsangnamdo, Korea Tel. +82-55-328-1111(Toll free. +82-80-328-1111) Qlight OverSEAs Sales Dept | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel : +82-51-620-4100 Qlight Public Relations & Marketing Team Office | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel. +82-51-245-0017

Qlight USA, Inc. www.glight.com www.glightusa.com | sales@glightusa.com 3003 North First Street, Suite #341, San Jose, CA 95134 USA Tel. +1-408-519-5740 Fax. +1-408-519-5739

SHANGHAI Qlight Electronic Co., Ltd. www.glight.com www.glightcn.com | glightcn@glight.com China Factory/ Shanghai Sales Office | #19, Nanda Road, Baoshan Area, Shanghai, China Tel. +86-21-6651-7100 Fax. +86-21-6315-3929 China Factory Site 2 (Qidong) | #33, Haiyan Road, Qidong High-tech Industrial Development Zone, Qidong, Jiangsu Province, China Tel +86-513-8384-9999 Fax +86-513-8384-9910



Sightec Solution such as model name, symptom, telephone number and address. \*ALL PRODUCT, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE TO IMPROVE RELIABILITY FUNCTION OR DESIGN OR OTHERWISE

RELIABILITY, FUNCTION OR DESIGN OR OTHERWISE. Head office : Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea (Postal Code : 08507) Factory : 185-25, Mukbang-Ro, Sangdong-Myeon, Gimhae-Si, Gyeongsangnam-Do, Korea (Postal Code : 50805)