
# Explosion Proof Bulb Revolving Warning Light with Siren Buzzer SNES/ SNESL/ SNESLR/ SNES-S



Thank you for purchasing Qlight's products. Please read this user manual carefully prior to installation and operation to ensure safe and correct use.

### Safety Precautions for Explosion Proof Products

Please follow the instruction below to ensure safe and correct use of explosion proof products.

- 1. Explosion proof products should be managed according to explosion proof regulations. Do not disassemble, assemble, alter or repair the product arbitrarily.
- 2. The temperature rating of the product is the temperature the product will experience at the applied rated voltage and ambient temperature indicated.
- 3. Use cable glands that satisfy the product's explosion proof grade and temperature grade.
- 4. Unused cable entries must be filled with material that meets the explosion proof grade and temperature rating.
- 5. Before installing the product, please make sure all cautions indicated on the labels, packaging, and operation manual of the product are fully understood.
- 6. Installation, maintenance and repair of the product must be performed by experts in the explosion proof field, or persons who have received relevant training.
- 7. For safety, the product should be installed and operated in environments that avoid high temperature and high pressure.
- 8. Please follow general safety precautions and avoid installing the product in locations that may generate excessive heat.
- 9. When installing the product in places where chemicals are located, please make sure that the environment does not have two or more incompatible chemicals mixed. For safety, please read the instruction manual carefully and be mindful of the chemical compositions where the product is used.
- 10. This product requires grounding.
- 11. Please note that special conditions shall be applied if the sign "X" is placed after the certificate number.1) For safe use, regular overpressure test must be carried out in accordance with EN 60079-1, clause 15.2.3.2) For safe use, tempered glass must be protected from strong impact
- 12. When using NPT cable glands (plugs), it is recommended to use them after applying non-hardening grease to maintain protective performance.

## Precaution for Safety

Failure to follow the instructions below may cause a loss of life or serious physical injury.

- 1. During wiring or maintenance, please completely turn off the power of the product. (Failure to follow this may lead to an electric shock.)
- Do not install the product in locations that subjects it to excessive dust or water other than the conditions designated by the IP protection ratings indicated for each product. (Failure to follow these instructions may cause a fire to the product, electric shock, physical injury, malfunction or damage to the product.)
- 3. Do not alter or repair this product. If maintenance or repair service is required, please contact your local Qlight contact point. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 4. Please apply the correct voltage to the product. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 5. When the product is applied to a condition that may impact lives or property, please make sure to have a double safety device. (Failure to follow this may cause damage to property, fire, electric shock and loss of life.)

# A Precautions for Correct Use

Failure to follow the proper instructions may cause damage to property, the product, or malfunction of the product that would void the warranty.


- 1. Please remove any objects that can interrupt ventilation around the product.
- 2. Please turn off the power of the product immediately if it fails to operate properly.
- 3. Carefully wire the product according to each product's specification.
- 4. Please be careful in preventing chemicals such as thinner, benzene, etc. in contact with the surface of the product.
- 5. Do not apply excessive force/impact to the product.
- 6. Failure to follow any of the instructions above may cause malfunction or damage to the product, fire, and electric shock.



Please scan the QR code for more detailed product information.

www.qlight.com

# **Ordering Specifications**



# **Product Specifications**

#### Explosion Proof Specifications


•			
SNES	Zone	Zone 1	High risk gas/vapour(Gas)
SNESL	definitions(Gas)	Zone 2	Medium risk gas/vapour(Gas)
SNESLR	Group definitions(Gas)		Acetone, Petrol, Methanol, Propane, Toluene
SNES-S			Acetone, Fettor, Methanor, Fropane, Toldene
DC 12V or 24V		GROUP II B	Ethylene, City gas
AC 110V or 220V		GROUP II C	Hydrogen, Acetylene, Carbon sulphide
IECEX - Ex db IIC T6 Gb,	Maximum surface temperature of electrical equipment	T1	450°C
ATEX – (©)II2G Ex db IIC T6 Gb, Ex db op is IIC T6 Gb (with LED) NEPSI, CCC - Ex db IIC T6 Gb, IP66 KCs - Ex d IIB+H2 T6 IP66 TIIS - Ex d IIC T6 Gb, IP66 (SNESLR DC12/24V, AC110V		T2	300°C
		Т3	200°C
	Zone definitions(Dust)	T4	135°C
		T5	100°C
	Group definitions(Dust)	T6	85°C
-40°C ≤ Ta ≤ 55°C(KCs) -40°C ≤ Ta ≤ 60°C -20°C ≤ Ta ≤ 55°C(TIIS)		Zone 21	High risk powder/dust(Dust)
	dominiono(Buoty	Zone 22	Medium risk powder/dust(Dust)
	Group definitions(Dust)	GROUP II A	Ignitible fibers/flyings(more than 0.5mm)
Zone1, Zone2		GROUP II B	Non-conductive dusts
IP66		GROUP II C	Conductive dusts
	$\begin{array}{l} SNESL \\ SNESLR \\ SNES-S \\ DC 12V or 24V \\ AC 110V or 220V \\ IECEX - Ex db IIC T6 Gb, \\ Ex db op is IIC T6 Gb (with LED) \\ ATEX -  \textcircled{Sll2G Ex db IIC T6 Gb}, \\ Ex db op is IIC T6 Gb (with LED) \\ ATEX -  \textcircled{Sll2G Ex db IIC T6 Gb, IP66} \\ KCs - Ex d IIB+H2 T6 IP66 \\ TIIS - Ex d IIC T6 Gb, IP66 \\ (SNESLR DC12/24V, AC110V only) \\ -40^\circC \leq Ta \leq 55^\circC(KCs) \\ -40^\circC \leq Ta \leq 55^\circC(TIIS) \\ Zone1, Zone2 \\ \end{array}$	SNESLZone definitions(Gas)SNESLRGroup definitions(Gas)DC 12V or 24V AC 110V or 220VGroup definitions(Gas)IECEX - Ex db IIC T6 Gb, Ex db op is IIC T6 Gb (with LED) ATEX – 🐼 II2G Ex db IIC T6 Gb, IP66 KCs - Ex d IIB+H2 T6 IP66 TIIS - Ex d IIC T6 Gb, IP66 (SNESLR DC12/24V, AC110V only)Maximum surface temperature of electrical equipment-40°C $\leq$ Ta $\leq$ 55°C(KCs) -20°C $\leq$ Ta $\leq$ 55°C(TIIS)Group definitions(Dust)Zone 1, Zone2Group definitions(Dust)	SNESLZoneZone 2SNESLRGROUP II ASNES-SGroup definitions(Gas)GROUP II ADC 12V or 24V AC 110V or 220VGroup definitions(Gas)GROUP II BIECEX - Ex db IIC T6 Gb, Ex db op is IIC T6 Gb (with LED) ATEX - $\textcircled{S}$ )I2G Ex db IIC T6 Gb, P66 KCs - Ex d IIB+H2 T6 IP66 TIIS - Ex d IIC T6 Gb, IP66 (SNESLR DC12/24V, AC110V only)Maximum surface temperature of electrical equipmentT1ZoneT4ZoneT4definitions(Dust)T5Group definitions(Dust)T6Group definitions(Dust)Zone 21Zone 22-40°C < Ta < 55°C(TIIS)


#### ■ General Product Specification

Model number	Voltage	Current	Bulb specifications		Sound pattern and	Certificate	\A/aimht	Calar	
			Volts/Watts	Configuration	Part#	volume	Certificate	Weight	Color
SNES	DC12V	1.766A	12V15W	G23 15S	17	• Warning sound (Buzzer) : Max.105dB	IFCEX ATEX CCS	3.70kg	R-Red A-Amber G-Green B-Blue
	DC24V	1.044A	24V15W	G23 15S	18				
	AC110V	0.288A	12V15W	G23 15S	17			4.40kg	
	AC220V	0.144A	12V15W	G23 15S	17				
SNES-S	DC12V	0.655A		BGA2120 -BBC I type	47			3.60kg	
	DC24V	0.500A	200V						
	AC110V	0.104A	-350V					4.25kg	
	AC220V	0.066A		.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					

Model number	Voltage	Current	Sound pattern and volume	Certificate	Weight	Color
SNESL	DC12V	0.432A			3.15kg	R-Red A-Amber G-Green B-Blue
	DC24V	0.377A		IECEX EX COS		
	AC110V	0.111A			3.85kg	
	AC220V	0.055A	• Warning sound			
SNESLR	DC12V	0.485A	(Buzzer) : Max.105dB		3.65kg	
	DC24V	0.411A				
	AC110V	0.111A			1.201/2	
	AC220V	0.055A			4.30kg	

#### SNES/ SNESL/ SNESLR/ SNES-S






# 4-Ø8 FITTING HOLES 114


# Parts Definition/ Installation/ Light Function Selection


#### Parts Definition



#### Light Function Selection(SNESL only)

• Please refer to the chart below to use light function selection switch located inside the product.






· Default function is set at steady LED. Select the desired function for your application during installation.

#### Installation


- First, machine holes on the mounting surface ①.
- The mounting hole of this product is 8mm in diameter.
- When machining taps, fasten the bolt through the mounting hole of the bracket.
- When machining holes, insert the bolt through the hole of the product, and tighten the nut from the opposite side of the mounting surface.


# **Terminal Box Wiring Instructions**



## **Mounting Hole Specifications**

 Machine holes on the mounting surface referring to the diagram below.






Grounding Instructions

M4 ground contact part

- Please use an M4 bolt at the location marked in the diagram above to ground the product.
- When connecting the grounding cable, please use a ring terminal.
- Please use a grounding cable with a diameter greater than 4mm.

### **Bulb/ Xenon Bulb Replacement Instructions**


Bulb Replacement Instructions(SNES only)



- Please wait at least 1 minute after turning off the power before replacing the bulb.
- In order to dissemble the bulb, please push down the bulb(①) lightly and screw it counterclockwise.
- In order to put the bulb in to the unit, please place the bulb(①) in the socket(②) and screw it clockwise while lightly pushing down the bulb.

## Installation Environment and Protection Rating

Xenon Bulb Replacement Instructions(SNES-S only)



- Please wait at least 30 minutes after turning off the power before replacing the xenon bulb.
- Please pull out the entire xenon bulb structure ① to disassemble while pushing the hook down.
- For xenon bulb assembly, please push down the connector portion of the xenon bulb structure to the connector pin location (2) until it makes "clark" sound.


- This product is designed to be explosion proof.
- Please make sure to use the product in an environment that meets the specified explosion proof rating and regulations.
- For further information, please visit our website (http://www.qlight.com).

# Product installation direction

#### Install the product in accordance with the manual. Otherwise rainwater or moisture may penetrate into the product.


· BEACON/SIGNALING LIGHT


\* For products with a protection rating of less than IPX4, please install it vertically.



· ELECTRONIC SOUNDER/SIGNAL HORN

Sounder part shall not be facing the sky.














#### · HEAVY-DUTY & EXPLOSION PROOF SIGNALINGS

Sounder part shall not be facing the sky.







· SIGNAL TOWER LIGHTS

Power cord inlet part shall not be facing the sky.

\* For products with a protection rating of less than IPX4, please install it vertically.



Specification and dimensions listed in this catalogue subject to change without notice for product quality improvement. The newest product information is available on our website.(www.qlight.com) Please read the instruction manual attached to the product carefully before installation and use.

#### Qlight Co., Ltd. www.qlight.com | trade@qlight.com

Head Office | Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea Tel. +82-2-2679-6152(Toll free. +82-80-328-2222) Fax. +82-2-2679-6154

Factory | 185-25, Mukbang-ro, Sangdong-myeon, Gimhae-si, Gyeongsangnamdo, Korea Tel. +82-55-328-1111(Toll free. +82-80-328-1111) Qlight OverSEAs Sales Dept | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel : +82-51-620-4100 Qlight Public Relations & Marketing Team Office | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel. +82-51-245-0017

Qlight USA, Inc. www.glight.com www.glightusa.com | sales@glightusa.com 3003 North First Street, Suite #341, San Jose, CA 95134 USA Tel. +1-408-519-5740 Fax. +1-408-519-5739

SHANGHAI Qlight Electronic Co., Ltd. www.qlight.com www.qlightcn.com | qlightcn@qlight.com China Factory/ Shanghai Sales Office | #19, Nanda Road, Baoshan Area, Shanghai, China Tel. +86-21-6651-7100 Fax. +86-21-6315-3929 China Factory Site 2 (Qidong) | #33, Haiyan Road, Qidong High-tech Industrial Development Zone, Qidong, Jiangsu Province, China Tel +86-513-8384-9999 Fax +86-513-8384-9910



Sightec Solution such as model name, symptom, telephone number and address. \*ALL PRODUCT, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE TO IMPROVE RELIABILITY FUNCTION OR DESIGN OR OTHERWISE

RELIABILITY, FUNCTION OR DESIGN OR OTHERWISE. Head office : Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea (Postal Code : 08507) Factory : 185-25, Mukbang-Ro, Sangdong-Myeon, Gimhae-Si, Gyeongsangnam-Do, Korea (Postal Code : 50805)