



Accessories for
Multi-function Meters of Electrical System Parameters

Expand the range of applications



measurements



test leads



installation



communication



software



power supply



transportation

Sonel[®] we measure globally



measurements

PV system measurements

A test instrument is not sufficient to perform photovoltaic system measurements - accessories dedicated for this type of systems are also needed.



PVM-1 adapter

index: WAADAPVM1

Necessary to conduct selected measurements in photovoltaic systems. Short-circuits a circuit under voltage (DC). Moreover, it protects the user from electric arc.

Accessory dedicated for:

MPI-540-PV



MC4-banana sockets adapter

index: WAADAMC4

Connects banana jacks of the test instrument with the PV system utilizing MC4 connectors. The kit consists of 2 adapters.

Accessories dedicated for:

MPI-540-PV

PVM-1020 KIT



MC4 splitter

index: WAADAMC4SKPL

Connects banana jacks of the test instrument with the PV system utilizing MC4 connectors. Enables power measurement. The kit consists of 2 splitters.

Accessories dedicated for:

MPI-540-PV

PVM-1020 KIT

Solar radiation measurement



IRM-1 meter

index: WMGBIRM1

IRM-1, small, but indispensable for testing PV systems. By measuring solar radiation values, as well as panel and ambient temperatures, it provides the necessary data to convert the results into STC conditions. The kit consists of:

- IRM-1 solar radiation and temperature meter,
- IRM-1 mounting&measuring set,
- Z-24 power supply, M14 carrying case.

Accessory dedicated for:

PVM-1020

PVM-1020 KIT

Solar radiation measurement set

index: WMGBIRM1MPI

It enables cooperation between the IRM-1 and the MPI-540-PV meter. The kit consists of:

- IRM-1 solar radiation and temperature meter,
- IRM-1 mounting&measuring set,
- LORA-S1 adapter for data transmission,
- Z-24 power supply, M14 carrying case.

Accessories dedicated for:

MPI-540-PV



Mounting the solar radiation meter



IRM-1 mounting&measuring set

index: WASONTPVCKPL

The set is used to attach the IRM-1 meter to the PV panel. It consists of:

- IRM-1 mounting kit for PV panels,
- probe for measuring the temperature of PV panels and the ambient temperature.

Accessories dedicated for:

MPI-540-PV

IRM-1

PVM-1020 KIT



IRM-1 mounting kit for PV panels

index: WAPOZUCHPV

The set is used to attach the IRM-1 meter to the PV panel. It consists of:

- mounting frame,
- mounting clamp.

Accessories dedicated for:

MPI-540-PV

IRM-1

PVM-1020 KIT



Mounting clamp

index: WAZACPV

Presses the mounting frame to the PV panel.

Accessory dedicated for:

MPI-540-PV

IRM-1

PVM-1020 KIT



Temperature measurement probe

index: WASONTPVC


Thanks to two sensors, the probe measures the temperature of a photovoltaic panel and the ambient temperature. It is attached to the mounting frame.

Accessory dedicated for:

MPI-540-PV

IRM-1

PVM-1020 KIT





measurements



EVSE-01 adapter

index: WAADAEVSE01

Adapter allows to perform comprehensive **measurements of electric vehicle charging stations** - quickly and in accordance with applicable regulations. Simulating the charging cable (proximity pilot line - PP) and vehicle connection status (control pilot line - CP), it will bring the station into different operating states. This will enable **measurements in the field of electric shock protection**: Z_s fault loop impedance, R_{iso} insulation resistance and checking the parameters of RCD residual current devices. To facilitate diagnostics, one of the EVSE-01 sockets is provided with pulse width modulation signal (PWM).

The EVSE-01 adapter enables measurements of AC electric vehicle charging stations with **type 2 connector**. Tests for 1-phase and 3-phase stations are available - both with and without ventilation.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530


MPI-525

MPI-520

MPI-507

MPI-506

MPI-502F



TWR-1J adapter

index: WAADATWR1J

Adapter for testing residual current devices not installed and not operating in the electrical system. The device cooperates with any Sonel test instrument with implemented measurements of RCD parameters.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520

MPI-507

MPI-506

MPI-502F

MRP-201



AC-16 line splitter

index: WAADAAC16

AC-16 has been designed to simplify current and voltage measurements: it eliminates the need to remove the electrical sockets. It is dedicated for use in earthed networks. The unit is equipped with a 1:1 (X1) ratio and 10:1 (X10) ratio. The maximum current load is 16 A. The adapter can be used with any type of clamps offered by SONEL S.A.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-530-IT

MPI-530

MPI-520

PVM-1020 KIT



Measurements of multi-core cables

Depending on the measurement facility and the established standards (each conductor to each or conductor to other shorted and grounded conductors), the measurement of the insulation resistance of wires or multi-core cables requires several connections. In order to shorten the measurement time and eliminate the inevitable connection errors, Sonel recommends an adapter that switches between individual pairs of conductors for the operator.



AutoISO-1000C adapter

index: WAADAAISO10C

Designed to measure the insulation resistance of cables and multi-core wires with a measuring voltage of up to 1000 V. The use of the adapter eliminates the possibility of making a mistake, and significantly reduces the time needed to measure the insulation resistance between pairs of conductors. For instance, for 4-core cables, the user will perform only one connection operation (i.e. connect the adapter to the facility), while AutoISO-1000C will perform crossing for six consecutive connections.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-535

MPI-530-IT

MPI-530

MPI-520



AutoISO-2500 adapter

index: WAADAAISO25

Designed to measure the insulation resistance of cables and multi-core wires with a measuring voltage of up to 2500 V. The use of the adapter eliminates the possibility of making a mistake, and significantly reduces the time needed to measure the insulation resistance between pairs of conductors. For instance, for 4-core cables, the user will perform only one connection operation (i.e. connect the adapter to the facility), while AutoISO-2500 will perform crossing for six consecutive connections.

Accessory dedicated for:

MPI-536

MPI-525





measurements

Adapters for 230 V sockets

Type WS adapters are highly valued and practical accessories. They enable user a quick and easy measurement in a UNI-Schuko socket without the use of probes or measuring cords. Interaction with the measuring device is possible through a multi-plug connector. Depending on the type and model, we can use a straight or angled plug. By means of a dedicated button on the housing, some adapters have the function of automatic measurement triggering and saving the result to the memory.

| Name | Features | Index |
|-------|--|-----------|
| WS-01 | Triggering the measurement, UNI-Schuko straight plug | WAADAWS01 |
| WS-03 | Triggering the measurement, UNI-Schuko straight plug | WAADAWS03 |
| WS-04 | Not triggering the measurement, UNI-Schuko angled plug | WAADAWS04 |
| WS-05 | Not triggering the measurement, UNI-Schuko angled plug | WAADAWS05 |



Accessories dedicated for:



WS-01 adapter

- MPI-502F
- MRP-201



WS-03 adapter

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535
- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520
- MPI-507
- MPI-506
- MPI-502F




WS-04 adapter

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535
- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520
- MPI-507
- MPI-506
- MPI-502F



WS-05 adapter

- MPI-502F
- MRP-201



AGT-16T adapter



AGT-32P adapter



AGT-63P adapter

Industrial socket adapters

Adapters enabling the connection of instruments to single-phase or three-phase sockets in industry environments. Offered in three current load versions – 16 A, 32 A and 63 A – as well as variants with 4 and 5 pins for the 3-phase outlets.

| Name | Intended use | Index |
|---------|-------------------------------|-------------|
| AGT-16T | 16 A, 1-phase, 3-pole sockets | WAADAAGT16T |
| AGT-16C | 16 A, 3-phase, 4-pole sockets | WAADAAGT16C |
| AGT-16P | 16 A, 3-phase, 5-pole sockets | WAADAAGT16P |
| AGT-32T | 32 A, 1-phase, 3-pole sockets | WAADAAGT32T |
| AGT-32C | 32 A, 3-phase, 4-pole sockets | WAADAAGT32C |
| AGT-32P | 32 A, 3-phase, 5-pole sockets | WAADAAGT32P |
| AGT-63P | 63 A, 3-phase, 5-pole sockets | WAADAAGT63P |

Accessories dedicated for:

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535
- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520
- MPI-507
- MPI-506
- MPI-502F
- MRP-201
- PVM-1020 KIT





Voltage adapters

index: WAADAM4M64

They enable the test instrument to be connected directly to the terminal block in the electrical switchboard. Each adapter has M4 / M6 thread. Versatility of this solution is unique on the global scale. The set includes 4 adapters.

Accessories dedicated for:

MPI-540-PV

MPI-540



Illuminance measurements

LP probes cooperate with test instruments via a multi-plug connector. They enable measurements of illuminance with different resolution and in a different class, depending on the probe used.

LP-1 light meter probe

index: WAADALP1

| | |
|-------------------|-------------|
| Class | B |
| Resolution | from 0.1 lx |

LP-10B light meter probe

index: WAADALP10B

| | |
|-------------------|--------------|
| Class | B |
| Resolution | from 0.01 lx |

LP-10A light meter probe

index: WAADALP10A

| | |
|-------------------|---------------|
| Class | A |
| Resolution | from 0.001 lx |

WS-06 adapter

index: WAADAWS06

Sonel miniDIN-multi-plug lead. Dedicated for the connection of a light meter probe with the test instrument.

Set: light meter probe+adapter

Includes measurement probe and WS-06 adapter.

| Set | Index |
|--|---------------|
| LP-1 light meter probe + WS-06 adapter | WAADALP1KPL |
| LP-10B meter probe + WS-06 adapter | WAADALP10BKPL |
| LP-10A meter probe + WS-06 adapter | WAADALP10AKPL |

Accessories dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530





measurements



Flexible coil

Flexible current coil, also known as a Rogowski coil, is useful for testing objects, on which hard clamps cannot be attached. The coil is terminated with a 5-pin plug. It is available with different levels of the output signal and different lengths.

| Name | Max. diameter of measured conductor | Output signal level | Index |
|------|-------------------------------------|---------------------|-------------|
| F-1A | 360 mm | 38.8 μ V / 1 A | WACEGF1AOKR |
| F-2A | 235 mm | | WACEGF2AOKR |
| F-3A | 120 mm | | WACEGF3AOKR |

Accessories dedicated for:

MPI-540-PV

MPI-540

MPI-530-IT

MPI-530



Current clamps

Split-Core current clamps are used for measuring alternating and direct currents. They are available in four variants of different diameters of the clamped conductor and the type of current to be measured. All models are terminated with a 5-pin connector.

| Name | Diameter | Rated current | Type of current | Index |
|------|---------------------|---------------|-----------------|-------------|
| C-4A | \varnothing 52 mm | 1000 A | AC | WACEGC4AOKR |
| C-5A | \varnothing 39 mm | 1000 A | AC/DC | WACEGC5AOKR |
| C-6A | \varnothing 20 mm | 10 A | AC | WACEGC6AOKR |
| C-7A | \varnothing 24 mm | 100 A | AC | WACEGC7AOKR |
| C-PV | \varnothing 30 mm | 40 A / 400 A | AC/DC | WACEGCPVOKR |

Accessories dedicated for:



C-4A current clamp

MPI-540-PV

MPI-540



C-5A current clamp

MPI-540-PV

MPI-540



C-6A current clamp

MPI-540-PV

MPI-540

MPI-530-IT

MPI-530



C-7A current clamp

MPI-540-PV

MPI-540



C-PV current clamp

MPI-540-PV

PVM-1020 KIT





C-3 current clamp

index: WACEGC30KR

The clamp is used to measure alternating currents. The maximum diameter of the tested conductor is 52 mm. It is terminated with a 5-pin plug, compatible with Sonel devices. Using of the clamp eliminates the need to disconnect control connections, significantly reducing the testing time. This clamp allows user to determine the type of current flowing through the tested earthing element and to check the resulting voltage drop.

Accessory dedicated for:

MPI-540-PV

MPI-540


MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-520



N-1 transmitting clamp

index: WACEGN1BB

The transmitting clamp is used to measuring current for earth resistance measurements. Together with C-3 current clamp (hard) they are used in the two-clamp method, and in many cases they eliminate the need for driving the auxiliary probes into the ground. The maximum diameter of the tested conductor is 52 mm. The clamp is powered by a removable two-wire lead, terminated with 4 mm banana plugs.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530



Test lead for N-1 clamp

index: WAPRZ002DZBB

Two-wire test lead with a length of 2 meters. It connects N-1 transmitting clamp with measuring terminals of the meter used for earth resistance measurements.

The test lead is factory-fitted with two pairs of „H” and „E” tags, which indicate the correct way of connecting it to the meter terminals and clamps.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530



Adapter for C-PV clamp

index: WAADACPV

The cable serves as an adapter connecting the C-PV clamp with the test socket of the test instrument.

Accessory dedicated for:

MPI-540-PV



measurements

Pin probes

Secure pin probes with \varnothing 4 mm socket, intended for test leads with plugs and a guard. The probe insulated tips with a length of 4 mm, ensure safe measurements on a various objects. The probes have a guard ring and a grooved surface, providing stable and secure hand grip - also with dielectric gloves.



Pin probes 1 kV

| | |
|-----------------------------|-----------------|
| Plug | banana, 4 mm |
| Measurement category | 1000 V, CAT III |
| Maximum current | 20 A |

| Color | Index |
|-------|-------------|
| Black | WASONBLOGB1 |

Accessories dedicated for:

PVM-1020 KIT

| Color | Index |
|-------|-------------|
| Blue | WASONBUOGB1 |

Accessories dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520

MPI-507

MPI-506

MPI-502F

MRP-201

| Color | Index |
|--------|-------------|
| Red | WASONREOGB1 |
| Yellow | WASONYEOGB1 |

Accessories dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520


MPI-507

MPI-506

MPI-502F

MRP-201

PVM-1020 KIT



Pin probes 5 kV


| | |
|-----------------------------|-----------------|
| Plug | banana, 4 mm |
| Measurement category | 5000 V, CAT III |
| Maximum current | 32 A |

| Color | Index |
|-------|-------------|
| Black | WASONBLOGB2 |
| Red | WASONREOGB2 |

Accessories dedicated for:

MPI-536

MPI-525





Foldable pin probe

index: WASONSP2M


The probe is used to measure the short circuit loop impedance of lighting fixtures or other objects that are out of reach of the hand. It can also be used to measure the insulation resistance of objects up to 1 kV.

The probe is adjustable in length from 1 to 2 m. The measuring tip fits into a 16 A three-phase socket.

| | |
|-----------------------------|-----------------|
| Plug | banana, 4 mm |
| Measurement category | 1000 V, CAT III |

Accessory dedicated for:

| | | | |
|------------|---------|----------|---------|
| MPI-540-PV | MPI-540 | MPI-536 | MPI-535 |
| MPI-530-IT | MPI-530 | MPI-525 | MPI-520 |
| MPI-507 | MPI-506 | MPI-502F | MRP-201 |




Adapter with pin probe

index: WAADAWS09

The WS-09 adapter is an automatic three-wire pin probe. It provides much faster measurements by its start button located on the adapter housing. The adapter also has a button that allows user to save the measurement result in the memory of the meter. The probe used during measurements in electrical installations reduces to a minimum the operations performed on the meter itself, significantly improving the efficiency of work.

Accessory dedicated for:

| | | | |
|------------|---------|---------|---------|
| MPI-540-PV | MPI-540 | MPI-536 | MPI-535 |
|------------|---------|---------|---------|





measurements

Earth contact test probes (rods)

The test probes are designed for measuring earth resistance with 3- and 4-wire method. The probes are made of impact-resistant alloy and have an opening for direct connection of test leads with plugs without a guard.



25 cm rod



30 cm rod



80 cm rod

| Type | Length | Index |
|----------|--------|----------|
| Straight | 25 cm | WASONG25 |

Accessories dedicated for:

MPI-507

| Type | Length | Index |
|-----------------------------|--------|------------|
| Straight with a reel holder | 30 cm | WASONG30 |
| Straight with a reel holder | 80 cm | WASONG80V2 |

Accessories dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520

MPI-507





PRS-1 probe

index: WASONPRS1

If the site insulation is used as a means of protection against electric shock, the insulation resistance of floors and walls should be checked with an appropriate measuring instrument using a probe dedicated for this purpose.

PRS-1 has the shape of an equilateral triangle and has been made according to the guidelines provided in for in the HD 60364-6 and EN 1081 standards. Legs of the probe were made with a special rubber mix – volume resistance of a single leg does not exceed 5 k Ω , and the hardness is in the range between 50 to 70 IRHD. With appropriate pressure on the probe, such a design solution will ensure approx. 900 mm² contact surface area with the tested plane.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520



Adapter for impedance measurement

index: WAADAWS07

Sonel adapter for measuring loop impedance Z_{L-N}

Accessory dedicated for:

MPI-507

MPI-506

MPI-502F





measurements



Crocodile clips 1 kV

Secure, insulated crocodile clips with Ø 4 mm socket, intended for connecting test leads with plugs and a guard. Their jaws have a wide range of opening that enables them to be attached to conductors with a diameter of 16 mm. In addition to the serrated jaw surface, the clips have flat surfaces for grasping small objects. They are available in many colors.

| | |
|-----------------------------|-----------------|
| Plug | banana, 4 mm |
| Spread range | 25 mm |
| Measurement category | 1000 V, CAT III |
| Maximum current | 20 A |
| Color | Index |
| Black | WAKROBL20K01 |

Accessory dedicated for:

- [MPI-540-PV](#)
- [MPI-540](#)
- [MPI-525](#)
- [PVM-1020 KIT](#)

| | |
|--------------|--------------|
| Color | Index |
| Red | WAKRORE20K02 |
| Yellow | WAKROYE20K02 |


Accessories dedicated for:

- [MPI-540-PV](#)
- [MPI-540](#)
- [MPI-536](#)
- [MPI-535](#)
- [MPI-530-IT](#)
- [MPI-530](#)
- [MPI-525](#)
- [MPI-520](#)
- [MPI-507](#)
- [MPI-506](#)
- [MPI-502F](#)
- [MRP-201](#)
- [PVM-1020 KIT](#)

| | |
|--------------|--------------|
| Color | Index |
| Blue | WAKROBU20K02 |

Accessories dedicated for:

- [MPI-540-PV](#)
- [MPI-540](#)
- [MPI-536](#)
- [MPI-535](#)
- [MPI-530-IT](#)
- [MPI-530](#)
- [MPI-525](#)
- [MPI-520](#)
- [MPI-507](#)
- [MPI-506](#)
- [MPI-502F](#)
- [MRP-201](#)



Crocodile clips 11 kV

Secure, insulated crocodile clips with Ø 4 mm socket, intended for connecting test leads with plugs and a guard. Their jaws have a wide range of opening that enables them to be attached to conductors with a diameter of 43 mm. In addition to the serrated jaw surface, the clips have flat surfaces for grasping small objects. They are available in many colors.

| | |
|-----------------------------|-----------------|
| Plug | banana, 4 mm |
| Spread range | 43 mm |
| Measurement category | 11000 V, CAT IV |
| Maximum current | 32 A |
| Color | Index |
| Black | WAKROBL32K09 |
| Red | WAKRORE32K09 |

Accessories dedicated for:

- [MPI-536](#)
- [MPI-525](#)





Cramp

index: WAZACIMA1

Professional cramp designed for use in situations when strong and durable metal connection is required. The cramp is provided with a thumbscrew for secure tightening it to the object. The terminal with a diameter of 4 mm is compatible with test leads with plugs and a guard.

| | |
|---------------------|--------------|
| Plug | banana, 4 mm |
| Spread range | 50 mm |

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520

MPI-507



CS-1 cable simulator

index: WAADACS1

Designed for insulation resistance simulation of power cables. Equipped with highly accurate resistors. Intended for training, presentation and auxiliary purposes – for instance in a situation, where general estimation of the measurement correctness is needed.

CS-1 enables the measurement of four resistance values and their combination. The device utilizes 4 mm banana plugs. Its casing is characterized by high resistance to mechanical damage.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520



CS-5kV calibration box

index: WAADACS5KV

The calibration box has been designed to verify indications of insulation resistance meters. The use of high-quality resistors with a very high degree of accuracy makes the CS-5kV an ideal tool for cooperation with devices with a test voltage of up to 5 kV DC.


The box enables the measurement of four resistance values and their combination. The device utilizes 4 mm banana plugs.

Accessory dedicated for:

MPI-536

MPI-525





test leads

Test leads

Universal test leads, which are safe and resistant to damage. They can be used with a wide range of measuring accessories, such as crocodile clips, probes or cramps. The plug of the test lead is shielded ensuring safe operation.



Test leads 1 kV

| | | |
|---------------------------------------|---|--|
| Plug | banana, 4 mm, safe, straight, nickel plated | |
| Measurement category | CAT III 1000 V / CAT IV 600 V | |
| Insulation material | silicon | |
| Insulation type | double | |
| Cross-section area of the wire | 1 mm ² | |

| Color | Length | Index |
|-------|--------|--------------|
| Black | 1.2 m | WAPRZ1X2BLBB |

Accessory dedicated for:

PVM-1020 KIT

| Color | Length | Index |
|---------------------|--------|---------------|
| Black, with markers | 1.2 m | WAPRZ1X2BLBBN |

Accessory dedicated for:

MPI-540-PV

MPI-540

| Color | Length | Index |
|-------|--------|--------------|
| Blue | 1.2 m | WAPRZ1X2BUBB |
| Red | 5 m | WAPRZ005REBB |
| Red | 10 m | WAPRZ010REBB |
| Red | 20 m | WAPRZ020REBB |

Accessories dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520

MPI-507

MPI-506

MPI-502F

MRP-201

| Color | Length | Index |
|--------|--------|--------------|
| Red | 1.2 m | WAPRZ1X2REBB |
| Yellow | | WAPRZ1X2YEBB |

Accessories dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520

MPI-507

MPI-506

MPI-502F

MRP-201

PVM-1020 KIT



Test leads 5 kV


| | | |
|---------------------------------------|---|--|
| Plug | banana, 4 mm, safe, straight, nickel plated | |
| Measurement category | CAT III 1000 V / CAT IV 600 V | |
| Insulation material | silicon | |
| Insulation type | double | |
| Cross-section area of the wire | 1 mm ² | |

| Color | Length | Index |
|-------|--------|--------------|
| Black | 1.8 m | WAPRZ1X8BLBB |
| Red | | WAPRZ1X8REBB |

Accessories dedicated for:

MPI-536

MPI-525





Test lead on a H-frame



Test lead on a reel

Test leads on reels

They are designed specifically for outdoor work - they have increased resistance to mechanical damage. One end of the test leads is terminated with a secure banana plug (4 mm), while the other end has a 4 mm lamella for connecting it to the reel and directly to the probe driven into the ground.

| Color | Features | Index |
|-------|---------------|---------------|
| Blue | 15 m, H-frame | WAPRZ015BUBBN |
| Red | 30 m, H-frame | WAPRZ030REBBN |

Accessories dedicated for:

MPI-507

| Color | Features | Index |
|--------|------------|----------------|
| Blue | 15 m, reel | WAPRZ015BUBBSZ |
| Red | 25 m, reel | WAPRZ025REBBSZ |
| Blue | 25 m, reel | WAPRZ025BUBBSZ |
| Red | 30 m, reel | WAPRZ030REBBSZ |
| Yellow | 50 m, reel | WAPRZ050YEBBSZ |

Accessories dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535


MPI-530-IT

MPI-530

MPI-525

MPI-520

MPI-507



Test wire reel

index: WAPOZSZP1

It is used for winding leads. The reel is made of a material resistant to cracking, even at low temperatures. It is provided with an opening with a switching spring, enabling the reel to be directly inserted onto the probe driven into the ground. In order to improve the winding the leads, the reel is equipped with a folding handle. It also has a side terminal for connecting the test lead or a lead connecting a few wires.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520





installation



Hanging hook straps

index: WAPOZUCH1

The straps are designed for hanging the meters in safe locations to free the operator's hands. Their one end is provided with a hook, while the other with a Velcro strap used to attach the device.

Accessory dedicated for:

MPI-507

MPI-506

MPI-502F

MRP-201

PVM-1020 KIT



Universal magnetic hanging strap

index: WAPOZUCH6

Universal magnetic holder for mounting the meter to metal surfaces, e.g. switchgear doors, etc.

Accessory dedicated for:

MPI-507

MPI-506

MPI-502F



Universal cover

index: WAPOZUCH12

Protective cover for meters.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520





communication



Mini Bluetooth keyboard - S4 case

index: WAFUTS4

A mini keyboard enabling more comfortable data entry during measurement performance. Communication with the test instrument is wireless via Bluetooth. Protective case is equipped with hand fastening.

Accessories dedicated for:

MPI-530-IT

MPI-530



USB cable

index: WAPRZUSB

The cable with connectors of A and B type, compatible with USB 1.1 and 2.0. It is intended to connect the computer to Sonel devices equipped with USB sockets of B type. The cable is used to transfer the measurement results, configurations and updating the firmware of many meters.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520



OR-1 adapter

index: WAADAUSBOR1

The adapter is designed for wireless data transmission between a PC and meters equipped with a corresponding transceiver module. It provides two-way communications between the measuring device and computer. To use this feature, the computer must have SONEL S.A. software installed, compatible with MPI meters.

Accessory dedicated for:

MPI-525

MPI-520

MRP-201



LORA-S1 adapter

index: WAADAUSBLORA

The adapter is designed for wireless data transmission between the IRM-1 meter and the MPI-540-PV.

Accessory dedicated for:

MPI-540-PV





software

Manage your data!

USB
UNIVERSAL SERIAL BUS

MPI-540-PV MPI-540

MPI-536 MPI-535

MPI-530-IT MPI-530


MPI-525 MPI-520

IRM-1



MPI-525 MPI-520

MRP-201




MPI-507 MPI-506

MPI-502F PVM-1020



Sonel Reports PLUS

Download data from memory of test instruments and create necessary documentation.



Sonel Reader

Read the measurement data and save them on your computer.



- MPI-530-IT
- MPI-530



Sonel MPI Mobile

Read the measurement data. Add photographs, comments and voice memo - and share it.



Sonel Reports PLUS

index: WAPROREPORTSPLUS


Sonel Reports Plus supports creation of documentation after testing of electrical installation. The software communicates with Sonel test instruments, downloads data from memory of the devices and creates necessary documentation. Many useful functions are included in order to help creating documentation of the measurements. Sonel Reports Plus supports the meter by reading, downloading and uploading test structure from/to test instrument.

Features:

- every report can contain description page,
- tree structure presents a clear picture of the tested building and its rooms. Test structure can be uploaded to the meter and downloaded from it together with test results,
- user can print labels for test points,
- for every room user can add picture or scheme of electrical installation,
- software contains library of fuses,
- for every room user can create separate table with test results.

Software dedicated for:

- | | | | |
|--------------|---------|----------|---------|
| MPI-540-PV | MPI-540 | MPI-536 | MPI-535 |
| MPI-530-IT | MPI-530 | MPI-525 | MPI-520 |
| MPI-507 | MPI-506 | MPI-502F | MRP-201 |
| PVM-1020 KIT | | | |



Reports

Read data from test instrument

Search and save data from instrument in file

Open Report

Open existing report in order to edit

New Report

Create new empty Report

Import from

Import from epiNSTRUM

Data and software functions

Inspectors

Owners of installation

Test points

Fuses

Test labels

Manufacturer

www.sonel.pl

Register for full version

Help



software






Sonel Reader

index: WAPROREADER

This software is designed for downloading data from the meters. It enables data transfer to the PC, data saving in popular formats and printing.

Software dedicated for:

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535
- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520
- MPI-507
- MPI-506
- MPI-502F
- MRP-201
- PVM-1020 KIT




Sonel MPI Mobile

With the application you can **connect directly to the device** via Bluetooth and download the measurement data from the meter. After reading the measurements from the instrument, they can be easily and quickly **viewed**, but also **sent from the measurement place** to a person who can help interpret the data or perform a measurements documentation. To each measurement we can add, voice memo, note, GPS data, or photo. From the application level we also have **access to the meter's user manual**.

Software dedicated for:

- MPI-530-IT
- MPI-530





power supply

Rechargeable battery

The rechargeable battery for Sonel measuring devices. Its advantages include full leak-tightness, high capacity, low memory effect and high energy density. The battery may be charged even when it is not completely discharged. It is suitable as a backup energy bank in situations where the meter cannot be recharged.

| Name | Features | Index |
|-----------------------------|---------------|---------|
| NiMH rechargeable battery | 4.8 V 4.2 Ah | WAAKU07 |
| Li-Ion rechargeable battery | 11.1 V 3.4 Ah | WAAKU15 |

Accessory dedicated for:



WAAKU07

- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520



WAAKU15

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535



Battery pack

index: WAPOJ1

A container for the set of batteries for Sonel meters. It enables user to replace the battery pack with four LR14 alkaline batteries. It is suitable as a backup energy bank in situations where the meter cannot be recharged.

Accessory dedicated for:

- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520




Cable for battery charging from car cigarette lighter socket (12 V)

index: WAPRZLAD12SAM

It is connected directly to the meter. It allows user to charge the battery when the only power source is the car cigarette lighter socket. Discharged battery? No outlet? With this accessory you will complete your measurements without interruptions. The cable may be also used for other devices offered by SONEL S.A.

Accessory dedicated for:

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535
- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520





power supply



Z7 power supply


index: WAZASZ7

It is designed to power a number of Sonel measuring devices. It is equipped with IEC C8 male connector for connecting the power cord.

| | |
|-----------------------------|----------------|
| Input voltage | 100...240 V AC |
| Output voltage | 12 V DC |
| Maximum output power | 30 W |

Accessory dedicated for:

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535
- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520



Z24 power supply

index: WAZASZ24

5 V power supply with USB 2.0 output and a detachable micro-USB cable.

| | |
|-----------------------------|----------------|
| Input voltage | 100...240 V AC |
| Output voltage | 5 V DC |
| Maximum output power | 5 W |

Accessory dedicated for:

- IRM-1



230 V mains cable (IEC C7 plug)

index: WAPRZLAD230

It is designed to power a number of Sonel measuring devices. One of its ends is terminated with C7 plug, while the other with the mains plug of CEE 7/16 type („Europlug”).

| | |
|---------------------------------------|--------------------------|
| Cross-section area of the wire | 2 x 0.75 mm ² |
| Nominal voltage | 250 V AC/DC |

Accessory dedicated for:

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535
- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520





Charging set

index: WAKPLADMPI520

Power supply and charging set for batteries in selected MPI series test instruments.

| Name | Index |
|---|---------------|
| NiMH rechargeable battery | WAAKU07 |
| Cable for battery charging from car cigarette lighter socket (12 V) | WAPRZLAD12SAM |
| Z7 power supply | WAZASZ7 |
| 230 V mains cable (IEC C7 plug) | WAPRZLAD230 |



Accessory dedicated for:

MPI-530-IT

MPI-530

MPI-525

MPI-520



AZ-2 power supply adapter

index: WAADAAZ2

Designed for charging the analyzer battery directly from the electrical switchgear. It is particularly useful during long-term monitoring on facilities, where using the grid socket is not possible. Safety stackable plugs enable the charging of the analyzer while still having the option to perform measurements. Connected to the power supply adapter with an IEC C8 connector, AZ-2 does not require any additional adapters to function properly.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535





transportation



L2 carrying case

index: WAFUTL2

This case is designed for storage and transport of the meter and its accessories. The case has two main compartments, two pockets closed with the zipper and two Velcro pockets. It is also provided with a special pocket for documents and an insert for storing reels with test leads. The bottom of the case is protected against the contact with the ground by four feet. It is provided with a carrying handle and a strap for hanging it on the shoulder.

Accessory dedicated for:

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535
- MPI-530-IT
- MPI-530
- MPI-525
- MPI-520



L3 carrying case

index: WAFUTL3

The case specially designed for the safe storage and transport of long (80 cm) probes driven into the ground. It is provided with a strap for hanging it on the shoulder. Strong seams prevent tearing of the material. Parts of the case exposed to puncturing by the probe tip/blade are reinforced.

Accessory dedicated for:

- WASONG80V2



L4 carrying case

index: WAFUTL4

This case is designed for storage and transport of the meter and its accessories. It has three main compartments closed with a zipper and one pocket on the flap. The compartments are equipped with elastic bands for fixing the accessories. The case is provided with a strap for hanging it on the user's shoulder. Its bottom part is protected against contact with the ground by two feet.

Accessory dedicated for:

- MPI-520
- PVM-1020 KIT




L19 backpack

index: WAFUTL19

The backpack designed especially for comfortable carrying the meter with accessories. It is particularly useful when you want to have your hands free when moving with the equipment, e.g. when climbing a ladder. Equipped with a tablet pocket, it can accommodate a meter and a set of accessories. It is made of high-quality materials and has reinforced zippers and buckles.

Accessory dedicated for:

- MPI-540-PV
- MPI-540
- MPI-536
- MPI-535





M6 carrying case

index: WAFUTM6

This case is designed for storage and transport of the meter and its accessories. It has one main compartments closed with a zipper and one pocket on the flap. The main compartment is provided with an insert dividing it into smaller parts. It also has additional elastic bands for fixing the accessories. The case is provided with a strap for hanging it on the user's shoulder. Its bottom part is protected against contact with the ground by four feet.

Accessory dedicated for:

MPI-507

MPI-506

MRP-502

MRP-201

PVM-1020



M13 carrying case

index: WAFUTM13

This case is designed for storage and transport of the meter and its accessories. Protects the contents against soil and damage. Equipped with a shoulder strap.

Accessory dedicated for:

MPI-540-PV



M14 carrying case

index: WAFUTM14

This case is designed for storage and transport of the meter and its accessories. Protects the contents against soil and damage. Equipped with a shoulder strap.

Accessory dedicated for:

IRM-1



Hard carrying case

It ensures the safe transport and storage of the instrument together with its accessories. A large number of compartments allows for effective protection of a large amount of equipment.

| Set | Index |
|--------------------------|-----------|
| XL-12 hard carrying case | WAWALXL12 |
| XL-13 hard carrying case | WAWALXL13 |

Accessories dedicated for:



XL-12 carrying case

MPI-540-PV

MPI-540

MPI-536

MPI-535



XL-13 carrying case

MPI-530-IT

MPI-530





transportation



L2 hanging straps

index: WAPOZSZEKPL

The set includes a strap for carrying the meter in the hand, and a strap for hanging the device on the shoulder and around the neck. The longer strap is adjustable.

Accessory dedicated for:

MPI-540-PV

MPI-540

MPI-536

MPI-535

MPI-530-IT

MPI-530

MPI-525

MPI-520



M1 hanging straps

index: WAPOZSZE4

The hanging straps are designed for carrying and hanging Sonel meters. Their length is adjustable. The straps may be used to hang the meter around the neck or on the shoulder.

Accessory dedicated for:

MPI-507




















MPI-506





















MPI-502F





















MRP-201





















PVM-1020 KIT







































| Photo | Name | Index | MPI-540-PV Solar | MPI-540-PV | MPI-540-PV Start | MPI-540 | MPI-540 Start | MPI-536 | MPI-535 | MPI-530/530-HT | MPI-525 | MPI-520 | MPI-520 Start | MPI-507 | MPI-506 | MPI-502F | MRP-201 | PVM-1020 KIT | PVM-1020 | IRM-1 |
|---|--|--------------|------------------|------------|------------------|---------|---------------|---------|---------|----------------|---------|---------|---------------|---------|---------|----------|---------|--------------|----------|-------|
|  | PVM-1020 photovoltaic meter | WMGBPVM1020 | | | | | | | | | | | | | | | | 1 | 1 | • |
|  | IRM-1 solar radiation and temperature meter | WMGBIRM1 | • | • | • | | | | | | | | | | | | | 1 | • | 1 |
|  | AC-16 line splitter | WAADAAC16 | • | • | • | • | • | | | • | | • | • | | | | | | • | • |
|  | AGT-16C three-phase socket adapter 16 A | WAADAAGT16C | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • |
|  | AGT-16P three-phase socket adapter 16 A | WAADAAGT16P | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • |
|  | AGT-16T industrial socket adapter 16 A | WAADAAGT16T | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • |
|  | AGT-32C three-phase socket adapter 32 A | WAADAAGT32C | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • |
|  | AGT-32P three-phase socket adapter 32 A | WAADAAGT32P | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • |
|  | AGT-32T industrial socket adapter 32 A | WAADAAGT32T | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • |
|  | AGT-63P three-phase socket adapter 63 A | WAADAAGT63P | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • |
|  | AutoISO-1000C adapter | WAADAAISO10C | • | • | • | • | • | | • | • | | • | • | | | | | | | |
|  | AutoISO-2500 adapter | WAADAAISO25 | | | | | | • | | | • | | | | | | | | | |
|  | EVSE-01 adapter | WAADAEVSE01 | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | | | |
|  | PVM-1 adapter | WAADAPVM1 | 1 | 1 | 1 | | | | | | | | | | | | | | | |
|  | IRM-1 mounting&measuring set (solar radiation meter mounting kit for PV panels + probe for measuring the temperature of PV panels and the ambient temperature) | WASONTPVCKPL | • | • | • | | | | | | | | | | | | | 1 | | 1 |
|  | Solar radiation measurement set (IRM-1 solar radiation and temperature meter + IRM-1 mounting&measuring set + Z24 power supply + LORA-S1 adapter for data transmission + M14 carrying case) | WMGBIRM1MPI | 1 | • | • | | | | | | | | | | | | | | | |
|  | TWR-1J - RCD breaker testing adapter | WAADATWR1J | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | | | |
|  | WS-01 adapter with START button with UNI-Schuko plug | WAADAWS01 | | | | | | | | | | | | | | | • | • | | |
|  | WS-03 adapter with START button with UNI-Schuko plug | WAADAWS03 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | |

| Photo | Name | Index | MPI-540-PV Solar | MPI-540-PV | MPI-540-PV Start | MPI-540 | MPI-540 Start | MPI-536 | MPI-535 | MPI-530/530-IT | MPI-525 | MPI-520 | MPI-520 Start | MPI-507 | MPI-506 | MPI-502F | MRP-201 | PVM-1020 KIT | PVM-1020 | IRM-1 | |
|---|--|--------------|------------------|------------|------------------|---------|---------------|---------|---------|----------------|---------|---------|---------------|---------|---------|----------|---------|--------------|----------|-------|--|
| | | | | | | | | | | | | | | | | | | | | | |
|  | WS-04 adapter with UNI-Schuko plug | WAADAWS04 | • | • | • | • | • | • | • | • | • | • | • | • | • | | | | | | |
|  | WS-05 adapter with UNI-Schuko plug | WAADAWS05 | | | | | | | | | | | | • | • | • | 1 | | | | |
|  | WS-06 adapter (miniDIN-4P plug) | WAADAWS06 | • | • | • | • | • | • | • | • | | | | | | | | | | | |
|  | WS-07 adapter for measuring Z(L-N) | WAADAWS07 | | | | | | | | | | | | • | • | • | | | | | |
|  | WS-09 adapter (pin probe) | WAADAWS09 | • | • | • | • | • | • | • | | | | | | | | | | | | |
|  | Voltage adapters with M4/M6 thread (set of 4 pcs.) | WAADAM4M64 | 1 | 1 | 1 | 1 | 1 | | | | | | | | | | | | | | |
|  | MC4-banana sockets adapter (set of 2 pcs.) | WAADAMC4 | 1 | 1 | 1 | | | | | | | | | | | | | 1 | 1 | | |
|  | MC4 splitter for power measurement in PV systems (set of 2 pcs.) | WAADAMC4SKPL | | | | | | | | | | | | | | | | • | • | | |
|  | Adapter for C-PV clamp | WAADACPV | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
|  | Double-wire test lead 2 m, for N-1 clamps (banana plugs) | WAPRZ002DZBB | • | • | • | • | • | • | • | • | | | | | | | | | | | |
|  | F-1A flexible coil (Ø360 mm) | WACEGF1AOKR | • | • | • | • | • | | | • | | | | | | | | | | | |
|  | F-2A flexible coil (Ø235 mm) | WACEGF2AOKR | • | • | • | • | • | | | • | | | | | | | | | | | |
|  | F-3A flexible coil (Ø120 mm) | WACEGF3AOKR | 3 | 3 | • | 3 | • | | | • | | | | | | | | | | | |
|  | N-1 transmitting clamp (Ø52 mm) | WACEGN1BB | • | • | • | • | • | • | • | • | | | | | | | | | | | |
|  | C-3 current clamp (Ø52 mm) | WACEGC3OKR | • | • | • | • | • | • | • | • | | • | • | | | | | | | | |
|  | C-4A current clamp (Ø52 mm) | WACEGC4AOKR | • | • | • | • | • | | | | | | | | | | | | | | |
|  | C-5A current clamp (Ø39 mm) | WACEGC5AOKR | • | • | • | • | • | | | | | | | | | | | | | | |
|  | C-6A current clamp (Ø20 mm) | WACEGC6AOKR | • | • | • | • | • | | | • | | | | | | | | | | | |
|  | C-7A current clamp (Ø24 mm) | WACEGC7AOKR | • | • | • | • | • | | | | | | | | | | | | | | |
|  | C-PV clamp | WACEGCPVOKR | 1 | 1 | 1 | | | | | | | | | | | | | 1 | 1 | | |

| Photo | Name | Index | MPI-540-PV Solar | MPI-540-PV | MPI-540-PV Start | MPI-540 | MPI-540 Start | MPI-536 | MPI-535 | MPI-530/530-IT | MPI-525 | MPI-520 | MPI-520 Start | MPI-507 | MPI-506 | MPI-502F | MRP-201 | PVM-1020 KIT | PVM-1020 | IRM-1 |
|---|--|----------------|------------------|------------|------------------|---------|---------------|---------|---------|----------------|---------|---------|---------------|---------|---------|----------|---------|--------------|----------|-------|
|  | Crocodile clip, black, 1 kV, 20 A | WAKROBL20K01 | 1 | 1 | 1 | 1 | 1 | | | | 1 | | | | | | | 1 | 1 | |
|  | Crocodile clip, red, 1 kV, 20 A | WAKRORE20K02 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | 1 | 1 | 1 | 1 | • | • | 1 | 1 | |
|  | Crocodile clip, blue, 1 kV, 20 A | WAKROBU20K02 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | • | • | • | • | • | • | | | |
|  | Crocodile clip, yellow, 1 kV, 20 A | WAKROYE20K02 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
|  | Crocodile clip, black, 11 kV, 32 A | WAKROBL32K09 | | | | | | 1 | | | 1 | | | | | | | | | |
|  | Crocodile clip, red, 11 kV, 32 A | WAKRORE32K09 | | | | | | • | | | • | | | | | | | | | |
|  | Test lead 1.2 m, black, 1 kV (banana plugs) | WAPRZ1X2BLBB | | | | | | | | | | | | | | | | 1 | 1 | |
|  | Test lead 1.2 m, black, 1 kV with markers (banana plugs) | WAPRZ1X2BLBBN | 1 | 1 | 1 | 1 | 1 | | | | | | | | | | | | | |
|  | Test lead 1.2 m, red, 1 kV (banana plugs) | WAPRZ1X2REBB | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
|  | Test lead 1.2 m, blue, 1 kV (banana plugs) | WAPRZ1X2BUBB | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | |
|  | Test lead 1.2 m, yellow, 1 kV (banana plugs) | WAPRZ1X2YEBB | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
|  | Test lead 5 m, red, 1 kV (banana plugs) | WAPRZ005REBB | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | | | |
|  | Test lead 10 m, red, 1 kV (banana plugs) | WAPRZ010REBB | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | | | |
|  | Test lead 20 m, red, 1 kV (banana plugs) | WAPRZ020REBB | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | | | |
|  | Test lead 30 m, red, 1 kV (banana plugs) | WAPRZ030REBBN | | | | | | | | | | | | 1 | | | | | | |
|  | Test lead 15 m, blue, 1 kV (banana plugs) | WAPRZ015BUBBN | | | | | | | | | | | | 1 | | | | | | |
|  | Test lead 15 m, blue (on a reel) | WAPRZ015BUBBSZ | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | • | | | | | | |
|  | Test lead 25 m, red (banana plugs, on a reel) | WAPRZ025REBBSZ | • | • | • | • | • | • | • | • | • | • | • | • | | | | | | |
|  | Test lead 25 m, blue (banana plugs, on a reel) | WAPRZ025BUBBSZ | • | • | • | • | • | • | • | • | • | • | • | • | | | | | | |
|  | Test lead 30 m, red (banana plugs, on a reel) | WAPRZ030REBBSZ | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | • | | | | | | |

| Photo | Name | Index | MPI-540-PV Solar | MPI-540-PV | MPI-540-PV Start | MPI-540 | MPI-540 Start | MPI-536 | MPI-535 | MPI-530/530-IT | MPI-525 | MPI-520 | MPI-520 Start | MPI-507 | MPI-506 | MPI-502F | MRP-201 | PVM-1020 KIT | PVM-1020 | IRM-1 | |
|---|--|----------------|------------------|------------|------------------|---------|---------------|---------|---------|----------------|---------|---------|---------------|---------|---------|----------|---------|--------------|----------|-------|---|
|  | Test lead 50 m, yellow (banana plugs, on a reel) | WAPRZ050YEBBSZ | • | • | • | • | • | • | • | • | • | • | • | • | | | | | | | |
|  | Test lead 1.8 m, black, 5 kV (banana plugs, shielded) | WAPRZ1X8BLBB | | | | | | 1 | | | | 1 | | | | | | | | | |
|  | Test lead 1.8 m, red, 5 kV (banana plugs) | WAPRZ1X8REBB | | | | | | 1 | | | | 1 | | | | | | | | | |
|  | PRS-1 resistance test probe | WASONPRS1 | • | • | • | • | • | • | • | • | • | • | • | • | | | | | | | |
|  | LP-1 light meter probe (miniDIN-4P plug) | WAADALP1 | • | • | • | • | • | • | • | • | • | | | | | | | | | | |
|  | LP-1 light meter probe for MPI (set, WS-06 plug) | WAADALP1KPL | • | • | • | • | • | • | • | • | • | | | | | | | | | | |
|  | LP-10A light meter probe (miniDIN-4P plug) | WAADALP10A | • | • | • | • | • | • | • | • | • | | | | | | | | | | |
|  | LP-10A light meter probe for MPI (set, WS-06 plug) | WAADALP10AKPL | • | • | • | • | • | • | • | • | • | | | | | | | | | | |
|  | LP-10B light meter probe (miniDIN-4P plug) | WAADALP10B | • | • | • | • | • | • | • | • | • | | | | | | | | | | |
|  | LP-10B light meter probe (set, WS-06 plug) | WAADALP10BKPL | • | • | • | • | • | • | • | • | • | | | | | | | | | | |
|  | Foldable pin probe, 1 kV, 2 m (banana socket) | WASONSP2M | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | | | |
|  | Pin probe, black 1 kV (banana socket) | WASONBLOGB1 | | | | | | | | | | | | | | | | | • | • | |
|  | Pin probe, red 1 kV (banana socket) | WASONREOGB1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
|  | Pin probe, blue 1 kV (banana socket) | WASONBUOGB1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | | | | |
|  | Pin probe, yellow 1 kV (banana socket) | WASONYE0GB1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | 1 | 1 | • | • | • | • | | |
|  | Pin probe, black 5 kV (banana socket) | WASONBLOGB2 | | | | | | | • | | | • | | | | | | | | | |
|  | Pin probe, red 5 kV (banana socket) | WASONREOGB2 | | | | | | | 1 | | | 1 | | | | | | | | | |
|  | Probe for measuring the temperature of PV panels and the ambient temperature | WASONTPVC | • | • | • | | | | | | | | | | | | | | • | | • |
|  | Earth contact test probe (rod), 25 cm | WASONG25 | | | | | | | | | | | | | 2 | | | | | | |
|  | Earth contact test probe (rod), 30 cm | WASONG30 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 | • | • | | | | | | | |

| Photo | Name | Index | MPI-540-PV Solar | MPI-540-PV | MPI-540-PV Start | MPI-540 | MPI-540 Start | MPI-536 | MPI-535 | MPI-530/530-IT | MPI-525 | MPI-520 | MPI-520 Start | MPI-507 | MPI-506 | MPI-502F | MRP-201 | PVM-1020 KIT | PVM-1020 | IRM-1 |
|---|---|---------------|------------------|------------|------------------|---------|---------------|---------|---------|----------------|---------|---------|---------------|---------|---------|----------|---------|--------------|----------|-------|
|  | Earth contact test probe (rod), 80 cm | WASONG80V2 | • | • | • | • | • | • | • | • | • | • | • | • | | | | | | |
|  | Cramp (banana socket) | WAZACIMA1 | • | • | • | • | • | • | • | • | • | • | • | • | | | | | | |
|  | CS-1 cable simulator | WAADACS1 | • | • | • | • | • | • | • | • | • | • | • | | | | | | | |
|  | CS-5kV calibration box | WAADACS5KV | | | | | | • | | | • | | | | | | | | | |
|  | NiMH battery 4.8 V 4.2 Ah | WAAKU07 | | | | | | | | 1 | 1 | • | • | | | | | | | |
|  | Li-Ion battery 11.1 V 3.4 Ah | WAAKU15 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | | | | |
|  | Battery container | WAPQJ1 | | | | | | | | | • | • | 1 | 1 | | | | | | |
|  | Z7 power supply | WAZASZ7 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | • | | | | | | | |
|  | Z24 5 V power supply with USB 2.0 output and a detachable micro-USB cable | WAZASZ24 | | | | | | | | | | | | | | | | 1 | | 1 |
|  | Mains cable with IEC C7 plug | WAPRZLAD230 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | • | | | | | | | |
|  | MPI charging set (charger + battery) | WAKPLADMPI520 | | | | | | | | | • | • | • | • | | | | | | |
|  | AZ-2 power supply adapter (IEC C7 plug/banana connectors) | WAADAAZ2 | • | • | • | • | • | • | • | | | | | | | | | | | |
|  | Cable for battery charging from car cigarette lighter socket (12 V) | WAPRZLAD12SAM | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | • | • | | | | | | | |
|  | Test wire reel | WAPZSZP1 | • | • | • | • | • | • | • | • | • | • | • | | | | | | | |
|  | L2 hanging straps (set) | WAPZSZKPL | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | |
|  | M1 hanging straps | WAPZSZE4 | | | | | | | | | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
|  | M1 hanging hook straps | WAPZUCH1 | | | | | | | | | | | | 1 | 1 | 1 | • | • | • | |
|  | Magnetic hanging strap | WAPZUCH6 | | | | | | | | | | | | • | • | • | | | | |
|  | Cover (universal) | WAPZUCH12 | • | • | • | • | • | • | • | • | • | • | • | | | | | | | |
|  | Solar radiation meter mounting kit for PV panels | WAPZUCHPV | • | • | • | | | | | | | | | | | | | 1 | | 1 |

| Photo | Name | Index | MPI-540-PV Solar | MPI-540-PV | MPI-540-PV Start | MPI-540 | MPI-540 Start | MPI-536 | MPI-535 | MPI-530/530-IT | MPI-525 | MPI-520 | MPI-520 Start | MPI-507 | MPI-506 | MPI-502F | MRP-201 | PVM-1020 KIT | PVM-1020 | IRM-1 | |
|---|--|-----------------|------------------|------------|------------------|---------|---------------|---------|---------|----------------|---------|---------|---------------|---------|---------|----------|---------|--------------|----------|-------|---|
| | | | | | | | | | | | | | | | | | | | | | |
|  | Clamp for mounting the solar radiation meter to the solar panels | WAZACPV | • | • | • | | | | | | | | | | | | | • | | • | |
|  | L2 carrying case | WAFUTL2 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | • | | | | | | | | |
|  | L3 carrying case for a 80 cm rods | WAFUTL3 | • | • | • | • | • | • | • | • | • | • | • | • | | | | | | | |
|  | L4 carrying case | WAFUTL4 | | | | | | | | | | • | 1 | | | | | | 1 | | |
|  | L19 backpack | WAFUTL19 | • | • | • | • | • | • | • | | | | | | | | | | | | |
|  | M6 carrying case | WAFUTM6 | | | | | | | | | | | | 1 | 1 | 1 | 1 | | | 1 | |
|  | M13 carrying case | WAFUTM13 | 1 | 1 | 1 | | | | | | | | | | | | | | | | |
|  | M14 carrying case | WAFUTM14 | | | | | | | | | | | | | | | | | | | 1 |
|  | XL12 hard carrying case | WAWALXL12 | | • | • | • | • | • | • | | | | | | | | | | | | |
|  | XL13 hard carrying case | WAWALXL13 | | | | | | | | • | | | | | | | | | | | |
|  | S4 armband case for mini Bluetooth keyboard | WAFUTS4 | | | | | | | | • | | | | | | | | | | | |
|  | USB cable | WAPRZUSB | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
|  | LORA-S1 USB adapter for data transmission | WAADAUSBLORA | • | • | • | | | | | | | | | | | | | | | | |
|  | OR-1 USB wireless receiver | WAADAUSBOR1 | | | | | | | | | • | • | • | | | | | 1 | | | |
|  | PC software: Sonel Reports PLUS | WAPROREPORTSPUS | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • | • |
|  | PC software: Sonel Reader | WAPROREADER | 1 | 1 | 1 | 1 | 1 | 1 | • | • | • | • | • | • | • | • | • | • | • | • | • |

1, 2, 4 - the number of standard accessories
• - optional accessory



