

SUZUKA





BRICK & STONE VENEER . TEXTURED PAINT . WALL PANEL . ECES . TEXTURE COATING . PEBBLE STONE COATING

Photos of the products shown in this catalogue may vary in color due to lighting condition & printing. We suggest you examine actual product samples before ordering.



## suzuka.com.my

**f** suzuka.group | Hotline: +6012-258 7388







KRETERRA-E1.1-2407

WALL FINISH PROFESSION

SINCE 1977


CEMENT EFFECT FLOOR COATING

FOR THE INTERIOR













## APPLICATION TECHNIQUE SUBSTRATE REQUIREMENT & PREPARATION:

Substrate concrete or screed should be a minimum of compressive strength 25N/mm<sup>2</sup> and adhesive pull-off strength of minimum 1.5N/mm<sup>2</sup> (concrete failure).

- Concrete substrates must be prepared mechanically using abrasive blast cleaning or scarifying equipment to remove cement laitance and achieve an open textured surface.
- Crack and hollows should be properly remedied.
- Rough contaminations and high spots can be removed by grinding.
- The substrate should be clean and free from laitance, oil, dust, paint residues, algae, loose and friable material must be completely removed from all surfaces before application of the product.



STEP 1: GRINDING

Grind the floor to ensure a rough surface for moisture barrier application.



STEP 2 : MOISTURE BARRIER

Mix Part A and Part B in 20L pail for 5 seconds, add component C, mix thoroughly for at least 2 minutes using a suitable electrical stirrer with helical paddle (with 750 watt high power mixer) until a smooth homogenous consistency is achieved.

Spread the mixed MB with flat/notch trowel to the required thickness. Immediately after, use the spike



STEP 3: SANDING

After the surface dried for 24 hours, sand the surface with sandpaper (7 grit) to ensure a smooth surface. Remove the dust & the dirt from the



**STEP 4: PRIMER** 

Roll a layer of primer on the entire surface. Let it dry for at least 1 hour.



**STEP 5: TEXTURE COAT** 

Scrape a layer of texture coat randomly on the entire surface. Let dry for 40 minutes.

A second layer of texture coat may be applied to enhance the texture effects.



After the surface dried, sand the surface with sandpaper (7 grit) to ensure a smooth surface. Remove the dust & the dirt from the surface.



STEP 7: TOPCOAT

Mix Part A & Part B of topcoat. Roll a layer of topcoat on the entire surface. Use a dry and clean roller to absorb the excess topcoat. Let it fully dry for **14 hours**.















Topcoat

Primer

WPU-G (GLOSS) Water based PU Topcoat

**COATING SYSTEM** 

**Moisture Barrier** 

Cementitious Moisture Barrier

Self Smoothening Epoxy

KRP - Kreterra Primer

**Texture Coat** 

KRT - Kreterra Texture

Material

WPU-M (MATT) Water based PU Topcoat

**5.5 KG** (4.5 : 1) Part A : 4.5 kg Part B : 1 kg

**5 KG** (4 : 1)

Part A : 3 kg

Part B : 1 kg

Packing (Weight Ratio)

Part A : 3.5 kg

Part B : 1.5 kg

Part C : 19 kg

Coating Interval (Hrs)

24

Hours

4

Hours

2

Hours

14

Hours

 $2 \text{ kg/m}^2 (1 \text{ mm})$ 

7 - 9 m<sup>2</sup>/ltr

 $5 - 6 \, \text{m}^2/\text{ltr}$ 

0.13 kg/m<sup>2</sup>

@ 50µ

Trowel,

Roller

Trowel

Spray &

Roller

Paint Roller

& Spike Roller