

#### **Package Content:**

No.	Description	Qty
1	MAG MW40 Controller Board 1 nos	
2	Transformer 3 amp 1 nos	
3	12v, 7Ah Backup Battery 1 nos	
4	Weatherproof PVC Box 1 nos	
5	Stainless Steel Arm (DC Motor) 1 pair	
6	Rear Bracket 1 pair	
7	Manual Release Key 1 pair	
8	Remote Control Receiver 1 nos	
9	Remote Control Transmitter 3 nos	
10	Wall Mount Metal Plate 1 pair	
11	Front Connection Bracket 1 pair	
12	Front Metal Plate	1 pair
13	Stopper 1 nos	
14	Bolt & Nuts 1 pack	


## **Technical Specification:**

Description	Parameter			
Driving Method	Electro – mechanical screw driver piston type			
Operating voltage	DC 16 V for first speed DC 8 V for second speed			
Motor Output	15 watt per arm			
Motor Amp.	2.1			
Piston Displace	32 cm			
Piston Speed	2.9 cm/sec			

Description	Parameter
Back-up battery	12 volt. 7Ah rechargeable
Cafaty Clutch	Electric current sensing using H-Amp Auto
Safety Clutch	Reverse
Electric Controller	Micro-processor based
Temperature	0 to 80°C
Gear Box	Three stages planetary reducer
Manual Operation	Special released key during power failure
Max. Weight of gate	250 kg per wing with force adjustable

## **Installation Guide:**











## Dimension structure for swing gate



# **Typical Installation Diagram:**



#### **Control Panel:**



Preset				
Open Hi-speed	Adjust from 0~20 sec for opening at hi-speed			
Close Hi-speed	Adjust from 0~20 sec for closing at hi-speed			
M2 Delay	Adjust from 0~6 sec for closing gate with lock			
Total Time	Adjust from 5~30 sec total travelling time			
M1	Adjust from 1.5~4amp for motor 1 sensitivity of hi-amp cut			
M2	Adjust from 1.5~4amp for motor 2 sensitivity of hi-amp cut			
LED				
AC ON	When AC power and Red LED lit			
Close	Turn on power Red close LED lit or when closing			
Open	When opening Green LED lit until close button pressed			
CPU	Turn on power Red LED 1 sec continue flash			
2 Side	When 2 side push button pressed (LED blink once)			
½ S	When ½S push button pressed & hold for 3 sec (LED blink			
	once)			
1 Side	When 1 side push button pressed (LED blink once)			
Jumper				
Open reverse	"Y" for lock with 0.5 sec reverse when opening.			
OP/CL HWS	Press against button gate will reverse close/open at half			
	way. Press against button gate will stop at half way.			
Hi speed	"Y" when opening hi-amp cut gate will stop, when closing			
overload	hi-amp cut gate will reverse.			
Light – DLY	Pillar light remain on for 30 sec after gate close.			
– FLW	Pillar light follow motor cut off time.			

Wiring Connection		
Push Button	2 side	Press for both gate open/close
	½ S	Press & hold for 3 sec. Lock side gate open. (for 2 wire only)
	1 side	Press for lock side gate open.
Motor		
Motor 1		Connect to arm motor
Motor 2 (Delay)		Connect to arm motor with lock
Lock		Optional DC12V lock require
Trans Secondary		Connect 3amp main transformer secondary terminal
Trans		Connect 3amp main transformer primary terminal
Light		Connect to pillar light LIVE wire terminal
AC230V		Connect to AV230V main power supply